



HP Jetdirect

en3700

ew2400

620n

**Administrator's
Guide**

Administrator's Guide

HP Jetdirect Print Servers

Models: 620n
 en3700
 ew2400

© 2003-2004 Copyright Hewlett-Packard Development Company, L.P.
© 2002 Copyright Hewlett-Packard Company

All rights reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained in this document is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Edition 4, 9/2004

Trademark Credits

Microsoft®, MS-DOS®, Windows®, are U.S. registered trademarks of Microsoft Corporation. NetWare® and Novell® are registered trademarks of Novell Corporation. IBM®, IBM Warp Server®, Operating System/2® are registered trademarks of International Business Machines Corp. Ethernet is a registered trademark of Xerox Corporation. PostScript is a trademark of Adobe Systems, Incorporated. UNIX® is a registered trademark of the Open Group.

Table of Contents

1. Introducing the HP Jetdirect Print Server

Introduction	7
Supported Print Servers.....	8
Supported Network Protocols	8
Security Protocols	10
Supplied Manuals.....	12
HP Support	12
Product Registration.....	14
Product Accessibility	14

2. HP Software Solutions Summary

Introduction	15
HP Install Network Printer Wizard (Windows).....	18
HP Jetdirect Printer Installer for UNIX	19
HP Web Jetadmin.....	20
Internet Printer Connection Software.....	23
HP IP/IPX Printer Gateway for NDPS.....	26
HP WPS Assistant (Mac OS X).....	27
HP LaserJet Utilities for Mac OS.....	28

3. TCP/IP Configuration

Introduction	34
Default IP Address	35
Using BOOTP/TFTP.....	40
Using DHCP.....	62
Using RARP	70
Using the arp and ping Commands.....	72
Using Telnet.....	74
Using the Embedded Web Server	98
Using the Printer Control Panel.....	99
Moving to Another Network.....	100

4. Using the Embedded Web Server

Introduction	101
Requirements.....	103
Viewing the Embedded Web Server	104
HP Jetdirect Home Tab.....	107
Networking Tab	109
Other Links	153

5. Configuring for LPD Printing	
Introduction	154
LPD Setup Overview	156
LPD on UNIX Systems	158
LPD on Windows NT/2000/Server 2003 Systems	162
LPD on Windows XP Systems.....	167
LPD on Mac OS Systems.....	169
6. FTP Printing	
Introduction	172
Requirements	172
Print Files	173
Using FTP Printing	173
Example of an FTP Session.....	178
7. Security Features	
Introduction	179
Using Security Features.....	183
8. Troubleshooting the HP Jetdirect Print Server	
Introduction	185
Resetting to Factory Defaults	186
General Troubleshooting.....	188
Troubleshooting Wireless Print Servers	196
Troubleshooting an LPD UNIX Configuration	200
9. HP Jetdirect Configuration Page	
Introduction	202
Configuration Page Format.....	203
Configuration Page Messages	205
Error Messages	225
A. TCP/IP Overview	
Introduction	236
IP Address	237
Configuring IP Parameters	240
Subnets.....	241
Gateways.....	242
Syslog Server	242

B. The HP Jetdirect EIO Control Panel Menu

Introduction	245
Classic Control Panel	246
Graphical Control Panel	249

C. OpenSSL Statements

Index

Introducing the HP Jetdirect Print Server

Introduction

HP Jetdirect print servers allow you to connect printers and other devices directly to a network. By attaching a device directly to a network, you can install it in a convenient location and share it with multiple users. In addition, a network connection allows data transfers to or from the device at network speeds.

HP Jetdirect EIO internal print servers are installed in HP printers that have a compatible enhanced input/output (EIO) slot.

HP Jetdirect external print servers connect printers to the network by adapting the printer's USB port to the network.

Note

Unless otherwise specified, the term print server in this manual refers to the HP Jetdirect print servers and not a separate computer running print server software.

When connected through a wireless connection to your network, an HP Jetdirect wireless print server provides the same printing services as Jetdirect print servers connected by network cables.

Supported Print Servers

The features and capabilities of HP Jetdirect print servers depend on the print server's product model and its operating firmware version. See [Table 1.1](#).

Table 1.1 Supported Products

Model	Product Number	Printer Connect	Network Connect	Network Protocols and Features	Firmware Version***
ew2400	J7951A	USB 2.0	10/100TX wired, or 802.11g wireless	Limited*	V.28.xx.nnnnnnnn
en3700	J7942A	USB 2.0	10/100TX	Full**	V.28.xx.nnnnnnnn
620n	J7934A	EIO slot	10/100TX	Full**	V.28.xx.nnnnnnnn
<p>* Limited support includes TCP/IP, IPX Direct Mode printing, AppleTalk (EtherTalk), LPD/Windows printing, limited upgrade capabilities.</p> <p>** Full support includes TCP/IP, IPX/SPX, AppleTalk (EtherTalk), LPR/LPD, Security. See Table 1.2.</p> <p>*** xx represents a release number. nnnnnnnn, if it appears, is an encoded value for HP support use only.</p>					

The installed firmware version can be identified using various methods, including the HP Jetdirect configuration page (see [Chapter 9](#)), Telnet (see [Chapter 3](#)), embedded Web server (see [Chapter 4](#)), and network management applications. For firmware updates, see [“Firmware Upgrades”](#).

Supported Network Protocols

Note For HP Jetdirect wireless print servers, this section assumes that a wireless connection to your network has been established.

The supported network protocols, and popular network printing environments that use those protocols, are listed in [Table 1.2](#).

Table 1.2 Supported Network Protocols

Supported Network Protocols	Network Printing Environments*	Product Support
TCP/IP	Microsoft Windows 98/Me/NT4.0/2000/XP (32- and 64-bit), Direct Mode printing Novell NetWare 5, 6.x using NDPS UNIX and Linux, including: Hewlett-Packard HP-UX, Sun Microsystems Solaris (SPARCsystems only), IBM AIX**, HP MPE-iX**, RedHat Linux**, SuSE Linux** LPR/LPD (Line Printer Daemon)** IPP (Internet Printing Protocol) FTP (File Transfer Protocol)	J7951A (ew2400)*** J7942A (en3700) J7934A (620n)
IPX/SPX and compatible	Novell NetWare** Microsoft Windows 98/Me/NT4.0/2000/XP (32-bit only), Direct Mode printing	J7951A (ew2400)*** J7942A (en3700) J7934A (620n)
AppleTalk (EtherTalk only)	Apple Mac OS	J7951A (ew2400) J7942A (en3700) J7934A (620n)
DLC/LLC	Microsoft Windows NT**	J7942A (en3700) J7934A (620n)
<p>* Refer to the current HP Jetdirect product data sheets for additional network systems and versions. For operation with other network environments, consult your system vendor or authorized HP dealer.</p> <p>** For these network systems, contact your network system vendor for software, documentation, and support.</p> <p>*** Supported: Windows IP/IPX Direct Mode printing and LPD/Windows are supported. Not Supported: NetWare, IPP, LPD/UNIX are not supported.</p>		

If not supplied with this product, HP network setup and management software for supported systems may be obtained from HP support at:

http://www.hp.com/support/net_printing

For software to set up network printing on other systems, contact your system vendor.

Security Protocols

SNMP (IP and IPX)

SNMP (Simple Network Management Protocol) is used by network management applications for device management. HP Jetdirect print servers support SNMP and standard MIB-II (Management Information Base) objects on both IP and IPX networks.

HP Jetdirect ew2400 print servers support an SNMP v1/v2c agent only.

Full-featured HP Jetdirect print servers (such as 620n and en3700) support an SNMP v1/v2c agent, and an SNMP v3 agent for enhanced security.

HTTPS

The following HP Jetdirect print servers support HTTPS (Secure Hyper Text Transfer Protocol) for secure, encrypted management communications between the embedded Web server and your Web browser.

- HP Jetdirect 620n internal print server (EIO)
- HP Jetdirect en3700 external print server
- HP Jetdirect ew2400 external wired/wireless print server

Authentication

EAP/802.1X Server-Based Authentication

As a network client, HP Jetdirect full-featured print servers (such as 620n, en3700) support network access using the Extensible Authentication Protocol (EAP) on an IEEE 802.1X network. The IEEE 802.1X standard provides a port-based authentication protocol where a port can allow or block access depending on client authentication results.

When using an 802.1X connection, the print server supports Extensible Authentication Protocol (EAP) with an authentication server, such as a RADIUS (Remote Authentication Dial In User Service, RFC 2138) server.

Full-featured print servers support the following EAP/802.1X method:

- **PEAP** (Protected Extensible Authentication Protocol). PEAP is a mutual authentication protocol that uses digital certificates for network server authentication and passwords for client authentication. For additional security, the authentication exchanges are encapsulated within TLS (Transport Layer Security). Dynamic encryption keys are used for secure communications.

The network infrastructure device that connects the print server to the network (such as an HP Procurve switch) must also support the EAP/802.1X method used. In conjunction with the authentication server, the infrastructure device can control the degree of network access and services available to the print server client.

To configure the print server for EAP/802.1X authentication, you must access the embedded Web server through your Web browser. For more information, see [Chapter 4](#).

Wireless Print Server Authentication

HP Jetdirect ew2400 wired/wireless external print servers do not support server-based authentication. They are intended for small-office networks where authentication servers are not typically used.

However, for security on wireless networks, some form of client authentication is highly desired. The HP Jetdirect ew2400 supports the following wireless authentication methods:

- **Shared Key.** Authentication is based on a secret, common Wired Equivalent Privacy (WEP) key that must be configured on each wireless device. A device that does not have the proper WEP key cannot access the network. Static WEP encryption protocols are used for network communications.
- **WPA-PSK.** Authentication is based on Wi-Fi Protected Access (WPA) standards through a Pre-Shared Key (PSK). When selecting WPA-PSK authentication, a user-specified pass-phrase must be entered to generate the pre-shared key. With WPA-PSK authentication, dynamic WPA encryption protocols are used for network communications to provide enhanced security.

Supplied Manuals

The manuals listed below are supplied with your print server or with printers that have factory-installed print servers.

- *Start* or *Use* guides, or equivalent printer documentation (shipped with printers that have factory-installed HP Jetdirect print servers).
- This manual, the *HP Jetdirect Print Server Administrator's Guide* for the applicable Jetdirect product models.
- HP Jetdirect *Setup* guides, supplied on CD-ROM with off-the-shelf print servers).

HP Support

HP Online Support

Click your way to a quick solution! The HP Web site:

http://www.hp.com/support/net_printing

is a great place to start for answers to questions about your HP Jetdirect print server — 24 hours a day, 7 days a week.

Firmware Upgrades

Hewlett-Packard offers downloadable firmware upgrades for HP Jetdirect print servers that contain upgradeable memory. The upgrades are available from the World Wide Web at:

http://www.hp.com/go/webjetadmin_firmware

Firmware Installation Tools

Note

HP Jetdirect ew2400 print servers will have limited upgrade capabilities. A network cable must be used. A firmware upgrade through a wireless connection is not supported.

Firmware upgrades for supported HP Jetdirect print servers may be installed over a network using one of the following firmware installation tools:

- HP Jetdirect Download Manager (Windows). HP Jetdirect Download Manager can be downloaded from HP online support at:

http://www.hp.com/go/dlm_sw

- HP Web Jetadmin may be used on supported systems. For more information on HP Web Jetadmin, visit:

<http://www.hp.com/go/webjetadmin/>

- The embedded Web server resident on the print server provides a firmware upgrade feature using your Web browser. For more information see [Chapter 4](#).
- FTP (File Transfer Protocol) may be used to transfer a firmware upgrade image file to the print server. To start an FTP session, use the device IP address or host name. If a password is set, it must be entered to log into the device. After user login, typical FTP commands to upgrade the device are illustrated below:

```
ftp> bin
ftp> hash
ftp> cd /download
ftp> put <firmware image filename; specify full pathname>
ftp>##### <Wait for FTP to complete the download>
ftp> bye
```

HP Support By Phone

Highly trained technicians are ready to take your call. For the most recent HP support telephone numbers and available services worldwide, visit:

http://www.hp.com/support/support_assistance

Note	For toll-free support in the USA and Canada, call 1-800-HPINVENT or 1-800-474-6836.
-------------	---

Note	Telephone fees are the responsibility of the caller. Rates may vary. Contact your local telephone company for current rates.
-------------	--

Product Registration

To register your HP Jetdirect print server, use the following HP Web page:

http://www.hp.com/go/jetdirect_register

Product Accessibility

Product Accessibility

For information on HP's commitment to accessibility of HP Jetdirect print server products:

- Visit the HP Web site at: <http://www.hp.com/accessibility>
- Send email to: accessibility@hp.com

HP Software Solutions Summary

Introduction

HP provides a variety of software solutions to set up or manage your HP Jetdirect-connected network devices. See [Table 2.1](#) to help you determine which software is best for you.

Note For more information on these and other solutions, visit HP online support at:

http://www.hp.com/support/net_printing

Table 2.1 Software Solutions (1 of 3)

Operating Environment	Function	Remarks
HP Install Network Printer Wizard (Windows)		
Windows 98, Me, NT 4.0, 2000, XP*, Server 2003 For direct mode IP and IPX printing. *32-bit mode only. IPX/SPX not supported on Windows XP 64-bit edition.	<p>Wireless print servers: With version 4.0, allows you to configure wireless parameters for an 802.11g wireless connection to your network.</p> <p>Wired or Wireless print servers: Once connected to your network, allows you to install (or add) a single network printer on your system for direct-mode (peer-to-peer) printing. For a network server, you can share the printer for client-server (shared) printing.</p>	<ul style="list-style-type: none"> ● Simple printer setup and installation. ● Runs from CD-ROM ● Installable version that runs from your hard disk is available for download from HP's Website.

Table 2.1 Software Solutions (2 of 3)

Operating Environment	Function	Remarks
HP Jetdirect Printer Installer for UNIX		
HP-UX 10.x-10.20, 11.x Solaris 2.6, 7, 8 (SPARCsystems only) TCP/IP	Fast and easy installation of HP Jetdirect-connected printers.	<ul style="list-style-type: none"> ● Supplied on the HP Jetdirect CD-ROM, and may be downloaded from HP's Website ● Not supported on value-based products, such as ew2400
HP Web Jetadmin		
(See the HP Website for supported system updates.) Windows 2000, XP Professional, Server 2003 HP-UX* Solaris* Linux* NetWare* TCP/IP, IPX/SPX *Supports queue creation and peripheral management from HP Web Jetadmin hosted on a supported system.	Remote installation, configuration, and management of HP Jetdirect-connected print servers, non-HP printers that support the standard MIBs, and printers with embedded Web servers. Alerts and consumables management. Remote firmware upgrades for HP Jetdirect print servers. Asset tracking and utilization analysis.	<ul style="list-style-type: none"> ● HP's preferred solution for ongoing management and installation of multiple printers anywhere on your intranet ● Browser-based management
Internet Printer Connection Software		
Windows NT 4.0, 2000 (Intel) TCP/IP only Note: Microsoft Internet Printing software is also integrated with Windows 2000, XP, Server 2003.	Printing through the Internet to Internet Printing Protocol (IPP)-enabled HP Jetdirect-connected printers.	<ul style="list-style-type: none"> ● Allows economical distribution of high-quality hardcopy documents over the Internet, replacing fax, mail, and overnight services ● Requires HP Jetdirect print server (firmware version x.20.00 or later) ● IPP is not supported on value-based products, such as ew2400

Table 2.1 Software Solutions (3 of 3)

Operating Environment	Function	Remarks
<u>HP IP/IPX Printer Gateway for NDPS</u>		
NetWare 5.x, 6.x	<p>Simplified installation, printing, and bidirectional management of HP Jetdirect-connected printers under Novell Distributed Print Services (NDPS).</p> <p>Allows automatic discovery and installation of HP Jetdirect-connected printers into NDPS.</p>	<ul style="list-style-type: none">● Frees up user licenses● Allows disabling of SAPs to reduce network traffic● Not supported on value-based products, such as ew2400
<u>HP WPS Assistant (Mac OS X)</u>		
Mac OS X 10.1.5 or later	Configuration of HP Jetdirect wireless print servers.	<ul style="list-style-type: none">● Distributed on the HP Jetdirect CD-ROM
<u>HP LaserJet Utilities for Mac OS</u>		
Mac OS 9.x, X 10.x(Classic Mode)	Configuration and management of HP Jetdirect-connected printers.	<ul style="list-style-type: none">● May be downloaded from HP's Website.

HP Install Network Printer Wizard (Windows)

The HP Install Network Printer Wizard, version 4.0 or above, is a utility for printer setup and installation on a TCP/IP or IPX/SPX network.

For wireless print servers, the wizard includes modules that allow you to first configure wireless settings on the print server so that it can connect to your network.

Once your printers have a network connection (either through a cabled/wired connection or a wireless connection), the wizard installs the printer on your systems or servers that will send print jobs directly to the printer. This is called “direct-mode”, or “peer-to-peer” printing.

If your system is a server, you can share the printer so that network clients can use the printer through the server, also known as “client-server” printing.

The HP Install Network Printer Wizard is included on the HP Jetdirect CD-ROM supplied with standalone HP Jetdirect products. The wizard is run through the **Install** selection on the Jetdirect CD-ROM interface. The wizard runs from the CD-ROM, although some files may be temporarily stored and then removed from your system disk after a system reboot.

A version that runs from your system disk is also available and can be downloaded from HP online support at:

http://www.hp.com/go/inpw_sw

Requirements

- Microsoft Windows XP, Windows 2000, Windows NT 4.0, Windows 98/Me, Server 2003
 - ◆ TCP/IP or IPX/SPX network protocol

Note

For HP Jetdirect ew2400 external wired/wireless print servers that will be used in a wireless environment, a network cable connection to configure wireless settings is recommended.

To configure wireless settings without a cable, you will need a computer that contains a wireless interface card, either built-in or installed in an I/O slot.

For detailed instructions, see the Setup guide provided with your print server.

- The proper printer software (printer driver) to use with your printer and operating system
- Printer connection to the network through an HP Jetdirect print server

HP Jetdirect Printer Installer for UNIX

The HP Jetdirect Printer Installer for UNIX contains support for HP-UX and Solaris systems. The software installs, configures and provides diagnostics capabilities for HP printers connected to TCP/IP networks using full-featured HP Jetdirect print servers. Value-based print servers, such as HP Jetdirect ew2400 print servers, are not supported.

The software is distributed through the following methods:

- HP Jetdirect CD-ROM, provided with standalone HP Jetdirect print servers
- Anonymous FTP site at <ftp.hp.com> (Directory: /pub/networking/software)
- HP online support at:

http://www.hp.com/support/net_printing

For system requirements and installation information, see the documentation provided with the software.

HP Web Jetadmin

HP Web Jetadmin is an enterprise management tool that allows you to remotely install, configure and manage a wide variety of HP and non-HP network printing devices simply through a standard Web browser. HP Web Jetadmin can be used to proactively manage both individual or groups of devices.

While HP Web Jetadmin supports devices that contain Standard Printer MIB (Management Information Base) objects for common management, it is well-integrated with HP Jetdirect print servers and HP printers to provide enhanced management features.

To use HP Web Jetadmin, see the online help and documentation supplied with the software.

System Requirements

HP Web Jetadmin software runs on Microsoft Windows Windows 2000, Windows XP Professional, and Windows Server 2003 systems. For information on supported operating systems, clients, and compatible browser versions, visit HP online support at <http://www.hp.com/go/webjetadmin>.

Note

When installed on a supported host server, HP Web Jetadmin can be accessed from any client through a compatible Web browser by browsing to the HP Web Jetadmin host. This allows printer installation and management on Novell NetWare and other networks.

Installing HP Web Jetadmin

Before installing the HP Web Jetadmin software, you must have administrator or root privileges on the local system:

1. Download the installation files from HP online support at <http://www.hp.com/go/webjetadmin>.
2. Follow the instructions on the screen to install the HP Web Jetadmin software.

Note Installation instructions are also contained in the HP Web Jetadmin install file.

Verifying Installation and Providing Access

- Verify that the HP Web Jetadmin software is correctly installed by navigating to it with your browser as shown in the following example:

```
http://systemname.domain:port/
```

where `systemname.domain` is the host name of your Web server and `port` is the port number assigned during installation. By default, the port number is 8000.

- Provide users access to HP Web Jetadmin software by adding a link to your Web server's home page that is addressed to HP Web Jetadmin's URL. For example:

```
http://systemname.domain:port/
```

Configuring and Modifying a Device

Using your browser, navigate to HP Web Jetadmin's URL.
For example:

```
http://systemname.domain:port/
```

Note

In place of `systemname.domain`, the IP address of the host computer on which HP Web Jetadmin is installed can be used.

Follow the instructions on the appropriate home page to find and manage your printer.

Removing HP Web Jetadmin Software

To remove HP Web Jetadmin software from your Web server, use the uninstall program provided with the software package.

Internet Printer Connection Software

Full-featured HP Jetdirect print servers (such as 620n or en3700) support the Internet Printing Protocol (IPP). Value-based print servers (such as ew2400) are not supported.

Using the appropriate software on your system, you can create an IPP print path from your system to a supported HP Jetdirect-connected printer over the Internet.

Note For incoming print path requests, the network administrator must configure the firewall to accept incoming IPP requests. Security features available in the software are currently limited.

Features and benefits provided by Internet printing include:

- High-quality, time-sensitive documents can be printed remotely, in full-color or black-and-white
- Documents can be printed remotely at a fraction of the cost of current methods (such as fax, mail, or overnight delivery services)
- The traditional LAN printing model can be extended to that of an Internet Printing Model
- IPP requests for sending print jobs can be transmitted outbound through firewalls

HP-Supplied Software

HP Internet Printer Connection software allows you to set up Internet printing from Windows NT 4.0 and Windows 2000 clients.

1. To obtain the software:

Download the HP Internet Printer Connection software from HP online support at:

http://www.hp.com/go/ipc_sw

2. To install the software and set up the print path to the printer, follow the instructions provided with the software. Contact your network administrator to get the IP address or URL of the printer to complete the setup.

HP Software System Requirements

- Computer running Microsoft Windows NT 4.0 (Intel-based) or Windows 2000
- IPP-enabled HP Jetdirect print server (such as HP Jetdirect 620n or en3700)

HP Software Supported Proxies

Web proxy with support for HTTP v1.1 or greater (may not be needed if printing over an intranet).

Microsoft Supplied Software

Note	Contact Microsoft for support of Windows IPP software.
-------------	--

Windows 2000/XP/Server 2003 Integrated Software

On Windows 2000/XP/Server 2003 systems, an alternative to using the HP supplied software is to use the IPP-client software integrated with the Windows system. The IPP implementation on the HP Jetdirect print server is compatible with the Windows system IPP-client software.

To set up a print path to an HP Jetdirect-connected Internet printer using the Windows 2000/XP IPP-client software, proceed as follows:

1. Open the **Printers** folder (click **Start**, select **Settings**, and select **Printers**).
2. Run the Add Printer wizard (double-click **Add Printer**), then click **Next**.
3. Select the option for a network printer and click **Next**.

4. Select **Connect to a printer on the Internet** and enter the print server's URL:

`http://IP_address[/ipp/port#]`

where *IP_address* is the IP address configured on the HP Jetdirect print server. *[/ipp/port#]* identifies the port number, which is port 1 for single-port 620n and en3700 print servers (default is */ipp/port1*).

Example:	
<code>http://192.160.45.40</code>	An IPP connection to HP Jetdirect 620n/en3700 print server with IP address 192.160.45.40. (" <i>/ipp/port1</i> " is assumed and not required.)

Then click **Next**.

5. You will be prompted for a printer driver (the HP Jetdirect print server does not contain printer drivers, so your system cannot automatically obtain the driver). Click **OK** to install the printer driver onto your system and follow the instructions on the screen. (You may need your printer CD-ROM to install the driver.)
6. To complete the print path setup, follow the instructions on the screen.

Windows Me IPP Client

The IPP implementation on the HP Jetdirect print server is compatible with Windows Me IPP-client software. The IPP client is installed from the **Add-Ons** folder on the Windows Me CD-ROM. For installation and setup of a Windows Me IPP client, see the instructions provided with the Windows Me CD-ROM.

Novell Supplied Software

The HP Jetdirect print server is compatible with IPP running on NetWare 5.1 with SP1 or later. For NetWare client support, refer to your NetWare technical documentation or contact Novell.

HP IP/IPX Printer Gateway for NDPS

NDPS (Novell Distributed Print Services) is a printing architecture developed by Novell in partnership with Hewlett-Packard. NDPS simplifies and streamlines the administration of network printing. It eliminates the need to set up and link print queues, printer objects, and print servers. Administrators can use NDPS to manage networked printers within supported NetWare environments.

The HP IP/IPX Printer Gateway is a NetWare Loadable Module (NLM) developed by HP to provide functionality and compatibility with Novell's NDPS for full-featured HP Jetdirect print servers. Value-based print servers, such as ew2400, are not supported.

The HP Gateway seamlessly integrates HP Jetdirect-attached printers into the NDPS environment. Using the HP Gateway, an administrator can view statistics, configure gateway settings, and configure printing for HP Jetdirect-connected printers.

Features

Features and benefits provided by the HP Gateway and NDPS include:

- Smart detection of printers in NetWare 5.x, 6.x environments
- Automatic installation of printers using IP/IPX
- Tight integration with Novell's NDS and NWAdmin
- Status updates from printers
- Simplified Automatic Driver Download
- Reduced SAP Traffic
- Reduced number of required NetWare User Licenses
- Native TCP/IP printing with NetWare 5.x, 6.x

To Get the Software

The HP IP/IPX Printer Gateway is included with all current versions of NDPS. Novell NetWare 5.x and 6.x includes NDPS. To obtain the most recent software version, or to obtain the related documentation:

- Visit http://www.hp.com/go/hpgate_sw
- Select and follow the instructions for downloading drivers and software.

System requirements and Novell Client support are included in the documentation supplied with the software.

HP WPS Assistant (Mac OS X)

This utility allows you to configure an HP Jetdirect wireless print server (WPS) with a connection to your Mac OS network.

To use this utility, the HP Jetdirect wireless print server must be in a factory-default state with its wireless port enabled. Proceed as follows:

1. Insert the CD-ROM into your Mac OS system (version X 10.1.5 or later).
2. Select and open the **HPJETDIRECT** CD-ROM icon.
3. If provided, read the release notes for updated information.
4. Select and open the **HP WPS Assistant** folder.
5. Run the HP WPS Assistant utility, then follow the instructions on the screen.

Note

Optionally, for Mac OS 9.x or X systems, you may use the embedded Web server to configure a network connection.

Once a wireless connection has been created, you will need to use other utilities (such as the HP LaserJet Utility for Mac OS) to configure and manage your printer for printing.

HP LaserJet Utilities for Mac OS

Note

The HP LaserJet Utilities for Mac OS allow you to configure and manage your HP Jetdirect-connected printers on networks that use the AppleTalk (EtherTalk) protocol.

On TCP/IP networks, you can use Mac OS system utilities to discover and install your printer:

- On Mac OS 9.x systems, use the Apple Desktop Printer Utility to set up LPR/LPD printing.
- On Mac OS X 10.x systems, use the Print Center to select IP Printing or Rendezvous to install your printer.

TCP/IP printer configuration is also supported through other tools, such as the embedded Web server.

Installing the Printer Software

To install the printer software for Mac OS systems, follow the instructions in the documentation supplied with your printer. If you are installing the HP LaserJet Utility from the HP Jetdirect CD-ROM, use the following installation instructions.

Note

If you are installing the HP LaserJet Utility from a source other than the CD-ROM, see the README file that accompanies the software for installation instructions.

Note

Automatic virus detection programs might interfere with the installation of this software. Turn off any such programs that are active on your Mac OS computer before proceeding with the installation process.

1. Insert the CD-ROM into the CD-ROM drive.
2. In the **HP Installer** window, double-click the installation icon for the software in the language you want.
3. Follow the instructions on the screen.

For more information about configuring your printer driver, see the online documentation provided on the CD-ROM that came with the printer.

Configuring the Printer

The HP LaserJet Utility allows printer settings such as printer name and preferred zone to be configured from your Mac OS system. Hewlett-Packard recommends that only network administrators use the printer configuration capabilities of this utility.

If this printer is to be serviced by a print spooler, set up the printer's name and zone before configuring the spooler to capture the printer.

Running the HP LaserJet Utility

1. With the printer turned on and online, and the print server connected to the printer and to the network, double-click the **HP LaserJet Utility** icon.
2. If the printer's name is not listed as the target printer, click **Select Printer**. The **Select a Target Printer** window appears.
 - Select the zone, if necessary, from the AppleTalk Zones list in which the printer resides. The zone the printer is in is shown on the configuration page. See the hardware installation guide for your print server or your printer's Getting Started guide for instructions on printing a configuration page.
 - Select the printer from the **Available Printers** list and click **OK**.

Verifying Network Configuration

To verify your current network configuration, print a Jetdirect configuration page. If you have not printed a configuration page from your printer, see your printer documentation for instructions (see [Chapter 9](#) for more information). If your printer has a control panel, make sure a READY message appears on the control panel for at least 1 minute, then print the page. The current configuration is listed under “AppleTalk” on the configuration page.

Note

If you have multiple printers on your network, you need to print a configuration page to identify the printer’s name and zone.

Renaming the Printer

The factory supplies a default name for your printer.

Hewlett-Packard highly recommends that you rename your printer to avoid having multiple printers with similar names on your network.

CAUTION

After you have renamed the printer and have set up print queues to that printer, use caution when changing the printer name again. If you rename the printer again, the queues for that printer will no longer function.

Note

The name may be up to 32 characters in length. A warning beep indicates that an illegal character was typed. For illegal characters, see the Help system integrated with the software.

You can name your printer anything you like—for example, “Michael’s LaserJet 4000.” The HP LaserJet Utility has the ability to rename devices located in different zones, as well as the local zone (no zones need to be present in order to use the HP LaserJet Utility).

1. Select the **Settings** icon from the scrolling icon list. The **Please select a setting:** dialog appears.
2. Select **Printer Name** in the list.
3. Click **Edit**. The **Set Printer Name** dialog box appears.
4. Type the new name.
5. Click **OK**.

Note

If you try to name your printer the same name as another printer, an alert dialog box appears directing you to select another name. To select another name, repeat steps 4 and 5.

6. If your printer is on an EtherTalk network, continue with the next section, "[Selecting a Zone](#)."
7. To exit, select **Quit** from the **File** menu.

Notify everyone on your network of the new name for your printer so they can select the printer in the Chooser.

Selecting a Zone

The HP LaserJet Utility allows you to select a preferred zone for your printer on a Phase 2 EtherTalk network. Instead of your printer remaining on the default zone, which is set by the router, this utility lets you select the zone on which your printer appears. The zones on which your printer can reside are limited by your network configuration. **The HP LaserJet Utility only enables you to select a zone that is already configured for your network.**

Zones are groups of computers, printers, and other AppleTalk devices. They can be grouped by physical location (for example, Zone A may contain all the printers on the network in building A). They may also be grouped logically (for example, all printers used in the finance department).

1. Select the **Settings** icon from the scrolling icon list. The **Please Select a Setting:** dialog box appears.
2. Select **Printer Zone** in the list and click **Edit**. The **Select a Zone** dialog box appears.

3. Select your preferred network zone from the **Select a Zone:** list and click **Set Zone**.
4. To exit, select **Quit** from the **File** menu.

Notify everyone on your network of the new zone for your printer so they can select the printer in the Chooser.

Selecting Your Printer

1. Select the **Chooser** from the **Apple** menu.
2. Select the printer icon for use with your printer. If the appropriate printer icon does not appear in the Chooser, or you are not sure which icon to select for your printer, see “[Installing the Printer Software](#)” in this chapter.

3. If AppleTalk is not active, an alert dialog box appears on your screen. Select **OK**. The **Active** button turns on.

If your network is linked to other networks, the **AppleTalk Zones** list dialog box appears in the Chooser.

4. If applicable, select the zone in the **AppleTalk Zones** scrolling list where your printer is located.
5. Select the printer name you want to use from the list of printer names in the upper-right area of the Chooser. If the printer's name does not appear in the list, make sure the following tasks have been performed:
 - the printer is turned on and is online.
 - the print server is connected to the printer and to the network.
 - the printer cable connections are secure.

A **READY** message should appear if the printer has a control panel display. See [Chapter 8](#) for more information.

Note

If your printer is the only name listed in the dialog box, you must still select it. Your printer remains selected until you select a different printer with the Chooser.

6. Click **Setup** or **Create** in the Chooser; then, if prompted, select the appropriate PostScript Printer Description file (PPD) for the printer. For more information, see the online documentation.

7. Set **Background Printing** to **ON** or **OFF**.

If background printing is turned **OFF** when you send a print job to the printer, status messages appear on your screen and you have to wait until the messages clear before continuing your work. If background printing is turned **ON**, the messages are redirected to the PrintMonitor and you can continue working while the printer is printing your job.

8. Exit the Chooser.

To display your user name on the network when you are printing documents, go into the Control Panel on your Mac OS computer, select **Sharing Setup**, then type your owner name.

Testing the Configuration

1. Select **Print Window** from the *File* menu, or if no window is open, select **Print Desktop**.

The *Print* dialog box appears.

2. Click **Print**.

If the printer prints the job, you have connected your printer to your network correctly. If your printer does not print, see [Chapter 8](#).

TCP/IP Configuration

Introduction

To operate properly on a TCP/IP network, the HP Jetdirect print server must be configured with valid TCP/IP network configuration parameters, such as an IP address that is valid for your network. For general information on TCP/IP networks, see [Appendix A](#).

Server-Based and Manual TCP/IP Configuration

When in a factory-default state and powered on, the HP Jetdirect print server will try to obtain its TCP/IP configuration using a server-based method, such as BOOTP/TFTP, DHCP/TFTP, or RARP. These server-based methods are described later in this chapter. Depending on the print server model, up to two minutes may be used for these methods. If configuration is not successful, a default IP address will be assigned.

The print server may also be configured manually. Manual-based tools include Telnet, a Web browser, the printer control panel, arp and ping commands (when the default IP address is 192.0.0.192), or SNMP-based management software. TCP/IP configuration values assigned manually will be retained when powered off/on.

The print server can be reconfigured to use either server-based or manual configuration of TCP/IP settings at any time.

To identify the IP address that is configured on the print server at any time, see the HP Jetdirect configuration page.

Default IP Address

When in a factory-default state (for example, when shipped from the factory or after a cold-reset), the HP Jetdirect print server has no IP address. A default IP address may or may not be assigned depending on the network environment.

Default IP Address Will Not Be Assigned

A default IP address will not be assigned if a server-based method (such as BOOTP or DHCP) is successful. And if the print server is powered off/on, the same method will again be used to retrieve IP configuration settings. If this method now fails to retrieve the IP configuration settings (for example, the BOOTP or DHCP server is no longer available), a default IP address will not be assigned. Instead, the print server will continue to send IP configuration requests indefinitely. You must cold-reset the print server to change this behavior.

In addition, a default IP address will not be assigned if a network cable is not attached to a wired print server.

Default IP Address Will Be Assigned

A default IP address will be assigned if the factory-default methods fail, or if the print server has just been reconfigured by an administrator to use a server-based method (such as BOOTP or DHCP) that fails.

If a default IP address is assigned, the address will depend on the network to which the print server is connected. The print server senses broadcast packets on the network to determine the appropriate default IP settings:

- On small private networks that adhere to automated, standards-based IP address assignments, the print server uses a link-local addressing technique to assign a unique IP address. Link-local addressing is limited to a local IP subnet (not routed) and may be referenced as *Auto IP*. The IP address assigned will be in the range of 169.254.1.0 to 169.254.254.255 (commonly referenced as 169.254/16). However, it can be further modified for your network using supported TCP/IP configuration tools if necessary.

With link-local addresses, subnetting is not used. The subnet mask will be 255.255.0.0, and cannot be changed.

Link-local addresses will not route off the local link, and access to or from the Internet will not be available. The default gateway address will be the same as the link-local address.

If a duplicate address is sensed, the HP Jetdirect print server will automatically reassign its address, if necessary, in accordance with standard link-local addressing methods.

- On large or enterprise IP networks, a temporary address of 192.0.0.192 will be assigned until it is reconfigured with a valid address through supported TCP/IP configuration tools. We refer to this address as *Legacy Default IP*.
- On mixed-environment networks, the self-assigned default IP address may be either 169.254/16 or 192.0.0.192. In this case, you should verify on the Jetdirect configuration page that the assigned default IP address is as expected.

The IP address configured on your print server may be determined by inspecting the Jetdirect configuration page for the print server. See [Chapter 9](#).

Default IP Address Configuration Options

Default IP Parameter

A Default IP configuration parameter on the print server controls how the default IP address is assigned. Whenever the print server is unable to obtain an IP address during a forced TCP/IP reconfiguration (for example, when manually configured to use BOOTP or DHCP), this parameter will determine the default IP address to use.

When the print server is in a factory-default state, this parameter is undefined.

If the print server is initially configured with a default IP address (either a link-local IP address or the legacy default 192.0.0.192 IP address), the Default IP parameter will be set to either **Auto IP** or **Legacy Default IP** to match.

The Default IP parameter can be changed through a supported configuration tool, such as Telnet, a Web browser, a printer control panel, and SNMP management applications.

DHCP Requests Enable/Disable

When a default IP address is assigned, you can configure the print server to send, or not send, periodic DHCP requests. DHCP requests are used to retrieve IP configuration settings from a DHCP server on the network. By default, this parameter is enabled, allowing DHCP requests to be transmitted. However, this parameter may be disabled through supported configuration tools such as Telnet, a Web browser, and SNMP management applications.

HP Jetdirect Wireless Print Server. When initially powered on, a factory-default wired/wireless print server that has no connection to a network will likely self-assign a link-local IP address. If a network connection to a DHCP server-based network is made, the IP address will likely be reconfigured because DHCP requests on the print server are enabled by default.

Default IP on Wireless and Wired Print Servers

Wired and wireless print servers may have different default IP configuration results:

- When powered on, a factory-default print server connected to a network through a cable (wired) will systematically use BOOTP, DHCP, and RARP to retrieve its IP settings. Up to two minutes are used. If configuration is not successful, a default IP address will be assigned as described previously.
- For a factory-default wired/wireless print server that is not connected through a cable, only a wireless Ad Hoc connection is initially available. In this case, retrieval of IP settings from a network is limited to about four seconds. During this time, a single BOOTP request is transmitted, and broadcast packets are sensed. Because a response from a BOOTP server on an Ad Hoc network is unlikely, and the number of broadcast packets sensed will be minimal, a default IP configuration using link-local addressing is likely.

However, the IP configuration may change once the wireless print server is connected a DHCP network because the sending of DHCP requests will be enabled by default.

Configuration tools that require a specific default IP address on the print server for initial communication may not work without modification. For the default IP address settings actually configured on the print server, see the Jetdirect configuration page.

TCP/IP Configuration Tools

When a network connection has been established, an HP Jetdirect print server can be configured with valid TCP/IP parameters for your network in the following ways:

- **Using Software.** You can use installation, setup, and management software running on supported systems. For more information see [Chapter 2](#), “[HP Software Solutions Summary](#)”.
- **BOOTP/TFTP.** You can download the data from a network-based server using BOOTP (Bootstrap Protocol) and TFTP (Trivial File Transfer Protocol) each time the printer is turned on. For more information, see “[Using BOOTP/TFTP](#)”.

The BOOTP daemon, `bootpd`, must be running on a BOOTP server that is accessible by the printer.

- **DHCP/TFTP.** You can use Dynamic Host Configuration Protocol (DHCP) and TFTP (Trivial File Transfer Protocol) each time the printer is turned on. These protocols are supported on HP-UX, Solaris, Red Hat Linux, SuSE Linux, Windows NT/2000/Server 2003, NetWare and Mac OS systems. (Refer to your network operating system manuals to verify that your server operating system supports DHCP.) For more information, see “[Using DHCP](#)”.

Note

Linux and UNIX systems: For more information, see the `bootpd` “man” page.

On HP-UX systems, a sample DHCP configuration file (`dhcptab`) may be located in the `/etc` directory.

Since HP-UX presently does not provide Dynamic Domain Name Services (DDNS) for its DHCP implementations, HP recommends that you set all print server lease durations to *infinite*. This ensures that print server IP addresses remain static until such time as Dynamic Domain Name Services are provided.

-
- **RARP.** A network-based server can use RARP (Reverse Address Resolution Protocol) to answer the print server's RARP request and supplying the print server with the IP address. The RARP method only allows you to configure the IP address. For more information, see “[Using RARP](#)”.

- **arp and ping commands.** (For print servers configured with Legacy default IP address 192.0.0.192 only) You can use the `arp` and `ping` commands from your system. For more information, see [“Using the arp and ping Commands”](#).
- **Telnet.** You can set configuration parameters using Telnet. In order to set configuration parameters, set up a Telnet connection from your system to the HP Jetdirect print server using the default IP address. Once configured, the print server saves the configuration when powered off/on. For more information, see [“Using Telnet”](#).
- **Embedded Web server.** You can browse to the embedded Web server on the HP Jetdirect print server to set configuration parameters. For more information, see [Chapter 4](#).
- **Printer Control Panel.** (HP Jetdirect 620n print servers only) You can manually enter the configuration data using the printer control panel keys. The control panel method allows you to configure only a limited subset of configuration parameters. Therefore, control panel configuration is recommended only during troubleshooting or for simple installations. If control panel configuration is used, the print server saves the configuration when powered off/on. For more information, see [“Using the Printer Control Panel”](#).

Using BOOTP/TFTP

Note

For HP Jetdirect *wireless* print servers, this section assumes that a wireless connection to your network has been established.

BOOTP (Bootstrap Protocol) and TFTP (Trivial File Transfer Protocol) provide a convenient way to automatically configure the HP Jetdirect print server for TCP/IP network operation. When powered on, the Jetdirect print server sends a BOOTP request message onto the network. A properly configured BOOTP server on the network will respond with a message that contains basic network configuration data for the Jetdirect print server. The BOOTP server's response may also identify a file that contains extended configuration data for the print server. The Jetdirect print server downloads this file using TFTP. This TFTP configuration file may be located on the BOOTP server, or a separate TFTP server.

BOOTP/TFTP servers are typically UNIX or Linux systems. Windows NT/2000/Server 2003 and NetWare servers can respond to BOOTP requests. Windows NT/2000/Server 2003 servers are configured through Microsoft DHCP services (see [Using DHCP](#)). However, Windows NT/2000/Server 2003 systems may require third-party software for TFTP support. For setup of NetWare BOOTP servers, refer to your NetWare documentation.

Note

If the Jetdirect print server and BOOTP/DHCP server are located on different subnets, IP configuration may fail unless the routing device supports "BOOTP Relay" (allows the transfer of BOOTP requests between subnets).

Why Use BOOTP/TFTP?

Using BOOTP/TFTP to download configuration data has the following benefits:

- Enhanced configuration control of the HP Jetdirect print server. Configuration by other methods, such as a printer control panel, are limited to select parameters.
- Ease of configuration management. Network configuration parameters for the entire network can be in one location.
- Ease of HP Jetdirect print server configuration. Complete network configuration can be automatically downloaded each time the print server is powered on.

Note

BOOTP operation is similar to DHCP, but the resulting IP parameters will be the same when powered off/on. In DHCP, IP configuration parameters are leased and may change over time.

When in its factory-default state and powered on, the HP Jetdirect print server will attempt to automatically configure itself using several dynamic methods, one of which is BOOTP.

BOOTP/TFTP on UNIX

This section describes how to configure the print server using BOOTP (Bootstrap Protocol) and TFTP (Trivial File Transfer Protocol) services on UNIX servers. BOOTP and TFTP are used to download network configuration data from a server to the HP Jetdirect print server over the network.

Systems That Use Network Information Service (NIS)

If your system uses NIS, you may need to rebuild the NIS map with the BOOTP service before performing the BOOTP configuration steps. Refer to your system documentation.

Configuring the BOOTP Server

For the HP Jetdirect print server to obtain its configuration data over the network, the BOOTP/TFTP servers must be set up with the appropriate configuration files. BOOTP is used by the print server to obtain entries in the `/etc/bootptab` file on a BOOTP server, while TFTP is used to obtain additional configuration information from a configuration file on a TFTP server.

When the HP Jetdirect print server is powered on, it broadcasts a BOOTP request that contains its MAC (hardware) address. A BOOTP server daemon searches the `/etc/bootptab` file for a matching MAC address, and if successful, sends the corresponding configuration data to the Jetdirect print server as a BOOTP reply. The configuration data in the `/etc/bootptab` file must be properly entered. For a description of entries, see “[Bootptab File Entries](#)”.

The BOOTP reply may contain the name of a configuration file containing enhanced configuration parameters. If the HP Jetdirect print server finds such a file, it will use TFTP to download the file and configure itself with these parameters. For a description of entries, see “[TFTP Configuration File Entries](#)”. Configuration parameters retrieved through TFTP are optional.

Note

HP recommends that the BOOTP server be located on the same subnet as the printers it serves.

BOOTP broadcast packets may not be forwarded by routers unless the routers are properly configured.

Bootptab File Entries

An example of a `/etc/bootptab` file entry for an HP Jetdirect print server is provided below:

```
picasso:\
:hn:\
:ht=ether:\
:vm=rfc1048:\
:ha=0001E6123456:\
:ip=192.168.40.39:\
:sm=255.255.255.0:\
:gw=192.168.40.1:\
:lg=192.168.40.3:\
:T144="hnp/picasso.cfg":
```

Note that the configuration data contains “tags” to identify the various HP Jetdirect parameters and their settings. Entries and tags supported by the HP Jetdirect print server are listed in [Table 3.1](#).

Table 3.1 Tags Supported in a BOOTP/DHCP Boot file (1 of 4)

Item	RFC 2132 Option	Description
<i>nodename</i>	--	The name of the peripheral. This name identifies an entry point to a list of parameters for a specific peripheral. <i>nodename</i> must be the first field in an entry. (In the example above, <i>nodename</i> is “picasso”.)
ht	--	The hardware type tag. For the HP Jetdirect print server, set this to ether (for Ethernet). This tag must precede the ha tag.
vm	--	The BOOTP report format tag (required). Set this parameter to rfc1048 .
ha	--	The hardware address tag. The hardware (MAC) address is the link-level, or station address of the HP Jetdirect print server. It can be found on the HP Jetdirect configuration page as the HARDWARE ADDRESS . On HP Jetdirect external print servers, it is printed on a label attached to the print server.
ip	--	The IP address tag (required). This address will be the HP Jetdirect print server’s IP address.

Table 3.1 Tags Supported in a BOOTP/DHCP Boot file (2 of 4)

Item	RFC 2132 Option	Description
sm	1	The subnet mask tag. The subnet mask will be used by the HP Jetdirect print server to identify the portions of an IP address that specify the network/subnetwork number and the host address.
gw	3	The gateway IP address tag. This address identifies the IP address of the default gateway (router) that the HP Jetdirect print server will use for communications with other subnets.
ds	6	DNS (Domain Name System) server's IP address tag. Only a single name server can be specified.
lg	7	The syslog server's IP address tag. It specifies the server that the HP Jetdirect print server sends syslog messages to. For more information, see Appendix A .
hn	12	The host name tag. This tag does not take a value but causes the BOOTP daemon to download the host name to the HP Jetdirect print server. The host name will be printed on the Jetdirect configuration page, or returned on an SNMP sysName request by a network application.
dn	15	Domain name tag. Specifies the domain name for the HP Jetdirect print server (for example, support.hp.com). It does not include the host name; it is not the Fully Qualified Domain Name (such as printer1.support.hp.com).
ef	18	Extensions file tag that specifies the relative path name of the TFTP configuration file. Note: This tag is similar to the vendor-specific tag T144, described below.
na	44	Tag for IP addresses of the NetBIOS-over-TCP/IP Name Server (NBNS). A primary and secondary server may be specified in order of preference.
lease-time	51	DHCP IP address lease duration time (seconds).
tr	58	DHCP T1 timeout, specifying the DHCP lease renewal time (seconds).

Table 3.1 Tags Supported in a BOOTP/DHCP Boot file (3 of 4)

Item	RFC 2132 Option	Description
tv	59	DHCP T2 timeout, specifying the DHCP lease rebind time (seconds).
T69	69	The IP address (in hexadecimal) of the preferred outgoing e-mail SMTP (Simple Mail Transport Protocol) server, for use with supported Scan devices.
T144	--	<p>An HP-proprietary tag that specifies the relative path name of the TFTP configuration file. Long path names may be truncated. The path name must be in double quotes (for example, "<i>pathname</i>"). For file format information, refer to "TFTP Configuration File Entries".</p> <p>Note: Standard BOOTP option 18 (extensions file path) also allows a standard tag (ef) to specify the relative path name of the TFTP configuration file.</p>
T145	--	Idle Timeout option. An HP-proprietary tag to set the idle timeout (seconds), which is the amount of time that a print data connection may remain idle before being closed. The range is 1 - 3600 seconds.
T146	--	<p>Buffer Packing option. An HP-proprietary tag to set buffer packing for TCP/IP packets.</p> <p>0 (default): Normal data buffers are packed before sending to the printer.</p> <p>1: Disable buffer packing. Data is sent to the printer when received.</p>
T147	--	<p>Write Mode option. An HP-proprietary tag that controls the TCP PSH flag setting for device-to-client data transfers.</p> <p>0 (default): disables this option, flag not set.</p> <p>1: all-push option. The push bit is set in all data packets.</p>
T148	--	<p>IP Gateway Disable option. An HP-proprietary tag to prevent configuration of a Gateway IP address.</p> <p>0 (default): allows an IP address.</p> <p>1: prevents a Gateway IP address to be configured.</p>

Table 3.1 Tags Supported in a BOOTP/DHCP Boot file (4 of 4)

Item	RFC 2132 Option	Description
T149	--	Interlock Mode option. An HP-proprietary tag that specifies whether an acknowledgement (ACK) on all TCP packets is required before the printer is allowed to close a Port 9100 print connection. A Port Number and Option value are specified, in the form: <i><Port Number> <Option></i> <i><Port Number></i> : For supported HP Jetdirect print servers, the Port Number is 1 (default). <i><Option></i> : Option value 0 (default) disables interlock, 1 enables. Example: 1 1 specifies <i><Port 1></i> , <i><interlock enabled></i>
T150	--	TFTP server's IP address option. An HP-proprietary tag to specify the TFTP server's IP address where the TFTP configuration file is located.
T151	--	Network Configuration option. An HP-proprietary tag to specify either "BOOTP-ONLY" or "DHCP-ONLY" requests be sent.

A colon (:) indicates the end of a field, and a backslash (\) indicates that the entry is continued on the next line. Spaces are not allowed between the characters on a line. Names, such as host names, must begin with a letter and can contain only letters, numbers, periods (for domain names only), or hyphens. The underline character (_) is not allowed. Refer to your system documentation or online help for more information.

TFTP Configuration File Entries

To provide additional configuration parameters for your HP Jetdirect print server, such as SNMP (Simple Network Management Protocol) or non-default settings, an additional configuration file can be downloaded using TFTP. This TFTP configuration file's relative path name is specified in the BOOTP reply using the `/etc/bootptab` file's T144 vendor-specific tag (or the "ef" standard BOOTP tag) entry. An example of a TFTP configuration file is provided below (the symbol '#' denotes a remark and is not included in the file).

```
#
# Example of an HP Jetdirect TFTP Configuration File
#
# Allow only Subnet 192.168.10 access to peripheral.
# Up to 10 'allow' entries can be written through TFTP.
# Up to 10 'allow' entries can be written through Telnet
# or embedded Web server.
# 'allow' may include single IP addresses.
#
allow: 192.168.10.0    255.255.255.0
#
#
# Disable Telnet
#
telnet-config: 0
#
# Enable the embedded Web server
#
ews-config: 1
#
# Detect SNMP unauthorized usage
#
auth-trap: on
#
# Send Traps to 192.168.10.1
#
trap-dest: 192.168.10.1
#
# Specify the Set Community Name
#
set-cmnty-name: lhomer2
#
# End of file
```

[Table 3.2](#) lists supported TFTP commands (HP Jetdirect firmware version V.28.xx or later).

[Table 3.3](#) describes the TFTP parameters.

Table 3.2 List of Supported TFTP Commands (1 of 2)

General	
● passwd:	● ssl-state:
● sys-location:	● security-reset:
● sys-contact:	● tftp-parameter-attribute:
TCP/IP Main	
● host-name:	● sec-dns-svr:
● parm-file:	● pri-wins-svr:
● domain-name:	● sec-wins-svr:
● pri-dns-svr:	● smtp-svr:
TCP/IP Print Options	
● 9100-printing:	● interlock:
● ftp-printing:	● buffer-packing:
● ipp-printing:	● write-mode:
● lpd-printing:	● mult-tcp-conn:
● banner:	
TCP/IP Raw Print Ports	
● raw-port:	
TCP/IP Access Control	
● allow: netnum [mask]	
TCP/IP Other Settings	
● syslog-config:	● ipv4-multicast:
● syslog-svr:	● idle-timeout:
● syslog-max:	● user-timeout:
● syslog-priority:	● ews-config:
● syslog-facility:	● tcp-mss:
● slp-config:	● tcp-msl:
● slp-keep-alive:	● telnet-config:
● ttl-slp:	● default-ip:
● mdns-config:	● default-ip-dhcp:
● mdns-service-name:	● dhcp-arbitration:
● mdns-pri-svc:	● phone-home-config:
	● web-refresh:

Table 3.2 List of Supported TFTP Commands (2 of 2)

SNMP	
● snmp-config:	● auth-trap:
● get-cmnty-name:	● trap-dest:
● set-cmnty-name:	
IPX/SPX	
● ipx-config:	● ipx-nds-context:
● ipx-unit-name:	● ipx-job-poll:
● ipx-frametype:	● pjl-banner:
● ipx-sapinterval:	● pjl-eoj:
● ipx-nds-tree:	● pjl-toner-low:
AppleTalk	
● appletalk:	
● name-override:	
DLC/LLC	
● dlc/llc-config:	
Other Settings	
● link-type:	● MFP-config:
● upgrade:	● usb-mode:
● webscan-config:	● status-page-lang:
● scan-idle-timeout:	● network-select:
● scan-email-config:	
Support	
● support-name:	● support-url:
● support-number:	● tech-support-url:

Table 3.3 TFTP Configuration File Parameters (1 of 12)

General
<p>passwd: (passwd-admin:)</p> <p>A password (up to 16 alphanumeric characters) that allows administrators to control changes of HP Jetdirect print server configuration parameters through Telnet, HP Web Jetadmin, or embedded Web server. The password may be cleared by a cold reset.</p>
<p>sys-location: (host-location:, location:)</p> <p>Identifies the physical location of the printer (SNMP sysLocation object). Only printable ASCII characters are allowed. The maximum length is 64 characters. The default location is undefined. (Example: 1st floor, south wall)</p>
<p>sys-contact: (host-contact:, contact:)</p> <p>ASCII character string (up to 64 characters) that identifies the person who administers or services the printer (SNMP sysContact object). This may include how to contact this person. The default contact is undefined.</p>
<p>ssl-state:</p> <p>Sets the print server's security level for Web communications:</p> <p>1 (default): Forced redirection to the HTTPS port. Only HTTPS (secure HTTP) communications can be used.</p> <p>2: Disable forced redirection to HTTPS. Both HTTP and HTTPS communications can be used.</p>
<p>security-reset:</p> <p>Reset security settings on the print server to factory default values. 0 (default) does not reset, 1 resets the security settings.</p>
<p>tftp-parameter-attribute:</p> <p>Specifies whether TFTP parameters can be manually overwritten on the print server (for example, through Telnet) after it has been configured by TFTP.</p> <p>tftp-ro (default): Do not allow TFTP parameters to be manually changed, and always overwrite manual configurations.</p> <p>tftp-rw: Allow TFTP parameters to be manually changed, and always overwrite manual configurations.</p> <p>manual-ro: Do not allow TFTP parameters to overwrite manually configured parameters.</p>

Table 3.3 TFTP Configuration File Parameters (2 of 12)

TCP/IP Main	
host-name: (sys-name:, name:)	Specifies the node name that will appear on the Jetdirect configuration page. Default is NPIxxxxxx, where xxxxxx is the last six digits of the LAN hardware address.
parm-file:	Specifies the path and file name whose contents are sent to the printer for printing each time the print server is powered on. The path and filename entry is limited to 64 alphanumeric characters.
domain-name:	The domain name for the device (for example, support.hp.com). It does not include the host name; it is not the Fully Qualified Domain Name (such as printer1.support.hp.com).
pri-dns-svr: (dns-srv)	The IP address of the DNS (Domain Name System) server.
sec-dns-svr:	The IP address of a secondary DNS server to use if the primary DNS server is unavailable.
pri-wins-svr: (pri-wins-srv:)	The IP address of the primary Windows Internet Naming Service (WINS) server.
sec-wins-svr: (sec-wins-srv:)	The IP address of the secondary Windows Internet Naming Service (WINS) server.
smtp-svr:	The IP address of the outgoing e-mail Simple Mail Transport Protocol (SMTP) server, for use with supported Scan devices.
TCP/IP Print Options	
9100-printing: (9100-config:)	Enables or disables printing to TCP port 9100 on the print server. 0 disables, 1 (default) enables.
ftp-printing: (ftp-config:, ftp:)	Enables or disables the ability to print through FTP: 0 disables, 1 (default) enables.

Table 3.3 TFTP Configuration File Parameters (3 of 12)

ipp-printing: (ipp-config:, ipp:) Enables or disables the ability to print through IPP: 0 disables, 1 (default) enables.
lpd-printing: (lpd-config:, lpd:) Enables or disables LPD (Line Printer Daemon) printing services on the Jetdirect print server. 0 disables, 1 (default) enables.
banner: A port-specific parameter that specifies printing an LPD banner page. 0 disables banner pages. 1 (default) enables banner pages.
interlock: (interlock-mode:) Specifies whether an acknowledgement (ACK) on all TCP packets is required before the printer is allowed to close a Port 9100 print connection. A Port Number and Option value are specified. For current HP Jetdirect print servers, the Port Number is 1. Option value 0 (default) disables interlock, 1 enables. For example, "interlock 1 1" specifies Port 1, interlock enabled.
buffer-packing: (packing:) Enables or disables buffer packing for TCP/IP packets. 0 (default): is normal, the data buffer is packed before sending to the printer. 1: disables buffer packing, data is sent to the printer as it is received.
write-mode: Controls the setting of the TCP PSH flag for device-to-client data transfers. 0 (default): disables this option, flag is not set. 1: all-push option. The push bit is set in all data packets.
mult-tcp-conn: Enables or disables multiple TCP connections. 0 (default): allows multiple connections. 1: disables multiple connections.
TCP/IP Raw Print Ports
raw-port: (addr:port:) Specifies additional ports for printing to TCP port 9100. Valid ports are 3000 to 9000, which are application-dependent.

Table 3.3 TFTP Configuration File Parameters (4 of 12)

TCP/IP Access Control
<p>allow: netnum [mask]</p> <p>Makes an entry into the host access list stored on the HP Jetdirect print server. Each entry specifies a host or network of hosts that are allowed to connect to the printer. The format is “allow: netnum [mask]” where netnum is a network number or host IP address, and mask is an address mask of bits applied to the network number and host address to verify access. Up to 10 access list entries are allowed. If there are no entries, all hosts are permitted access. For example,</p> <p>allow: 192.0.0.0 255.0.0.0 allows hosts on network 192.</p> <p>allow: 192.168.1.2 allows a single host. In this case, the default mask 255.255.255.255 is assumed and is not required.</p> <p>allow: 0 This entry clears the host access list.</p> <p>For additional information, see Chapter 7.</p>
TCP/IP Other Settings
<p>syslog-config:</p> <p>Enables or disables syslog server operation on the print server: 0 disables, 1 (default) enables.</p>
<p>syslog-svr: (syslog-srv:)</p> <p>The syslog server’s IP address. It specifies the server that the HP Jetdirect print server sends syslog messages to. For more information, see Appendix A.</p>
<p>syslog-max:</p> <p>Specifies the maximum number of syslog messages that can be sent by the HP Jetdirect print server on a per-minute basis. This setting allows administrators to control the log file size. The default is 10 per minute. If it’s set to zero, the number of syslog messages is not restricted.</p>
<p>syslog-priority:</p> <p>Controls the filtering of syslog messages sent to the syslog server. The filter range is 0 to 8, with 0 being the most specific and 8 the most general. Only messages that are lower than the filter level specified (or higher in priority) are reported. The default is 8, messages of all priorities are sent. If 0, all syslog messages are disabled.</p>
<p>syslog-facility:</p> <p>A code used to identify the source facility of a message (for example, to identify the source of selected messages during troubleshooting). By default, the HP Jetdirect print server uses LPR as the source facility code, but local user values of local0 through local7 can be used to isolate individual or groups of print servers.</p>
<p>slp-config:</p> <p>Enables or disables the Service Location Protocol (SLP) operation on the print server: 0 disables, 1 (default) enables.</p>

Table 3.3 TFTP Configuration File Parameters (5 of 12)

slp-keep-alive: Specifies a time period for the print server to send multicast packets on the network to prevent being deleted from network device tables. Some infrastructure devices, such as switches, may delete active devices from their device tables due to inactivity on the network. To enable this feature, set a value from 1 to 1440 minutes. Set 0 to disable this feature.
ttl-slp: Specifies the IP multicast “Time To Live” (TTL) setting for Service Location Protocol (SLP) packets. The default value is 4 hops (the number of routers from the local network). The range is 1-15. When set to a -1, multicast capability is disabled.
mdns-config: Enables or disables Multicast Domain Name System (mDNS) services. 0 disables, 1 (default) enables. mDNS is typically used on small networks for IP address and name resolution (through UDP port 5353) where a conventional DNS server is neither used or available.
mdns-service-name: Specifies an alphanumeric string of up to 64 ASCII characters assigned to this device or service. This name is persistent and is used to resolve a particular device or service if socket information (such as the IP address) changes from session to session. Apple Rendezvous will display this service. The default service name is the printer model and the LAN Hardware (MAC) address.
mdns-pri-svc: Specifies the mDNS highest priority service to use for printing. To set this parameter, choose one of the following printing option numbers: 1: Port 9100 printing 2: IPP port printing 3: The default LPD raw queue 4: The default LPD text queue 5: The default LPD auto queue 6: The default LPD binps (binary postscript) queue 7 through 12: If user-specified LPD queues are defined, corresponds to user-specified LPD queues 5 through 10. The default selection will depend on the printer, typically port 9100 printing or LPD binps.
ipv4-multicast: Enables or disables the receipt and transmission of IP version 4 multicast packets by the print server. 0 disables, 1 (default) enables.

Table 3.3 TFTP Configuration File Parameters (6 of 12)

<p>idle-timeout:</p> <p>The number of seconds that an idle print data connection is allowed to remain open. Since the card supports only a single TCP connection, the idle timeout balances the opportunity of a host to recover or complete a print job against the ability of other hosts to access the printer. The acceptable values range from 0 to 3600 (1 hour). If "0" is typed, the timeout mechanism is disabled. The default is 270 seconds.</p>
<p>user-timeout: (telnet-timeout:)</p> <p>An integer (1..3600) that specifies the number of seconds that your Telnet or FTP session can be idle before it will be automatically disconnected. The default is 900 seconds. 0 disables the timeout.</p> <p>CAUTION: Small values, such as 1-5, may effectively disable the use of Telnet. A Telnet session may terminate before any changes can be made.</p>
<p>ews-config: (web:)</p> <p>Enables or disables the print server's embedded Web server to change configuration values: 0 disables, 1 (default) enables.</p>
<p>tcp-mss: (subnets-local:)</p> <p>Specifies the maximum segment size (MSS) that the HP Jetdirect print server will advertise for use when communicating with local subnets (Ethernet MSS=1460 bytes or more) or remote subnets (MSS=536 bytes):</p> <p>0 (default): All networks are assumed to be local (Ethernet MSS=1460 bytes or more).</p> <p>1: Use MSS=1460 bytes (or more) for subnets, and MSS=536 bytes for remote networks.</p> <p>2: All networks are assumed to be remote (MSS=536 bytes), except the local subnet.</p> <p>MSS affects performance by helping to prevent IP fragmentation that may result in data retransmission.</p>
<p>tcp-msl:</p> <p>Specifies the maximum segment life (MSL) in seconds. The range is 5 - 120 seconds. The default is 15 seconds.</p>
<p>telnet-config: (telnet:)</p> <p>If set to 0, this parameter instructs the print server not to allow incoming Telnet connections. To regain access, change the setting in the TFTP configuration file and power cycle the print server, or cold reset the print server to factory default values. If this parameter is set to 1, incoming Telnet connections are allowed.</p>

Table 3.3 TFTP Configuration File Parameters (7 of 12)

<p>default-ip:</p> <p>Specifies the IP address to use when the print server is unable to obtain an IP address from the network during a forced TCP/IP reconfiguration (for example, when powered off/on or manually configured to use BOOTP/DHCP).</p> <p>DEFAULT_IP: sets the legacy default IP address 192.0.0.192.</p> <p>AUTO_IP: sets a link-local IP address 169.254.x.x.</p> <p>The initial setting is determined by the IP address obtained when first powered on.</p>
<p>default-ip-dhcp:</p> <p>Specifies whether DHCP requests will be periodically transmitted when a legacy default IP address 192.0.0.192 or link-local IP address 169.254.x.x has been automatically assigned.</p> <p>0: Disables DHCP requests.</p> <p>1 (default): Enables DHCP requests.</p>
<p>dhcp-arbitration:</p> <p>Specifies the amount of time, in seconds, that the print server will wait for DHCP configuration offers. A value from 1 to 10 may be set. The default is 5 seconds.</p>
<p>phone-home-config:</p> <p>Specifies privacy settings on the print server during embedded Web server access. This command controls whether statistical data on product use may be sent to HP. For HP to collect data, Internet access is required.</p> <p>2: Prompt the user to allow sending data on initial access to the Networking tab of the embedded Web server. This is the factory-default and cold-reset value. Once changed, this value cannot be re-selected.</p> <p>1: Allows the sending of data to HP without prompting the user.</p> <p>0: Disables sending data to HP without prompting the user.</p>
<p>web-refresh:</p> <p>Specifies the time interval (1 -99999 seconds) for embedded Web server diagnostic page updates. If set to 0, the refresh rate is disabled.</p>
SNMP
<p>snmp-config:</p> <p>Enables or disables SNMP operation on the print server. 0 disables, 1 (default) enables SNMP.</p> <p>CAUTION: Disabling SNMP will disable all SNMP agents (SNMP v1, v2, v3) as well as communications with HP Web Jetadmin. In addition, firmware upgrades through current HP downloading utilities will be disabled.</p>

Table 3.3 TFTP Configuration File Parameters (8 of 12)

<p>get-cmnty-name: (get-community-name:)</p> <p>Specifies a password that determines which SNMP GetRequests the HP Jetdirect print server will respond to. This is optional. If a user-specified get community name is set, the print server will respond to either a user-specified community name or the factory-default. The community name must be ASCII characters. The maximum length is 255 characters.</p>
<p>set-cmnty-name: (set-community-name:)</p> <p>Specifies a password that determines which SNMP SetRequests (control functions) the HP Jetdirect print server will respond to. The community name of an incoming SNMP SetRequest must match the print server's "set community name" for the print server to respond. (For additional security, you may limit configuration access through the print server's host access list). Community names must be ASCII characters. The maximum length is 255 characters.</p>
<p>auth-trap: (authentication-trap:)</p> <p>Configures the print server to send (on) or not send (off) SNMP authentication traps. Authentication traps indicate that an SNMP request was received, but the community name check failed. The default is "on."</p>
<p>trap-dest: (trap-destination:)</p> <p>Enters a host's IP address into the HP Jetdirect print server's SNMP trap destination list. The command format is:</p> <p>trap-dest: <i>ip-address</i> [community name] [port number]</p> <p>The default community name is "public"; the default SNMP port number is "162". The port number cannot be specified without a community name.</p> <p>If a "trap-community-name" command is followed by "trap-dest" commands, the trap community name will be assigned to those entries unless a different community name is specified in each "trap-dest" command.</p> <p>To delete the table, use "trap-dest: 0".</p> <p>If the list is empty, the print server does not send SNMP traps. The list may contain up to three entries. The default SNMP Trap Destination List is empty. To receive SNMP traps, the systems listed on the SNMP trap destination list must have a trap daemon to listen to those traps.</p>
<p>IPX/SPX</p>
<p>ipx-config: (ipx/spx:)</p> <p>Enables or disables IPX/SPX protocol operation on the print server: 0 disables, 1 (default) enables.</p>

Table 3.3 TFTP Configuration File Parameters (9 of 12)

ipx-unit-name: A user-assigned alphanumeric name assigned to the print server (31 characters maximum). By default, the name will be NPIxxxxxx, where xxxxxx are the last six digits of the LAN hardware address.
ipx-frametype: Specify the IPX frame type setting available for your print server model: AUTO (default), EN_SNAP, EN_8022, EN_8023, EN_II.
ipx-sapinterval: Specifies the time interval (1 to 3600 seconds) that the HP Jetdirect print server waits between Service Advertising Protocol (SAP) broadcasts on the network. The default is 60 seconds. 0 disables SAP broadcasts.
ipx-nds-tree: Identifies the name of the Novell Directory Services (NDS) tree for this printer.
ipx-nds-context: An alphanumeric string, up to 256 characters, that specifies the NDS context for the HP Jetdirect print server.
ipx-job-poll: Specifies the time interval (seconds) that the HP Jetdirect print server will wait to check for print jobs in a print queue.
pjl-banner: (ipx-banner:) Enables or disables printing an IPX banner page. 0 disables banner pages. 1 (default) enables banner pages.
pjl-eoj: (ipx-eoj:) Enables or disables IPX end-of-job notification. 0 disables, 1 (default) enables.
pjl-toner-low: (ipx-toner-low:) Enables or disables IPX toner-low notification. 0 disables, 1 (default) enables.
AppleTalk
appletalk: (at-config:, ethertalk:) Enables or disables AppleTalk (EtherTalk) protocol operation on the print server: 0 disables, 1 (default) enables.
name-override: (External print servers only) Specifies the name of the AppleTalk network. Up to 32 characters may be used.

Table 3.3 TFTP Configuration File Parameters (10 of 12)

DLC/LLC
<p>dlc/llc-config: (dlc/llc:)</p> <p>Enables or disables DLC/LLC protocol operation on the print server: 0 disables, 1 (default) enables.</p>
Other Settings
<p>link-type:</p> <p>(10/100 Fast Ethernet) Sets the print server's link speed (10 or 100 Mbps) and communication mode (Full- or Half-Duplex). Selections are AUTO, 100FULL, 100HALF, 10FULL, 10HALF.</p> <p>For AUTO (default), the print server uses autonegotiation to determine the link speed and mode. If autonegotiation fails, then 100HALF is set.</p>
<p>upgrade:</p> <p>To configure one or more Jetdirect print servers with the name and location of a firmware upgrade file.</p> <p>CAUTION: Ensure that command parameters are properly entered and that the upgrade file is a higher version than the currently installed version. The print server will attempt to upgrade when the upgrade file contains a higher version than the installed version.</p> <p>The command format is:</p> <p>upgrade: <TFTP server IP> <Version> <Product Number> <Filename></p> <p>where,</p> <p>TFTP Server IP is the IP address of the TFTP server,</p> <p>Version specifies the firmware version of the upgrade file,</p> <p>Product Number specifies and must match the product number of the print server,</p> <p>Filename is the path and filename of the firmware upgrade file.</p>
<p>webscan-config:</p> <p>Enables or disables the Web Scan feature on the print server when connected to a supported device. 0 disables, 1 (default) enables.</p>
<p>scan-idle-timeout:</p> <p>Specifies the number of seconds (1 - 3600) that an idle scan connection is allowed to remain open. 0 disables the timeout. The default is 300 seconds.</p>
<p>scan-email-config:</p> <p>Enable or disable the scan-to-email feature in the Web Scan server. 0 disables, 1 (default) enables.</p>
<p>MFP-config:</p> <p>Enable or disable print server support of the client software provided with your multifunction or all-in-one peripheral.</p> <p>0 (default): disables client software support (allows printing only).</p> <p>1: enables client software support (allows printing and scanning).</p>

Table 3.3 TFTP Configuration File Parameters (11 of 12)

<p>usb-mode:</p> <p>Specifies the communication mode over the USB port on the HP Jetdirect print server.</p> <ul style="list-style-type: none">● Auto (default): Automatically negotiates and sets the the highest communication mode possible for the attached printer or device.● MLC: (Multiple Logical Channels) An HP-proprietary communication mode that allows multiple channels of simultaneous print, scan and status communications.● BIDIR: A standard connection that supports bi-directional communications between the printer and print server. The print server sends print data and receives status from the printer.● UNIDIR: A standard connection in which data is transferred in one direction only (to the printer).
<p>status-page-lang:</p> <p>Specifies the page description language (PDL) that the print server will use to send the Jetdirect configuration/status page to the printer.</p> <ul style="list-style-type: none">● Auto (default): The PDL is auto-detected when the print server is powered on or after a cold-reset.● PCL: Hewlett-Packard Printer Control Language● ASCII: Standard ascii characters● HPGL2: Hewlett-Packard Graphics Language (v2)● PS: Postscript language
<p>network-select:</p> <p>(For HP Jetdirect products with a dual wired/wireless port, such as model ew2400) Specifies the active behavior of the print server.</p> <ul style="list-style-type: none">● Auto (default): Automatically detects whether a network cable is attached. If a network cable is not attached, only the IEEE 802.11g wireless port will be active. However, if a network cable is attached, then only the IEEE 802.3 wired port will be active. Use caution when plugging in a network cable on an active wireless network. Wireless access to the device will be terminated.● Wired: Only the 802.3 wired port will be active.● Wireless: Only the 802.11g wireless port will be active.

Table 3.3 TFTP Configuration File Parameters (12 of 12)

Support	
support-name: (support-contact:)	Typically used to identify the name of a person to contact for support of this device.
support-number:	Typically used to specify a phone number or extension to call for support of this device.
support-url:	A Web URL for product information on this device over the Internet or an intranet.
tech-support-url:	A Web URL for technical support over the Internet or an intranet.

Using DHCP

Note For HP Jetdirect *wireless* print servers, this section assumes that a wireless connection to your network has been established.

Dynamic Host Configuration Protocol (DHCP, RFC 2131/2132) is one of several auto configuration mechanisms that the HP Jetdirect print server uses. If you have a DHCP server on your network, the HP Jetdirect print server automatically obtains its IP address from that server and registers its name with any RFC 1001 and 1002-compliant dynamic name services as long as a WINS (Windows Internet Naming Service) server IP address has been specified.

A TFTP (Trivial File Transfer Protocol) configuration file may also be used with DHCP to configure extended parameters. For more information on TFTP parameters, see “[Using BOOTP/TFTP](#)”.

Note DHCP services must be available on the server. Refer to your system documentation or online help to install or enable DHCP services.

Note If the Jetdirect print server and BOOTP/DHCP server are located on different subnets, IP configuration may fail unless the routing device allows the transfer of DHCP requests between subnets.

UNIX Systems

For more information on setting up DHCP on UNIX systems, see the `bootpd` man page.

On HP-UX systems, a sample DHCP configuration file (`dhcptab`) may be located in the `/etc` directory.

Since HP-UX presently does not provide Dynamic Domain Name Services (DDNS) for its DHCP implementations, HP recommends that you set all print server lease durations to “infinite”. This ensures that print server IP addresses remain static until dynamic domain name services are provided.

Windows Systems

HP Jetdirect print servers support IP configuration from a supported Windows DHCP server. This section describes how to set up a pool, or “scope,” of IP addresses that the Windows server can assign or lease to any requester. When configured for BOOTP or DHCP operation and powered on, the HP Jetdirect print server automatically sends a BOOTP or DHCP request for its IP configuration. If properly set up, a Windows DHCP server will respond with the print server’s IP configuration data.

Note

This information is provided as an overview. For specific information or for additional support, see the information supplied with your DHCP server software.

Note

To avoid problems resulting from IP addresses that change, HP recommends that all printers be assigned IP addresses with infinite leases or reserved IP addresses.

Windows NT 4.0 Server

To set up a DHCP scope on a Windows NT 4.0 server, perform the following steps:

1. At the Windows NT server, open the *Program Manager* window and double-click the *Network Administrator* icon.
2. Double-click the **DHCP Manager** icon to open this window.
3. Select **Server** and select **Server Add**.
4. Type the server IP address, then click **OK** to return to the *DHCP Manager* window.
5. In the list of DHCP servers, click on the server you have just added, then select **Scope** and select **Create**.
6. Select **Set up the IP Address Pool**. In the *IP Address Pool* section, set up the IP address range by typing the beginning IP address in the *Start Address* box and the ending IP address in the *End Address* box. Also type the subnet mask for the subnet to which the IP address pool applies.

The starting and ending IP addresses define the end points of the address pool assigned to this scope.

Note If desired, you can exclude ranges of IP addresses within a scope.

7. In the *Lease Duration* section, select **Unlimited**, then select **OK**.

HP recommends that all printers be assigned infinite leases to avoid problems resulting from IP addresses that change. Be aware, however, that selecting an unlimited lease duration for the scope causes all clients in that scope to have infinite leases.

If you want clients on your network to have finite leases, you can set the duration to a finite time, but you should configure all printers as reserved clients for the scope.

8. Skip this step if you have assigned unlimited leases in the previous step. Otherwise, select **Scope** and select **Add Reservations** to set up your printers as reserved clients. For each printer, perform the following steps in the *Add Reserved Clients* window to set up a reservation for that printer:
 - a. Type the selected IP address.
 - b. Obtain the MAC address or hardware address from the configuration page, and type this address in the *Unique Identifier* box.
 - c. Type the client name (any name is acceptable).
 - d. Select **Add** to add the reserved client. To delete a reservation, in the *DHCP Manager* window, select **Scope** and select **Active Leases**. In the *Active Leases* window, click on the reservation you want to delete and select **Delete**.
9. Select **Close** to return to the *DHCP Manager* window.
10. Skip this step if you are not planning to use WINS (Windows Internet Naming Service). Otherwise perform the following steps when configuring your DHCP server:
 - a. From the *DHCP Manager* window, select **DHCP Options** and select one of the following:

Scope — if you want Name Services only for the selected scope.

Global — if you want Name Services for all scopes.
 - b. Add the server to the *Active Options* list. From the *DHCP Options* window, select **WINS/NBNS Servers (044)** from the *Unused Options* list. Select **Add**, then select **OK**.

A warning may appear requesting that you set the node type. You do this in step 10d.

- c. You must now provide the IP address of the WINS server by doing the following:
 - Select **Value**, then **Edit Array**.
 - From the IP Address Array Editor, select **Remove** to delete any undesired addresses previously set. Then type in the IP address of the WINS server and select **Add**.
 - Once the address appears in the list of IP addresses, select **OK**. This returns you to the **DHCP Options** window. If the address you have just added appears in the list of IP addresses (near the bottom of the window) return to step 10d. Otherwise, repeat step 10c.
- d. In the **DHCP Options** window, select **WINS/NBT Node Type (046)** from the **Unused Options** list. Select **Add** to add the node type to the **Active Options** list. In the **Byte** box, type 0x4 to indicate a mixed node, and select **OK**.

11. Click **Close** to exit to **Program Manager**.

Windows 2000 Server/Server 2003

To set up a DHCP scope on a Windows 2000 server or Server 2003 system, perform the following steps:

1. Run the Windows DHCP manager utility.
 - Windows 2000: Click **Start**, then select **Settings** and **Control Panel**. Open the **Administrative Tools** folder and run the **DHCP** utility.
 - Server 2003: Click **Start**, then select **Control Panel**. Open the **Administrative Tools** folder and run the **DHCP** utility.
2. In the **DHCP** window, locate and select your Windows server in the DHCP tree.

If your server is not listed in the tree, select **DHCP** and click the **Action** menu to add the server.
3. After selecting your server in the DHCP tree, click the **Action** menu and select **New Scope**. This runs the **Add New Scope Wizard**.
4. In the **Add New Scope Wizard**, click **Next**.
5. Enter a Name and Description for this scope, then click **Next**.

6. Enter the range of IP addresses for this scope (beginning IP address and ending IP address). Also, enter the subnet mask. then click **Next**.

Note

If subnetting is used, the subnet mask defines which portion of an IP address specifies the subnet and which portion specifies the client device. For more information, see [Appendix A](#).

7. If applicable, enter the range of IP addresses within the scope to be excluded by the server. Then click **Next**.
8. Set the IP address lease duration for your DHCP clients. Then click **Next**.

HP recommends that all printers be assigned reserved IP addresses. This can be accomplished after you set up the scope (see step [11](#)).

9. Select **No** to configure DHCP options for this scope later. Then click **Next**.

To configure DHCP options now, select **Yes** and click **Next**.

- a. If desired, specify the IP address of the router (or default gateway) to be used by clients. Then click **Next**.
 - b. If desired, specify the Domain Name and DNS (Domain Name System) servers for clients. Click **Next**.
 - c. If desired, specify WINS server names and IP addresses. Click **Next**.
 - d. Select **Yes** to activate the DHCP options now, and click **Next**.
10. You have successfully set up the DHCP scope on this server. Click **Finish** to close the wizard.

11. Configure your printer with a reserved IP address within the DHCP scope:
 - a. In the DHCP tree, open the folder for your scope and select **Reservations**.
 - b. Click the **Action** menu and select **New Reservation**.
 - c. Enter the appropriate information in each field, including the reserved IP address for your printer. (Note: the MAC address for your HP Jetdirect-connected printer is available on the HP Jetdirect configuration page.)
 - d. Under “Supported types”, select **DHCP only**, then click **Add**. (Note: Selecting **Both** or **BOOTP only** will result in a configuration through BOOTP due to the sequence in which HP Jetdirect print servers initiate configuration protocol requests.)
 - e. Specify another reserved client, or click **Close**. The reserved clients added will be displayed in the Reservations folder for this scope.
12. Close the DHCP manager utility.

NetWare Systems

NetWare 5.x servers provide DHCP configuration services for network clients, including the HP Jetdirect print server. To set up DHCP services on a NetWare server, refer to Novell documentation and support.

To Discontinue DHCP Configuration

CAUTION	Changes to an IP address on your HP Jetdirect print server may require updates to printer or system printing configurations for clients or servers.
----------------	---

If you do not want your HP Jetdirect print server configured through DHCP, you must reconfigure the print server to use a different different configuration method.

1. (For internal print servers) If you use the printer control panel to set Manual or BOOTP configuration, then DHCP will not be used.
2. You can use Telnet to set Manual (status indicates “User Specified”) or BOOTP configuration, then DHCP will not be used.
3. You can manually modify the TCP/IP parameters through a supported Web browser using the Jetdirect embedded Web server or HP Web Jetadmin.

If you change to BOOTP configuration, the DHCP-configured parameters are released and the TCP/IP protocol is initialized.

If you change to Manual configuration, the DHCP-configured IP address is released and the user-specified IP parameters are used.

Therefore, if you manually provide the IP address, you should also manually set all of the configuration parameters, such as subnet mask, default gateway, and idle timeout.

Note

If you choose to re-enable a DHCP configuration, the print server will acquire its configuration information from a DHCP server. This means that when you choose DHCP and complete your configuration session (using Telnet, for example), the TCP/IP protocol for the print server is re-initialized and all current configuration information is deleted. The print server then attempts to acquire new configuration information by sending DHCP requests on the network to a DHCP server.

For DHCP configuration through Telnet, refer to [“Using Telnet”](#) in this chapter.

Using RARP

Note For HP Jetdirect *wireless* print servers, this section assumes that a wireless connection to your network has been established.

This section describes how to configure the print server using the Reverse Address Resolution Protocol (RARP) on UNIX and Linux systems.

This setup procedure enables the RARP daemon running on your system to respond to a RARP request from the HP Jetdirect print server and to supply the IP address to the print server.

1. Turn the printer off.
2. Log onto your UNIX or Linux system as a superuser.
3. Make sure the RARP daemon is running on your system by typing the following command at the system prompt:

```
ps -ef | grep rarpd (Unix)
```

```
ps ax | grep rarpd (BSD or Linux)
```
4. The system response should be similar to the following:

```
861 0.00.2 24 72 5 14:03 0:00 rarpd -a
```

```
860 0.00.5 36 140 5 14:03 0:00 rarpd -a
```
5. If the system does not display a process number for the RARP daemon, see the *rarpd* man page for instructions on starting the RARP daemon.
6. Edit the `/etc/hosts` file to add your designated IP address and node name for the HP Jetdirect print server. For example:

```
192.168.45.39 laserjet1
```

7. Edit the `/etc/ethers` file (`/etc/rarpd.conf` file in HP-UX 10.20) to add the LAN hardware address/station address (from the configuration page) and the node name for the HP Jetdirect print server. For example:

```
00:01:E6:a8:b0:00 laserjet1
```

Note If your system uses Network Information Service (NIS), you need to incorporate changes to the NIS host and ethers databases.

8. Turn the printer on.
9. To verify that the card is configured with the correct IP address, use the ping utility. At the prompt, type:

```
ping <IP address>
```

where `<IP address>` is the assigned address from RARP.
10. If ping does not respond, see [Chapter 8](#).

Using the arp and ping Commands

Note For HP Jetdirect *wireless* print servers, this section assumes that a wireless connection to your network has been established.

You can configure an HP Jetdirect print server with an IP address using an ARP (Address Resolution Protocol) command from a supported system. The protocol is not routable, that is, the workstation from which the configuration is made must be located on the same network segment as the HP Jetdirect print server.

Using the arp and ping commands with HP Jetdirect print servers requires the following:

- Windows NT/2000/XP/Server 2003 or UNIX system configured for TCP/IP operation
- A legacy default IP address 192.0.0.192 has been set on the print server
- The LAN hardware (MAC) address of the HP Jetdirect print server (specified on an HP Jetdirect configuration page, or on a label attached to HP Jetdirect external print servers)

Note On some systems, superuser rights may be required for the arp command.

After an IP address is assigned through arp and ping commands, use other tools (such as Telnet, embedded Web server, or HP Web Jetadmin software) to configure other IP parameters.

To configure a Jetdirect print server, use the following commands:

```
arp -s <IP address> <LAN hardware address>
ping <IP address>
```

where <IP address> is the desired IP address to be assigned to the print server. The arp command writes the entries to the arp cache on the workstation, and the ping command configures the IP address on the print server.

Depending on the system, the LAN hardware address may require a specific format.

For example:

- For Windows NT 4.0, 2000, XP, Server 2003

```
arp -s 192.168.45.39 00-01-E6-a2-31-98  
ping 192.168.45.39
```

- For UNIX

```
arp -s 192.168.45.39 00:01:E6:a2:31:98  
ping 192.168.45.39
```

Note

Once the IP address has been set on the print server, additional `arp` and `ping` commands will be ignored. Once the IP address is configured, `arp` and `ping` cannot be used unless the print server is reset to factory values (see [Chapter 8](#)).

On UNIX systems, the `arp -s` command may vary between different systems.

Some BSD-based systems expect the IP address (or host name) in reverse order. Other systems may require additional parameters. See your system documentation for specific command formats.

Using Telnet

Note For HP Jetdirect *wireless* print servers, this section assumes that a wireless connection to your network has been established.

This section describes how to configure the print server using Telnet.

Although a Telnet connection may be protected by an administrator password, Telnet connections are not secure. For networks with high security levels, Telnet connections can be disabled on the print server using other tools (for example, TFTP, embedded Web server, or HP Web Jetadmin software).

Creating a Telnet Connection

To use Telnet commands with the HP Jetdirect print server, a route must be available from your workstation to the print server. If the print server and your computer must have a similar IP address, that is, the network portion of their IP addresses match, chances are that a route will exist. For information on IP address structure, see [Appendix A](#).

If their IP addresses do not match, then you can either change your workstation's IP address to match, or you can try an operating system command to create a route to the print server. (For example, if the print server is configured with a legacy default IP address 192.0.0.192, a route will not likely exist.)

On Windows systems, you can use the “route” command at a Windows command (DOS) prompt to create a route to the print server.

For information on system command prompts, see your Windows online help. On Windows NT systems, the command prompt utility is in the **Programs** folder (click **Start, Programs, Command Prompt**). On Windows 2000/XP/Server 2003 systems, it is in the **Accessories** folder in the **Programs** or **All Programs** folder.

To use the route command, you will also need the IP address of your workstation. To view it, you can enter the appropriate command at the command prompt:

```
C:\> ipconfig (on Windows NT/2000/XP/Server 2003)
```

```
C:\> winipconfig (on Windows 98)
```

To create a route from the system command prompt, enter the following command:

```
route add <Jetdirect IP Address> <system IP Address>
```

where <Jetdirect IP address> is the IP address configured on the HP Jetdirect print server, and <system IP address> is the IP address of the workstation's network card that is attached to the same physical LAN as the print server.

For example, to create a route from your workstation with IP address 169.254.2.1 to a print server with a default IP address of 192.0.0.192, try this command:

```
route add 192.0.0.192 169.254.2.1
```

CAUTION

Using Telnet to manually set an IP address will override dynamic IP configuration (such as BOOTP, DHCP, or RARP), resulting in a static configuration. In a static configuration, the IP values are fixed and the operation of BOOTP, DHCP, RARP and other dynamic configuration methods may no longer function.

Whenever you are manually changing an IP address, you should also reconfigure the subnet mask and default gateway at the same time.

A Typical Telnet Session

Initiating a typical Telnet session is illustrated below.

```
Microsoft(R) Windows NT(TM)
(C) Copyright 1985-1996 Microsoft Corp.

C:\>Telnet 192.168.40.133
C:\>_

Telnet - 192.168.40.133
Connect Edit Terminal Help
HP JetDirect
Password is not set

Please type "?" for help, or "/" for current settings.
>

Telnet - 192.168.40.133
Connect Edit Terminal Help
Please type "?" for help, or "/" for current settings.
> ?
Help Menu

Type one "Command" followed by one of its valid "Values".

Command:          Values:
-----          -
TCP/IP
ip-config          MANUAL, BOOTP-ONLY, DHCP-ONLY
ip                 IP address in dotted notation, 0.0.0.0 to dis
subnet-mask       IP address in dotted notation, 0.0.0.0 to dis
default-gw        IP address in dotted notation, 0.0.0.0 to dis
idle-timeout      integer (1..3600) seconds, 0 to disable
syslog-svr        IP address in dotted notation, 0.0.0.0 to dis
tftp-server       IP address in dotted notation, 0.0.0.0 to dis
```

To set configuration parameters, you must set up a Telnet session from your system to the HP Jetdirect print server.

1. Type the following at the system prompt:

```
telnet <IP address>
```

where <IP address> is the IP address listed on the Jetdirect configuration page. See [Chapter 9](#).

2. A connection to the HP Jetdirect print server will be displayed. If the server responds with “connected to IP address”, press **Enter** twice to make sure that the Telnet connection is initialized.
3. If prompted for a user name and password, enter the correct values.

By default, the Telnet interface does not require a user name or password. If an administrator password has been set, you will be prompted for a user name and this password before you can enter and save Telnet command settings.

4. By default, a Command Line interface is provided. To configure parameters using a Menu interface, enter **Menu**. For more information, see “[User Interface Options](#)”.

For a list of supported commands and parameters, see “[Telnet Commands and Parameters](#)”.

User Interface Options

The HP Jetdirect print server provides two interface options to enter Telnet commands: a [Command Line Interface \(Default\)](#) and a [Menu Interface](#).

Command Line Interface (Default)

Using the Telnet command line interface, you can set configuration parameters using the following procedures:

Note

During a Telnet session, enter ? to view available configuration parameters, the correct command format, and a list of commands.

To list additional (or advanced) commands, enter the command advanced before entering ?.

To display current configuration information, enter /.

1. At the Telnet prompt ">" type:

```
<parameter>: <value>
```

then press **Enter**, where <parameter> refers to the configuration parameter you are defining, and <value> refers to the definitions you are assigning to that parameter. Each parameter entry is followed by a carriage return.

See [Table 3.4](#) for configuration parameters.

2. Repeat the previous step to set any additional configuration parameters.
3. When you have finished typing the configuration parameters, type `exit` or `quit` (depending on your system).

When prompted whether to save settings that you have changed, enter Y (default) for Yes, or N for No.

If you enter `save` instead of `exit` or `quit`, you will not be prompted to save settings.

Telnet Commands and Parameters. [Table 3.4](#) lists the available Telnet commands and parameters.

Note If a parameter is supplied dynamically (for example, from a BOOTP or DHCP server), its value cannot be changed using Telnet without first setting Manual configuration. To set Manual configuration, see the `ip-config` command.

Whenever you are manually changing an IP address, you should also reconfigure the subnet mask and default gateway at the same time.

Table 3.4 Telnet Commands and Parameters (1 of 18)

User Control Commands	
Command	Description
?	Displays the Help and Telnet commands.
/	Displays current values.
menu	Displays the Menu Interface for access to configuration parameters.
advanced	Enables the Advanced commands. Help (?) will include the Advanced commands in the list.
general	Disables the Advanced commands. Help (?) will not include Advanced commands (default).
save	Save the configuration values and exit the session.
exit	Exit the session.
export	Export the settings to a file for editing, and importing through Telnet or TFTP (this command is only supported by systems, such as UNIX, that support input/output redirection).
General	
Command	Description
passwd	Set the administrator password (shared with the embedded Web server and HP Web Jetadmin). For example, "passwd jd1234 jd1234" sets the password to jd1234. Note that "jd1234" is entered twice for confirmation. Up to 16 alphanumeric characters may be used. When initiating the next Telnet session, you will be prompted for a user name and this password. To clear the password, enter the command without password and confirmation entries. Passwords may be cleared by a cold reset.

Table 3.4 Telnet Commands and Parameters (2 of 18)

sys-location	Alpha-numeric string (up to 255 characters), typically used to identify a location.
sys-contact	Alpha-numeric string (up to 255 characters), typically used to identify the name of a network or device administrator.
ssl-state	Sets the print server's security level for Web communications: 1 (default): Forced redirection to the HTTPS port. Only HTTPS (secure HTTP) communications can be used. 2 : Disable forced redirection to HTTPS. Both HTTP and HTTPS communications can be used.
security-reset	Reset security settings on the print server to factory default values. 0 (default) does not reset, 1 resets the security settings.
Wireless 802.11 Main	
Command	Description
network-type	Specify the 802.11g wireless network topology: Infrastructure : The print server will communicate on the network with other wired or wireless devices through an Access Point. Ad Hoc : (default) The print server will communicate with other wireless devices directly, without using an Access Point.
desired-ssid	Specify the desired Service Set Identifier (SSID), or Network Name, for the print server. Up to 32 alphanumeric characters may be used. The factory-default SSID is <code>hpsetup</code> in Ad Hoc mode. An Infrastructure network SSID of <code>hpsetup</code> should not be used. If the <code>ssid</code> command is issued without an entry (a blank SSID), the desired SSID will be assigned <code><AUTO></code> , where it will associate with the first network that matches its authentication settings.
encryption	Specify the use of encryption. 0 (default) disables, 1 enables.
wep-key-method	Specify the format for WEP key entry. WEP key entries must be of the proper length. ASCII : (default) Use alphanumeric ASCII characters (0 - 9, a - z, A - Z). For 40/64-bit encryption, enter 5 characters. For 104/128-bit encryption, enter 13 characters. ASCII entries are case-sensitive. HEX : Use hexadecimal digits (0 - 9, a - f, A - F). For 40/64-bit encryption, enter 10 hexadecimal digits. For 104/128-bit encryption, enter 26 hexadecimal digits. HEX entries are not case-sensitive.

Table 3.4 Telnet Commands and Parameters (3 of 18)

wep-key	<p>Specify a static WEP (Wired Equivalent Privacy) encryption key. The print server can store up to four WEP keys using four key positions (Key 1, 2, 3, 4). To enter a WEP key, specify the key position followed by the encryption key value. For example,</p> <pre>wep-key 1 0123456789net</pre> <p>assigns Key 1 with a 128-bit WEP key specified by the value 0123456789net.</p> <p>You can use the <code>wep-key-method</code> command to specify the format of the key value (hexadecimal digits, or alphanumeric ASCII characters). Alternatively, you can insert an optional parameter (ASCII or HEX) after the key position. For example,</p> <pre>wep-key 1 ASCII 0123456789net</pre> <p>assigns Key 1 with a 128-bit WEP key specified by the alphanumeric ASCII characters 0123456789net.</p> <p>When assigning static WEP keys, ensure that key positions and key values match other wireless devices on the network. Ensure that all key values entered are of the same length, and that WEP key lengths use the proper number of characters or digits.</p>
transmit-key	<p>Specify the WEP key position (1, 2, 3, 4) that the print server will use for encrypted communications. For example,</p> <pre>transmit-key 2</pre> <p>specifies that Key 2 will be used for encrypted communications, matching other devices on the network.</p>
desired-channel	<p>(Ad Hoc) Specify a desired channel that the print server will use for Ad Hoc network association requests. For ew2400, the default is channel 11.</p> <p>10: Use channel 10 (2457 MHz).</p> <p>11: Use Channel 11 (2462 MHz).</p> <p>The print server will use this channel to broadcast its availability if it fails to detect and associate with the specified Ad Hoc network on any channel.</p>
auth-type	<p>Specify a link-based authentication method for the print server before network access is allowed.</p> <p>Open: (default) Use Open System authentication if your wireless network does not require authentication for network access. However, your network may still use WEP encryption keys for data security.</p> <p>Shared_Key: Use Shared Key authentication if your network requires that each device be configured with the same secret WEP key for network access.</p> <p>Selecting Shared_Key is not valid with the <code>wpa-auth-type</code> command when setting WPA-PSK authentication.</p>

Table 3.4 Telnet Commands and Parameters (4 of 18)

wpa-auth-type	<p>This command is not compatible with the Shared Key authentication option in the <code>auth-type</code> command. Use this command to specify WPA-PSK authentication.</p> <p>PSK: WPA-PSK provides enhanced authentication where an authentication server is not used. Instead, a Pre-shared key provides device authentication. A Pre-shared key is generated when you specify a network pass-phrase using the <code>psk-passphrase</code> command. The <code>dynamic-encrypt</code> command should be set to the Robust option.</p>
psk-passphrase	<p>Specify a pass-phrase that is used to generate a network Pre-shared key. A pass-phrase must be from 8 to 63 ASCII characters in the hexadecimal range 21 through 7E (characters 0-9, a-z, A-Z and numerous special characters including !, @, #, \$, %, ^, &, (,), _, +, =, -, {, }, [,], \, /, ", <, >, ?, ", ' , ~).</p>
dynamic-encrypt	<p>For WPA-PSK authentication, use this command to set the print server for dynamic Wi-Fi Protected Access (WPA) encryption. Specify Robust as the command option.</p>
802.11 Wireless Diagnostics	
Command	Description
Current SSID	(Read-only parameter) The network name (SSID) to which the wireless print server connected.
Current Channel	(Read-only parameter) The channel that the wireless print server is currently using.
Signal Strength	<p>(Read-only parameter) The strength of the radio signal received by the print server.</p> <p><blank>: No radio signal detected while the print server is scanning.</p> <p>No Signal: No radio signal detected on any channel.</p> <p>Poor/Marginal/Good/Excellent: Indicates the detected signal strength level.</p>
Access Point Mac	<p>(Read-only parameter) The Media Access Control (MAC) address of the Access Point used for Infrastructure mode communications. For example,</p> <p>00:a0:f8:38:7a:f7</p> <p>specifies that the Access Point with MAC address 00a0f8387af7 was used for communicating on the network.</p>

Table 3.4 Telnet Commands and Parameters (5 of 18)

TCP/IP Main	
Command	Description
host-name	Alphanumeric string (up to 32 characters), to assign or change the name of the network device. For example, "host-name printer1" assigns the name "printer1" to the device. The default host name is NPIxxxxxx, where xxxxxx are the last six digits of the LAN hardware (MAC) address.
ip-config	Specify the configuration method: manual: The print server will wait for IP parameters using manual tools (such as Telnet, embedded Web server, control panel, installation/management software). Status will be <code>User Specified</code> . bootp: The print server will send BOOTP requests on the network for dynamic IP configuration. dhcp: The print server will send DHCP requests on the network for dynamic IP configuration. auto_ip: The print server will be automatically configured with a unique link-local address 169.254.x.x.
ip	IP address for the print server, in dotted notation. For example: <pre>ip-config manual ip 192.168.45.39</pre> where <code>ip-config</code> specifies manual configuration and <code>ip</code> manually sets the IP address 192.168.45.39 on the print server. Specifying 0.0.0.0 clears the IP address. If you exit and save a new IP address, it must be specified on the next Telnet connection.
subnet-mask	A value (in dotted notation) that identifies the network and host portions of an IP address in received messages. For example, <pre>subnet-mask 255.255.255.0</pre> stores the subnet mask value 255.255.255.0 on the print server. The value 0.0.0.0 disables the subnet mask. For more information see Appendix A .
default-gw	The IP address of a default gateway, in dotted notation. For example, <pre>default-gw 192.168.40.1</pre> assigns 192.168.40.1 as the IP address of the default gateway for the print server. Note: If the HP Jetdirect print server is configured by DHCP and you manually change the subnet mask or the default gateway address, you should manually change the print server's IP address. This will release the DHCP-assigned address back to the DHCP IP address pool.

Table 3.4 Telnet Commands and Parameters (6 of 18)

Config Server	(Read-only parameter) The IP address of the server (such as a BOOTP or DHCP server) that last configured the IP address on the HP Jetdirect print server.
TFTP Server	(Read-only parameter) The IP address of the TFTP server that provided TFTP parameters to the HP Jetdirect print server.
TFTP Filename	(Read-only parameter) The path and TFTP filename on the TFTP server. For example, hpnnp/printer1.cfg
domain-name	The domain name for the device. For example, domain-name support.hp.com assigns support.hp.com as the domain name. The domain name does not include the host name; it is not the Fully Qualified Domain Name (such as printer1.support.hp.com).
pri-dns-svr	IP address of the primary DNS (Domain Name System) server.
sec-dns-svr	IP address of a secondary DNS server to use if the primary DNS server is unavailable.
pri-wins-svr	The IP address of the primary Windows Internet Naming Service (WINS) server, in dotted notation.
sec-wins-svr	The IP address of the secondary Windows Internet Naming Service (WINS) server, in dotted notation.
smtp-svr	(SMTP Mail Server) The IP address of the outgoing e-mail Simple Mail Transport Protocol (SMTP) server, for use with supported Scan devices.
TCP/IP Print Options	
Command	Description
9100-printing	Enables or disables printing to TCP port 9100 on the print server. 0 disables, 1 (default) enables.
ftp-printing	Enables or disables the ability to print through FTP. 0 disables, 1 (default) enables. (TCP ports 20, 21)
ipp-printing	Enables or disables the ability to print using IPP. 0 disables, 1 (default) enables. (TCP port 631)
lpd-printing	Enables or disables the ability to print using LPD. 0 disables, 1 (default) enables. (TCP port 515)
banner	Enables or disables printing an LPD banner page. 0 disables banner pages. 1 (default) enables banner pages.

Table 3.4 Telnet Commands and Parameters (7 of 18)

interlock	Specifies whether an acknowledgement (ACK) on all TCP packets is required before the printer is allowed to close a Port 9100 print connection. A Port Number and Option value are specified. For HP embedded print servers, the default Port Number is 1. Option value 0 (default) disables interlock, 1 enables. For example, "interlock 1 1" specifies port 1, interlock enabled.
mult-tcp-conn	(Restrict Multiple Ports) Enables or disables multiple TCP connections. Allows you to restrict the use of multiple ports. 1 (default): allows multiple connections. 0 : disables multiple connections.
buffer-packing	Enables or disables buffer packing for TCP/IP packets. 1 (default): is normal, the data buffer is packed before sending to the printer. 0 : disables buffer packing, data is sent to the printer as it is received.
write-mode	Controls the setting of the TCP PSH flag for device-to-client data transfers. 0 (default): disables this option, flag is not set. 1 : all-push option. The push bit is set in all data packets.
TCP/IP LPD Queues	
Command	Description
addq	Adds a user-defined queue. The queue name (up to 32 displayable ASCII characters), prepend string name, append string name, and processing queue (typically, RAW) must be specified in the command line. Up to six user-defined queues may be added.
deleteq	Delete a user-specified queue. The queue name must be specified in the deleteq command line.
defaultq	Name of the queue to be used if the queue specified for a print job is unknown. By default, the default queue is AUTO .
addstring	Adds a user-defined character string that may be prepended or appended to print data. Up to eight character strings may be specified. A string name and the character string contents are specified in the addstring command line.
deletestring	Deletes a user-defined string. The string name is specified in the deletestring command line.
TCP/IP Raw Print Ports	
Command	Description
raw-port	Specifies additional ports for printing to TCP port 9100. Valid ports are 3000 to 9000, which are application-dependent. Up to two ports can be specified.

Table 3.4 Telnet Commands and Parameters (8 of 18)

TCP/IP Access Control	
Command	Description
allow	<p>Makes an entry into the host access list stored on the HP Jetdirect print server. Each entry specifies a host or network of hosts that are allowed to connect to the printer. The format is “allow netnum [mask]” where netnum is a network number or host IP address, and mask is an address mask of bits applied to the network number and host address to verify access. Up to 10 access list entries are allowed. If there are no entries, all hosts are permitted access. For example,</p> <pre>allow 192.0.0.0 255.0.0.0</pre> <p>allows hosts on network 192.</p> <pre>allow 192.168.1.2</pre> <p>allows a single host. In this case, the default mask 255.255.255.255 is assumed and is not required.</p> <pre>allow 0</pre> <p>clears the host access list.</p> <p>For additional information, see Chapter 7.</p>
TCP/IP Other	
Command	Description
syslog-config	Enables or disables syslog server operation on the print server: 0 disables, 1 (default) enables. (UDP port 514)
syslog-svr	<p>The syslog server’s IP address in dotted notation. It specifies the server that the HP Jetdirect print server sends syslog messages to. For example,</p> <pre>syslog-svr: 192.168.40.1</pre> <p>assigns 192.168.40.1 as the IP address of that server.</p> <p>For more information, see Appendix A.</p>
syslog-max	Specifies the maximum number of syslog messages that can be sent by the HP Jetdirect print server on a per-minute basis. This setting allows administrators to control the log file size. The default is 10 per minute. If it’s set to zero, the number of syslog messages is not restricted.
syslog-priority	<p>Controls the filtering of syslog messages sent to the syslog server. The filter range is 0 to 8, with 0 being the most specific and 8 the most general. Only messages that are lower than the filter level specified (or higher in priority) are reported. The default setting is 8, where messages of all priorities are sent.</p> <p>If 0, all syslog messages are disabled.</p>
syslog-facility	A code used to identify the source facility of a message (for example, to identify the source of selected messages during troubleshooting). By default, the HP Jetdirect print server uses LPR as the source facility code, but local user values of local0 through local7 can be used to isolate individual or groups of print servers.

Table 3.4 Telnet Commands and Parameters (9 of 18)

slp-config	Enables or disables the Service Location Protocol (SLP) operation on the print server: 0 disables, 1 (default) enables. SLP is used by selected HP software applications (through UDP port 427) to automate device discovery.
slp-keep-alive	Specifies a time period for the print server to send multicast packets on the network to prevent being deleted from network device tables. Some infrastructure devices, such as switches, may delete active devices from their device tables due to inactivity on the network. To enable this feature, set a value from 1 to 1440 minutes. Set 0 to disable this feature.
mdns-config	Enables or disables Multicast Domain Name System (mDNS) services. 0 disables, 1 (default) enables. mDNS is typically used on small networks for IP address and name resolution (through UDP port 5353) where a conventional DNS server is not available.
mdns-service-name	Specifies an alphanumeric string of up to 64 ASCII characters assigned to this device or service. This name is persistent and is used to resolve a particular device or service if socket information (such as the IP address) changes from session to session. Apple Rendezvous will display this service. The default service name is the printer model and the LAN Hardware (MAC) address.
mDNS Domain Name	(Read-only parameter) Specifies the mDNS domain name assigned to the device, in the form <host name>.local. If a user-specified host name has not been assigned, the default host name NPLxxxxxx is used, where xxxxxx are the last 6 digits of the LAN hardware (MAC) address.
mdns-pri-svc	Specifies the mDNS highest priority service to use for printing. To set this parameter, choose one of the following printing option numbers: 1: Port 9100 printing 2: IPP port printing 3: The default LPD raw queue 4: The default LPD text queue 5: The default LPD auto queue 6: The default LPD bins (binary postscript) queue 7 through 12: If user-specified LPD queues are defined, corresponds to user-specified LPD queues 5 through 10. The default selection will depend on the printer, typically port 9100 printing or LPD bins.
ttl-slp	Specifies the IP multicast "Time To Live" (TTL) setting for Service Location Protocol (SLP) packets. The default value is 4 hops (the number of routers from the local network). The range is 1-15. When set to a -1, multicast capability is disabled.

Table 3.4 Telnet Commands and Parameters (10 of 18)

ipv4-multicast	Enables or disables the receipt and transmission of IP version 4 multicast packets by the print server. 0 disables, 1 (default) enables.
idle-timeout	An integer (1 to 3600) that specifies the number of seconds an idle print data connection is allowed to remain open. For example, <code>idle-timeout 120</code> assigns 120 seconds as the desired idle timeout value. The default is 270 seconds. If set to 0, the connection will not terminate and other hosts will not be able to make a connection.
user-timeout	An integer (1 to 3600) that specifies the number of seconds that your Telnet or FTP session can be idle before it will be automatically disconnected. The default is 900 seconds. 0 disables the timeout. CAUTION: Small values, such as 1-5, may effectively disable the use of Telnet. A Telnet session may terminate before any changes can be made.
cold-reset	Sets TCP/IP factory default settings. After a cold reset, power cycle the print server. Parameters for other subsystems, such as IPX/SPX or AppleTalk, are not affected.
ews-config	Enables or disables the print server's embedded Web server. 0 disables, 1 (default) enables. For more information, see Chapter 4 .
web-refresh	Specifies the time interval (1 - 99999 seconds) for embedded Web server diagnostic page updates. If set to 0, the refresh rate is disabled.
tcp-mss	Specifies the maximum segment size (MSS) that the HP Jetdirect print server will advertise for use when communicating with local subnets (Ethernet MSS=1460 bytes or more) or remote subnets (MSS=536 bytes): 0: (default) All networks are assumed to be local (Ethernet MSS=1460 bytes or more). 1: Use MSS=1460 bytes (or more) for subnets, and MSS=536 bytes for remote networks. 2: All networks are assumed to be remote (MSS=536 bytes), except the local subnet. MSS affects performance by helping to prevent IP Fragmentation that may result in data retransmission.
tcp-msl	Specifies the maximum segment life (MSL) in seconds. The range is 5 - 120 seconds. The default is 15 seconds.

Table 3.4 Telnet Commands and Parameters (11 of 18)

gw-disable	<p>Specifies whether or not to automatically assign the device IP address as the gateway when a network gateway is not configured.</p> <p>0: A gateway using the device IP address will be assigned.</p> <p>1: A gateway is not assigned. The gateway address 0.0.0.0 will be configured.</p>
default-ip	<p>Specifies the IP address to use when the print server is unable to obtain an IP address from the network during a forced TCP/IP reconfiguration (for example, when powered off/on or manually configured to use BOOTP/DHCP).</p> <p>DEFAULT_IP: sets the legacy default IP address 192.0.0.192.</p> <p>AUTO_IP: sets a link-local IP address 169.254.x.x.</p> <p>The initial setting is determined by the IP address obtained when first powered on.</p>
default-ip-dhcp	<p>Specifies whether DHCP requests will be periodically transmitted when a legacy default IP address 192.0.0.192 or link-local IP address 169.254.x.x has been automatically assigned.</p> <p>0: Disables DHCP requests.</p> <p>1 (default): Enables DHCP requests.</p>
dhcp-fqdn-config dhcp-fqdn-behavior	<p>Specifies configuration control of the Fully Qualified Domain Name (FQDN), using either DHCP, manual configuration, or both. The fully qualified domain name consists of the device's host name and domain name. Select one of the following command values:</p> <p>0 (default): DHCP may be used to supply the host name and domain name. The host name may be changed using a manual configuration method (such as the embedded Web server, printer control panel, or Telnet). However, the domain name cannot be manually changed if it was configured through DHCP.</p> <p>1: Keep DHCP settings only. Once the Fully Qualified Domain Name is configured through DHCP, manual changes cannot be made.</p> <p>2: Keep manual settings. The settings can be manually configured. DHCP may be used only if the settings are factory-default values.</p> <p>3: Keep manual settings only. While manual configuration methods may be used, configuration through DHCP is not allowed.</p>
dhcp-arbitration	<p>Specifies the amount of time, in seconds, that the print server will wait for DHCP configuration offers. A value from 1 to 10 may be set. The default is 5 seconds.</p>

Table 3.4 Telnet Commands and Parameters (12 of 18)

phone-home-config	<p>Specifies privacy settings on the print server during embedded Web server access. This command controls whether statistical data on product use may be sent to HP. For HP to collect data, Internet access is required.</p> <p>2: Prompt the user to allow sending data on initial access to the Networking tab of the embedded Web server. This is the factory-default and cold-reset value. Once changed, this value cannot be re-selected.</p> <p>1: Allows the sending of data to HP without prompting the user.</p> <p>0: Disables sending data to HP without prompting the user.</p>
TCP/IP Diagnostics	
Command	Description
Last Config IP	(Read-only parameter) The IP address of the system from which the HP Jetdirect print server's IP address was configured.
TCP Conns Refused	(Read-only parameter) The number of client TCP connections that are refused by the print server.
TCP Access Denied	(Read-only parameter) The number of times that client systems were denied access to the print server because there was no allowable entry in the print server's host access list.
DHCP Lease Time	(Read-only parameter) DHCP IP address lease duration time (seconds).
DHCP Renew Time	(Read-only parameter) DHCP T1 timeout, specifying the DHCP lease renewal time (seconds).
DHCP Rebind Time	(Read-only parameter) DHCP T2 timeout, specifying the DHCP lease rebind time (seconds).
SNMP	
Command	Description
snmp-config	<p>Enables or disables SNMP operation on the print server. 0 disables, 1 (default) enables SNMP.</p> <p>CAUTION: Disabling SNMP will disable all SNMP agents (SNMP v1, v2, v3) as well as communications with management applications, such as HP Web Jetadmin. In addition, firmware upgrades through current HP downloading utilities will be disabled.</p>
get-cmnty-name	<p>Specifies a password that determines which SNMP GetRequests the HP Jetdirect print server will respond to. This is optional. If a user-specified get community name is set, the print server will respond to either a user-specified community name or the factory-default. The community name must be ASCII characters. The maximum length is 255 characters.</p>

Table 3.4 Telnet Commands and Parameters (13 of 18)

set-cmnty-name	Specifies a password that determines which SNMP SetRequests (control functions) the HP Jetdirect print server will respond to. The community name of an incoming SNMP SetRequest must match the print server's "set community name" for the print server to respond. (For additional security, you may limit configuration access through the print server's host access list.) Community names must be ASCII characters. The maximum length is 255 characters.
default-get-cmnty	Enables or disables the default Get community name. 0 disables, 1 (default) enables. Disabling this parameter may prohibit communications with SNMP management applications.
SNMP Traps	
Command	Description
auth-trap	Configures the print server to send (on) or not send (off) SNMP authentication traps. Authentication traps indicate that an SNMP request was received, but the community name check failed. 0 is off, 1 (default) is on.
trap-dest	Enters a host IP address into the HP Jetdirect print server's SNMP trap destination list. The command format is: trap-dest: <i>ip-address</i> [community name] [port number] The default community name is 'public'; the default SNMP port number is '162'. The port number cannot be specified without a community name. To delete the table, use 'trap-dest: 0'. If the list is empty, the print server does not send SNMP traps. The list may contain up to three entries. The default SNMP Trap Destination List is empty. To receive SNMP traps, the systems listed on the SNMP trap destination list must have a trap daemon to listen to those traps.
IPX/SPX	
Command	Description
ipx-config	Enables or disables IPX/SPX protocol operation on the print server. 0 disables, 1 (default) enables. For example, ipx-config 0 will disable IPX/SPX operation.
ipx-unitname	(Print Server Name) A user-assigned alphanumeric name assigned to the print server (31 characters maximum). By default, the name will be NPlxxxxx, where xxxxxx are the last six digits of the LAN hardware address.
Address	(Read-only parameter) Identifies the IPX network and node numbers detected on the network, in the form NNNNNNNN:hhhhhhh (hexadecimal), where NNNNNNNN is the network number and hhhhhhhh is the LAN hardware address of the print server.

Table 3.4 Telnet Commands and Parameters (14 of 18)

ipx-frametype	Specifies the IPX frame type settings available for your print server model: AUTO (default), EN_SNAP , EN_8022 , EN_8023 , EN_II . For more information, see Chapter 9 .
ipx-sapinterval	Specifies the time interval (1 to 3600 seconds) that the HP Jetdirect print server waits between Service Advertising Protocol (SAP) broadcasts on the network. The default is 60 seconds. 0 disables SAP broadcasts.
ipx-mode	(Read-only parameter) Specifies the NetWare mode configured on the print server, either RPRINTER or QSERVER mode.
ipx-nds-tree	An alphanumeric string, up to 31 characters, that specifies the NDS tree name for the print server.
ipx-nds-context	An alphanumeric string, up to 256 characters, that specifies the NDS context for the HP Jetdirect print server.
ipx-job-poll	Specifies the time interval (1 to 255 seconds) that the HP Jetdirect print server will wait to check for print jobs in a print queue. The default is 2 seconds.
pjl-banner ipx-banner	Enables or disables printing an IPX banner page through Printer Job Language (PJL). 0 disables banner pages. 1 (default) enables banner pages.
pjl-eoj ipx-eoj	Enables or disables IPX end-of-job notification through PJL. 0 disables, 1 (default) enables.
pjl-toner-low ipx-toner-low	Enables or disables IPX toner-low notification through PJL. 0 disables, 1 (default) enables.
AppleTalk	
Command	Description
appletalk	Enables or disables AppleTalk (EtherTalk) protocol operation on the print server. 0 disables, 1 (default) enables. For example, <code>appletalk 0</code> will disable AppleTalk operation
name-override	(External print servers only) Specifies the name of the AppleTalk network. Up to 32 characters may be used.
Name	(Read-only parameter) The name of the printer on the AppleTalk network. A number after the name indicates that there are multiple devices with this name, and this is the Nth instance of the name.
Print Type	(Read-only parameter) Specifies the AppleTalk network printer type reported by the Jetdirect print server. Up to three print types may be reported.
Zone	(Read-only parameter) The name of the AppleTalk network zone on which the printer is located.
Phase	(Read-only parameter) AppleTalk phase 2 (P2) is preconfigured on the HP Jetdirect print server.

Table 3.4 Telnet Commands and Parameters (15 of 18)

Status	<p>(Read-only parameter) Indicates the current AppleTalk configuration status.</p> <p>READY: Indicates the HP Jetdirect print server is awaiting data.</p> <p>DISABLED: Indicates that AppleTalk was manually disabled.</p> <p>INITIALIZING: Indicates that the print server is registering the node address or name. An additional status message may also be displayed.</p>
DLC/LLC	
Command	Description
dlc/llc-config	<p>Enables or disables DLC/LLC protocol operation on the print server. 0 disables, 1 (default) enables. For example,</p> <p style="padding-left: 40px;">dlc/llc-config 0 will disable DLC/LLC operation.</p>
strict-8022	<p>Controls DLC/LLC protocol interpretation:</p> <p>0 (default): disables, that is, provides loose interpretation.</p> <p>1: enables, that is, provides strict interpretation).</p>
Other	
Command	Description
upgrade	<p>To configure one or more Jetdirect print servers with the name and location of a firmware upgrade file.</p> <p>CAUTION: Ensure that command parameters are properly entered and that the upgrade file is a higher version than the currently installed version. The print server will attempt to upgrade when the upgrade file contains a higher version than the installed version.</p> <p>The command format is:</p> <p>upgrade: <TFTP server IP> <Version> <Product Number> <Filename></p> <p>where,</p> <p><TFTP Server IP> is the IP address of the TFTP server,</p> <p><Version> specifies the firmware version of the upgrade file,</p> <p><Product Number> specifies and must match the product number of the print server,</p> <p><Filename> is the path and filename of the firmware upgrade file.</p>
laa	<p>Specifies a locally administered address (LAA) that replaces the factory-assigned LAN Hardware (MAC) address. If LAA is used, a user-specified string of exactly 12 hexadecimal digits must be entered.</p> <p>For Ethernet print servers, the LAA address must start with hexadecimal X2, X6, XA, or XE, where X is any hexadecimal digit 0 through F.</p> <p>The default address is the factory-assigned address.</p>

Table 3.4 Telnet Commands and Parameters (16 of 18)

webscan-config	(Web Scan Config) Enables or disables the Web Scan feature on the print server when connected to a supported device. 0 disables, 1 (default) enables.
scan-idle-timeout	Specifies the number of seconds (1 - 3600) that an idle scan connection is allowed to remain open. 0 disables the timeout. The default is 300 seconds.
scan-email-config	(Email Scan Config) Enable or disable the scan-to-email feature in the Web Scan server. 0 disables, 1 (default) enables.
MFP-config	(MFP config) Enable or disable print server support of the client software provided with your multifunction or all-in-one peripheral. 0 (default): disables client software support (allows printing only). 1 : enables client software support (allows printing and scanning).
usb-mode	Specifies the communication mode over the USB port on the HP Jetdirect print server. <ul style="list-style-type: none">● Auto (default): Automatically negotiates and sets the highest communication mode possible for the attached printer or device.● MLC: (Multiple Logical Channels) An HP-proprietary communication mode that allows multiple channels of simultaneous print, scan and status communications.● BIDIR: A standard connection that supports bi-directional communications between the printer and print server. The print server sends print data and receives status from the printer.● UNIDIR: A standard connection in which data is transferred in one direction only (to the printer).
usb-speed	(Read-only parameter, USB 2.0 products only) Specifies the autonegotiated communication speed over the USB connection between the HP Jetdirect print server and the device. <ul style="list-style-type: none">● Full Speed: 12 Mb/s/sec as specified in the USB v2.0 specifications, compatible with USB v1.1 specifications.● Hi-Speed: 480 Mb/s/sec for USB v2.0 devices only.● Disconnected: The USB port is not connected.

Table 3.4 Telnet Commands and Parameters (17 of 18)

status-page-lang	<p>Specifies the printer job language (PJL) that the print server will use to send the Jetdirect configuration/status page to the printer.</p> <ul style="list-style-type: none">● Auto (default): The PDL is auto-detected when the print server is powered on or after a cold-reset.● PCL: Hewlett-Packard Printer Control Language● ASCII: Standard ascii characters● HPGL2: Hewlett-Packard Graphics Language (v2)● PS: Postscript language
link-type	<p>(10/100 Fast Ethernet) Sets the print server's link speed (10 or 100 Mbps) and communication mode (Full- or Half-Duplex). Selections are AUTO, 100FULL, 100HALF, 10FULL, 10HALF.</p> <p>For AUTO (default), the print server uses autonegotiation to determine the link speed and mode. If autonegotiation fails, then 100HALF is set.</p>
network-select	<p>(For HP Jetdirect products with a dual wired/wireless port, such as model ew2400) Specifies the active behavior of the print server.</p> <ul style="list-style-type: none">● Auto (default): Automatically detects whether a network cable is attached. If a network cable is not attached, only the IEEE 802.11g wireless port will be active. However, if a network cable is attached, then only the IEEE 802.3 wired port will be active. Use caution when plugging in a network cable on an active wireless network. Wireless access to the device will be terminated.● Wired: Only the 802.3 wired port will be active.● Wireless: Only the 802.11g wireless port will be active.
job-timeout	<p>(External print servers only) Specifies the time period after which an idle connection to the printer (for example, through the USB port) will be closed.</p> <p>An integer from 30 to 4294967295 seconds may be specified. If 0 is specified, the default value of 270 seconds is used.</p>
Support	
Command	Description
Web JetAdmin URL	(Read-only parameter) If HP Web Jetadmin discovers this device, the URL to access HP Web Jetadmin will be specified.
Web JetAdmin Name	(Read-only parameter) If HP Web Jetadmin discovers this device, the name of the HP Web Jetadmin host will be specified (if known).
support-name	Typically used to identify the name of a person to contact for support of this device.

Table 3.4 Telnet Commands and Parameters (18 of 18)

support-number	Typically used to specify a phone or extension number to call for support of this device.
support-url	A Web URL address for product information on this device over the Internet or an intranet.
tech-support-url	A Web URL address for technical support over the Internet or an intranet.

Menu Interface

An optional Menu interface is displayed when you type menu at the Telnet command prompt. The Menu interface eliminates the need to memorize commands, and provides structured menu lists for easy access to configuration parameters.

[Figure 3.1](#) illustrates the Menu interface, using the TCP/IP menus as an example.


- From the **Main Menu** screen, select and enter a menu number. If there are submenus, select and enter a submenu number.
- If you want to change a parameter setting, enter “Y” (for “Yes”) when prompted.

Changes to parameters are made by editing the setting through the use of the **Backspace** key. If an unrecognized value is entered, the correct entry options will be displayed.

Note

Changes are not saved on the Jetdirect print server until you exit a menu and, when prompted, choose to save your changes.

Figure 3.1 Example: Using the Menu Interface



To edit these parameters, enter Y. Use the **Backspace** key to edit the parameters.

Changes are not saved until you save them when you exit the session.

Using Telnet to Erase the Existing IP Settings

To erase the IP address during a Telnet session, use the following command line entries:

1. Type `cold-reset`, then press **Enter**.
2. Type `quit`, then press **Enter** to exit Telnet.
3. Power the print server off/on.

Note

This procedure resets all TCP/IP parameters, but only affects the TCP/IP subsystem. Parameters for other subsystems such as IPX/SPX or AppleTalk are not affected.

To reset all parameters to factory default values, refer to [Chapter 8](#).

Using the Embedded Web Server

You can set IP parameters on HP Jetdirect print servers that support the embedded Web server. For more information, refer to [Chapter 4](#).

Using the Printer Control Panel

When supported by the printer, HP Jetdirect internal print servers provide a configuration menu that can be accessed from the printer's control panel. Using this menu, you can enable or disable network protocols and set basic network parameters.

Note For instructions on using the control panel for your printer, refer to your printer documentation.

When accessing the HP Jetdirect menu from the printer's control panel, you can set the following TCP/IP network configuration parameters:

- IP host name
- DHCP lease behavior (release or renew)
- IP address of the print server
- Subnet mask
- Default gateway address
- Syslog server address
- Idle timeout period

If you need to configure more TCP/IP parameters than allowed by control panel configuration, use an alternate configuration tool (such as Telnet or the embedded Web server) as described in this chapter.

If the HP Jetdirect print server is configured with TCP/IP parameters from the printer control panel, the configuration is saved on the print server when powered off/on.

Moving to Another Network

Note

For HP Jetdirect *wireless* print servers, this section assumes that a wireless connection to your network has been established.

Moving an HP Jetdirect wireless print server to another network will require a new wireless connection to that network.

When moving an HP Jetdirect print server that is configured with an IP address to a new network, make sure that the IP address does not conflict with addresses on the new network. You may change the IP address of the print server to one that can be used on the new network, or erase the current IP address and configure another address after it is installed on the new network. See [Chapter 8](#), “[Troubleshooting the HP Jetdirect Print Server](#),” for instructions to reset the print server to factory default settings.

If the current BOOTP server is not reachable, you may need to locate a different BOOTP server and configure the printer to this server.

If the print server was configured using BOOTP, DHCP or RARP, edit the appropriate system files with updated settings. If the IP address was manually set (for example, from the printer control panel or Telnet), reconfigure IP parameters as described in this chapter.

Using the Embedded Web Server

Introduction

HP Jetdirect print servers contain an embedded Web server that can be accessed from a compatible Web browser over an intranet. The embedded Web server provides access to configuration and management pages for the HP Jetdirect print server and the attached network device (such as a printer or multifunction, all-in-one device).

Tabs across the upper portion of your browser window provide access to device and networking pages. The tabs and functions displayed will vary depending on the capabilities of the device and the HP Jetdirect print server firmware version:

- If the attached device can serve up its own Web pages, then the available tabs and functions provided by the device are displayed, along with a **Networking** tab served by the Jetdirect print server. For a description of the device pages, see the embedded Web server documentation supplied with your printer or MFP device.
- If Web pages for the attached device are not available, then the Jetdirect print server provides two tabs: **Home** and **Networking**.

Typical **Home** and **Networking** tabs served by the HP Jetdirect print server are illustrated in [Figure 4.1](#) and [Figure 4.2](#), respectively. For more information, see the “[HP Jetdirect Home Tab](#)” and the “[Networking Tab](#)”.

[HP Jetdirect Home Tab](#)




Figure 4.1 Typical HP Jetdirect Home Tab

[Networking Tab](#)

Menu items in left margin




Figure 4.2 HP Jetdirect Networking Tab

For network parameter descriptions, see “[Networking Tab](#)”.

Requirements

Compatible Web Browsers

To access the embedded Web server, you must use a compatible Web browser. In general, the embedded Web server can be used with Web browsers that support HTML 4.01 and cascading style sheets.

Hewlett-Packard tests a number of current and older browsers using a variety of systems. In general, we recommend using the following browsers:

- Microsoft Internet Explorer 5.0 or greater
- Netscape Navigator 6.0 or greater

Browser Exceptions

Due to known problems experienced during testing, we recommend that you do not use the following browsers:

- Netscape Navigator 6.2.x with SSL

Supported HP Web Jetadmin Version

HP Web Jetadmin is a browser-based, enterprise management tool for network devices. It is available from HP online support at the following URL:

<http://www.hp.com/go/webjetadmin>

To make use of improved security features, HP Web Jetadmin version 7.8 or greater is recommended for operation with the HP Jetdirect embedded Web server. Using HP Web Jetadmin, you can enable the SNMP v3 agent and seamlessly create an SNMP v3 account on the print server.

A link to HP Web Jetadmin will be displayed on the embedded Web server if HP Web Jetadmin has discovered this device through an Integration URL.

Currently, browser support between HP Web Jetadmin and the embedded Web server may differ. For supported browsers with HP Web Jetadmin, visit <http://www.hp.com/go/webjetadmin>.

Viewing the Embedded Web Server

Note

For HP Jetdirect *wireless* print servers, this section assumes that a wireless connection to your network has been established.

If a wireless network connection has not yet been established, you can use the embedded Web server to configure the HP Jetdirect wireless print server with wireless settings for your network.

Before you can use the embedded Web server, the HP Jetdirect print server must be configured with an IP address. For a description of an IP address and an overview of TCP/IP networking, see [Appendix A](#).

There are many ways to configure an IP address on the print server. For example, you can automatically configure IP parameters over the network using BOOTP (Bootstrap Protocol) or DHCP (Dynamic Host Configuration Protocol) each time the print server is turned on. Or, you can manually configure IP parameters using the printer's control panel (for selected printers with internal print servers), Telnet, the “arp” and “ping” commands, HP Web Jetadmin or other management software. For more information on TCP/IP configuration options, see [Chapter 3](#).

When powered on, an HP Jetdirect print server that is unable to retrieve a valid IP address from the network will automatically assign itself either a legacy default IP address 192.0.0.192 or a link-local address in the range 169.254.1.0 to 169.254.254.255. The IP address configured on your print server can be determined by inspecting the Jetdirect configuration page for the print server. See [Chapter 3](#) for more information.

If the legacy default IP address 192.0.0.192 has been assigned, you must temporarily set up your computer with the same IP network number or establish a route to the print server before you can gain access to the embedded Web server.

To access the embedded Web server, perform the following steps:

1. Run a supported Web browser.
2. Enter the IP address of the print server as the URL.




Figure 4.3 Entering the IP Address

3. If prompted with security alerts, click **Yes** to proceed.

For initial access, the embedded Web server uses standard HTTP. However, it can be configured to appear as a secure site, using an X.509-compliant certificate installed on the print server for identification. When properly configured, encrypted browser communications through HTTPS (secure HTTP) may be used for secure access.

Although not recommended, you can use your **Internet Options** menu to configure your browser to ignore security warnings if the print server is configured to operate through HTTPS. See [Mgmt. Protocols](#).

4. An embedded Web server page will be displayed, either the Home page of the HP Jetdirect print server or a device page served by the device.

Operating Notes

- If you enter or change a configuration parameter value, click **Apply** to enable your change, or click **Cancel** to erase your change.
- Changes to the IP address will close the connection to the embedded Web server. To re-establish a connection, use the new IP address.

CAUTION

Changes to the IP address on the HP Jetdirect print server may result in printing failures for clients that have been configured to print to this printer using the previous IP address.

-
- The embedded Web server provides access to wireless network connection parameters on HP Jetdirect wireless print servers.

CAUTION

If you change the wireless network settings, you may lose your connection. To reconnect, you may need to adjust your system to the new settings.

If the print server loses its network connection, you may need to reset it to a factory-default state and reinstall it.

-
- Features and configuration parameters not supported by value-based print servers, such as HP ew2400, will not appear.
 - Novell NetWare networks: On the **Network Settings** page, use the **IPX/SPX** tab to configure Novell Directory Services (NDS) Queue Server mode parameters. Note that the embedded Web server cannot create NDS objects (print server, printer, and print queue objects) on the Novell server. To create these objects, use a Novell NetWare utility, such as NWAdmin, or configure the IPX/SPX stack for NDS through HP utilities, such as HP Web Jetadmin.

HP Jetdirect Home Tab

The **Home** tab will display the HP Jetdirect home page if a Web server in the attached device cannot be accessed or does not exist. The HP Jetdirect home page displays a generic printer graphic to represent the attached device. The HP Jetdirect print server's product model, firmware version, and network addresses are displayed along with any device information that can be retrieved. [Table 4.1](#) provides a summary of the items displayed on the HP Jetdirect home page.

Table 4.1 HP Jetdirect Home Page Items (1 of 2)

Item	Description
Home tab	Displays the Jetdirect Home page. This tab will not appear if Web pages served by the attached device can be accessed.
<Device Tabs>	Various device tabs may appear if the attached network device (such as the printer or multifunction all-in-one device) contains a supported embedded Web server. Device tabs provide access to the Web pages served by the device.
Networking tab	Provides access to network configuration, security, and diagnostic parameters. For more information, see Networking Tab .
Device Info	Identifies the device (such as the model name of the printer or multifunction all-in-one device) connected to the network through the HP Jetdirect print server. Other information that can be retrieved from the device are also displayed (such as Page Count, or Control Panel status). The information will vary depending on the features of the attached device.
Select Language	Appears if the HP Jetdirect Web pages support multiple languages. Supported languages may also be selected through language preference settings in your browser. To display supported non-English languages, the use of cookies must be enabled in your browser settings.
Scan	Runs the Web Scan server on the HP Jetdirect print server if it supports the attached network device and is enabled. Web Scan allows you to perform a simple scan from the device using your Web browser. A scan-to-email configuration option is provided.

Table 4.1 HP Jetdirect Home Page Items (2 of 2)

Item	Description
Host Name	Specifies the IP host name assigned to the device and stored on the HP Jetdirect print server. See TCP/IP on the Networking Tab .
System Up Time	The length of time since either the HP Jetdirect print server or the network device was last powered off/on.
System Contact	A text string (stored on the HP Jetdirect print server) for the name of a person to contact for this device. See TCP/IP on the Networking Tab .
System Location	A text string (stored on the HP Jetdirect print server) that identifies the physical location of this device. See the Networking TCP/IP configuration pages.
HP Jetdirect	The product number of the HP Jetdirect print server (for example HP J7934A).
Firmware Version	The version of the operating instructions installed on the HP Jetdirect print server.
IP Address	The Internet Protocol address configured on the HP Jetdirect print server. For general information on IP addresses, see Appendix A .
Hardware Address	The LAN hardware (or MAC, Media Access Control) address of the HP Jetdirect print server. This unique address is assigned by Hewlett-Packard, but can be locally administered.
LAA	A Locally Administered Address (LAA) that replaces the LAN Hardware (MAC) address. The LAA may be configured under local control by a network administrator. By default, the LAA is the factory-assigned LAN Hardware address.
Admin Password	<p>Specifies whether or not an administrator password has been set. This password may also be configured through a Telnet session with the HP Jetdirect print server, or from HP Web Jetadmin.</p> <p>(EIO print servers only) Because passwords are synchronized with selected printers, the password may have also been set through printer security Web pages. Use the Admin Password page to set or clear administrator passwords.</p> <p>If an administrator password has been set, you will be prompted for a User Name and Password to access network parameters. For more information, click Help, or see the Admin. Account section in this guide.</p>

Networking Tab

The **Networking** tab provides access to HP Jetdirect network configuration parameters and status. The menu items in the left margin provide access to configuration and status pages.

Table 4.2 Networking Menu Items

CONFIGURATION section	
<ul style="list-style-type: none">● Network Settings● Other Settings	<ul style="list-style-type: none">● Privacy Settings● Select Language
SECURITY section	
<ul style="list-style-type: none">● Settings● Authorization	<ul style="list-style-type: none">● Mgmt. Protocols● Wireless● 802.1x Authentication
DIAGNOSTICS section	
<ul style="list-style-type: none">● Network Statistics● Protocol Info	<ul style="list-style-type: none">● Configuration Page

Sending Product Information to HP

The first time that you access the **Networking** tab in the embedded Web server, you will be prompted to allow the sending of product information to HP using the Internet. Product identification and usage data collected by HP will be used to improve product features and services. Personal data is not collected in accordance with HP privacy policies. See [Hewlett-Packard Online Privacy Statement](#).

If you choose to decline by pressing **No**, a log entry to record this choice may be sent to HP. To prevent HP from making a log entry that data collection was refused, do one of the following:

- Disable access to the Internet before pressing **No**.

You can disable Internet access on your browser, for example, by disabling the Web Proxy server. After pressing **No**, simply re-enable Internet access.

- Use Telnet to disable this functionality before pressing **No**.
 - a. Telnet to the IP address of the Jetdirect print server.
 - b. If prompted for a user name and password, enter “Admin” for the user name. Then enter the password assigned to the print server.
 - c. Enter the following Telnet command
“phone-home-config: 0”
 - d. To exit and save your settings, enter the command “quit”. The Telnet program will ask if you wish to save this information. Be sure to type “Y” for Yes.
- Use an SNMP management utility or an SNMP command line utility to disable this functionality before pressing **No**. The object identifier (OID) is .1.3.6.1.4.1.11.2.4.3.7.31.0 and needs to be set to zero (0).

You can choose to enable or disable this feature at any time using the **Privacy Settings** page under the **Networking** tab.

Network Settings

The **Network Settings** pages allow you to set or change configuration parameters for [802.11 \(Wireless Ethernet\)](#), [TCP/IP](#), [IPX/SPX](#), [AppleTalk](#), [DLC/LLC](#), and [SNMP](#) protocols. To assign a parameter setting, enter the desired value and click **Apply**.

802.11 (Wireless Ethernet)

Note HP Jetdirect ew2400 wired/wireless print servers may be used in a wired or wireless networking environment. To specify the connection type, see [Network Connection](#) on the [Misc. Settings](#) page.

The 802.11 pages allow you to create or change your wireless network configuration parameters for your IEEE 802.11 wireless ethernet connection. In addition, you may also configure basic TCP/IP settings at the same time.

The configuration parameters are summarized in [Table 4.3](#).

The **802.11** tab displays a single, static page that contains all wireless configuration parameters required to make a wireless

connection to your network. Click **Apply** to set, or **Cancel** to ignore, your configuration entries. To reset to factory-default values, click **Reset to defaults**.

Alternatively, you may choose to click the **Use Wizard** button at the top of the **802.11** page to configure your wireless network connection. This button will launch a configuration wizard that will guide you through the required 802.11 wireless configuration parameters and, depending on your choices, will bypass unnecessary parameters.

Note

If you improperly exit the wizard (for example, by failing to use the Cancel button), an *Operation Failed* screen may appear. If so, wait approximately two minutes before entering the wizard again.

Note

An HP Jetdirect wireless print server with factory-default settings (Ad Hoc mode) may be easily accessed by unauthorized clients. Therefore, it should not be powered on with factory-default settings longer than necessary, and any configuration changes that you make should be verified.

Table 4.3 802.11 Configuration Parameters (1 of 4)

Item	Description
Ad Hoc (peer-to-peer)	<p>“Ad Hoc” (or peer-to-peer) is a wireless communication topology in which the wireless devices on a network communicate directly with each other. Access Points are not used. Other terms used for Ad Hoc mode include Independent Basic Service Set (IBSS), and “computer-to-computer” mode.</p> <p>The factory-default mode configured on the HP Jetdirect print server is Ad Hoc. To initially communicate with the print server, your wireless computer must be set up for Ad Hoc mode.</p>
Channel	<p>(Ad Hoc mode only) The channel selection identifies the radio frequency that the print server will use to broadcast its availability if it fails to associate with the specified Ad Hoc network on any channel.</p> <p>By factory default, channel 11 (2462 MHz) will be used. However, channel 10 (2457 MHz) is also available.</p>
Infrastructure	<p>“Infrastructure” is a wireless communication topology in which communications to and from each wireless network device go through an Access Point. An Access Point is a device, like a gateway or Base Station, that receives and forwards wireless communications to other network devices. Typically, an Access Point connects wireless devices to a cabled network.</p> <p>Infrastructure mode is the preferred topology for large networks.</p> <p>Other terms used for Infrastructure mode include Basic Service Set (BSS), “star topology”, and “enterprise mode”.</p>
Select Network Name (SSID)	<p>Specify or select the name of the wireless network to which the HP Jetdirect print server will connect. The Network Name is also called the SSID (Service Set Identifier) and identifies the ESS (Extended Service Set) that is normally associated with larger Infrastructure Mode networks. The print server will list detected SSIDs.</p> <p>An empty (or “blank”) SSID field is accepted, for example, on networks that rely on signal strength, encryption and authentication methods to control network access.</p> <p>The factory-default SSID configured on the HP Jetdirect print server is “hpsetup”. To initially communicate with the print server, your wireless computer’s SSID must also be “hpsetup”. (Note: the SSID characters are case-sensitive. Be sure to use the appropriate lower- or uppercase characters.)</p>
Refresh	<p>Click this button to refresh the list of network names detected by the print server.</p>

Table 4.3 802.11 Configuration Parameters (2 of 4)

Item	Description
Open System	(No authentication) Select this authentication method if your wireless network does not require device authentication or security to access the network. However, your network may still use WEP encryption keys for data privacy.
Shared Key	(Requires a WEP key) Select this authentication method if each device on your wireless network uses a shared encryption key (that is, a shared "password" value) for network access and communications. Each device on the network must use the same key. The HP Jetdirect print server supports IEEE 802.11 Wired Equivalent Privacy (WEP) keys for encrypted network communications. If you select Shared Key authentication, you must configure one or more WEP keys.
WPA-PSK	Select Wi-Fi Protected Access Pre-Shared Key (WPA-PSK) for advanced authentication. WPA-PSK is typically for small networks where authentication servers are not used. If WPA-PSK authentication is selected, you will need to enter a network pass-phrase that is used to generate the pre-shared key for your network. In addition, you will need to select dynamic encryption.
Pass-phrase	Enter a network pass-phrase that will be used to generate the pre-shared key for WPA-PSK authentication on your network. A pass-phrase must be from 8 to 63 ASCII characters in the hexadecimal range 21 through 7E (characters 0-9, a-z, A-Z and numerous special characters including !, @, #, \$, %, ^, &, (,), _, +, =, -, {, }, [,], \, /, ", <, >, ?, " , ' , ~).
Disabled (No encryption)	Select Disabled if your wireless network does not use encryption keys for network access or communications.
Dynamic	(WPA-PSK authentication only) When configured for WPA-PSK authentication, the print server must use dynamic WPA encryption protocols.

Table 4.3 802.11 Configuration Parameters (3 of 4)

Item	Description
Static (WEP)	<p>Select Static (WEP) if your wireless network uses WEP (Wired Equivalent Privacy) keys for basic access control and data privacy. Under the control of your network administrator, each wireless device on the network must be configured with the same key.</p> <p>Encrypt transmit data using: Select the current active key.</p> <p>The HP Jetdirect print server can store up to four WEP keys using four key positions (Key 1, 2, 3, 4). But there can be only a single active key for a given network (or SSID) at a time. Key 1 is the default active key.</p> <p>Note: When you enter WEP keys, be sure to enter them in the key positions (or fields) that match other wireless devices on your network. For example, if other devices on your wireless network are using a WEP key in the Key 2 position as the active key, then you must also enter this WEP key in the Key 2 field on the Jetdirect print server and select Key 2 as the active key. The different key positions will have different encryption and decryption results.</p> <p>The HP Jetdirect wireless print server supports WEP keys for 40/64-bit and 104/128-bit encryption. To enter one or more WEP keys:</p> <p>Input keys in: Select whether you'll use alphanumeric characters or hexadecimal digits to specify WEP keys.</p> <p>Select Alphanumeric to enter your WEP keys using alphanumeric ASCII (8-bit) characters. Alphanumeric characters are limited to 0 through 9, a through z, A through Z. (Note: Alphanumeric characters are case-sensitive. Entering lower- or uppercase characters, 'a - z' or 'A - Z', will result in different WEP key values.)</p> <p>Select Hexadecimal to enter hexadecimal (4-bit) digits. Hexadecimal digits may be 0 through 9, a through f, A through F. (Note: Hexadecimal digits are not case-sensitive. Entering lower- or uppercase values, 'a - f' or 'A - F', will result in the same WEP key value.)</p> <p>All keys entered must be of the same length, either for 40/64-bit or 104/128-bit encryption. In each Key field, enter your 5 alphanumeric characters or 10 hexadecimal digits (40 bits) for "64-bit" encryption, or 13 alphanumeric characters or 26 hexadecimal digits (104 bits) for "128-bit" encryption. (Note: In both cases, 24 "Initialization Vector" bits are automatically added.)</p>

Table 4.3 802.11 Configuration Parameters (4 of 4)

Item	Description
TCP/IP settings	<p>To minimize reconnections to the print server for initial network configuration, the 802.11 page allows you to configure the following basic TCP/IP settings at the same time that you configure your wireless connection settings:</p> <ul style="list-style-type: none">● IP Configuration Method● IP address● Subnet Mask● Default Gateway <p>For a description of these parameters, see TCP/IP below.</p>

TCP/IP

The **TCP/IP** page provides configuration parameters summarized in [Table 4.4](#).

Table 4.4 TCP/IP Settings (1 of 3)

Item	Description
IP Configuration Method	<p>Selects the method that the HP Jetdirect print server will use for its IP configuration parameters: BOOTP (default), DHCP, Manual, or Auto IP.</p> <p>For BOOTP or DHCP, the IP parameters will be automatically configured by a BOOTP or DHCP server each time the print server is powered on.</p> <p>If you select Manual, then basic IP parameters can be manually entered using this Web page, or using other available tools.</p> <p>If you select Auto IP, then a unique link-local address 169.254.x.x will be assigned.</p> <p>For more information, see Chapter 3.</p>
Host Name	<p>Specifies a readable IP name (the SNMP SysName object) for the network device. The name must start with a letter and can end in a letter or number, up to 32 ASCII characters. The default name is NPIxxxxxx, where xxxxxx is the last six digits of the LAN hardware (MAC) address.</p>
IP Address	<p>Use this field to manually assign the Internet Protocol address on the HP Jetdirect print server. The IP address is a four byte (32-bit) address in the form "n.n.n.n", where 'n' is a number from 0 to 255. An IP address uniquely identifies a node on a TCP/IP network. Duplicate IP addresses on a TCP/IP network are not allowed. For more information on IP addresses, see Appendix A.</p>

Table 4.4 TCP/IP Settings (2 of 3)

Item	Description
Subnet Mask	If subnetting is used, use this field to manually assign a subnet mask. A subnet mask is a 32-bit number that, when applied to an IP address, determines which bits specify the network and subnet, and which bits uniquely specify the node. For more information on subnet masks, see Appendix A .
Default Gateway	Identifies the IP address of a router or computer that is used to connect to other networks or subnetworks.
Domain Name	Specifies the name of the Domain Name System (DNS) domain that the HP Jetdirect print server resides in (for example, support.hp.com). It does not include the host name; it is not the Fully Qualified Domain Name (such as printer1.support.hp.com).
Primary WINS Server	Specifies the IP address of the primary Windows Internet Naming Service (WINS) server. The WINS server provides IP address and name resolution services for network computers and devices.
Secondary WINS Server	Specifies the IP Address to be used for WINS if the primary WINS Server is unavailable.
Syslog Server	Specifies the IP address of a host computer that is configured to receive syslog messages from the HP Jetdirect print server. If a Syslog Server is not specified, syslog messages are disabled. For more information, see Appendix A .
Syslog Maximum Messages	Specifies the maximum number of syslog messages that can be sent by the HP Jetdirect print server on a per-minute basis. This setting allows administrators to control the log file size. The default is 10 per minute. If set to zero, no maximum number is defined.
Syslog Priority	Controls the filtering of syslog messages that are sent to the syslog server. The filter range is 0 to 8, with 0 being the most specific and 8 being the most general. Only messages that are lower than the filter level specified (that is, higher in priority) are reported. The default value is 8 which reports all syslog messages. A value of zero effectively disables syslog reporting.
Idle Timeout	Specifies the number of seconds that an idle connection is allowed to remain open. Up to 3600 seconds can be set. 270 is the default value. If set to 0, the timeout is disabled and TCP/IP connections will remain open until closed by the device at the other end of the network (for example, a workstation).

Table 4.4 TCP/IP Settings (3 of 3)

Item	Description
TTL/SLP	<p>Specifies the IP multicast Time To Live (TTL) discovery setting for Service Location Protocol (SLP) packets. The default value is 4 hops (the number of routers from the local network). The range is 1-15. If set to -1, multicast capability is disabled.</p> <p>For print servers configured for Auto IP (link-local) addresses, this field will be ignored. TTL on outbound packets will always be set to 255 and limited to the link-local network.</p>
System Contact	<p>Identifies a person who is assigned to administer or service this device. This field may include a phone number or similar information.</p> <p>When configured, this parameter will be displayed on the HP Jetdirect home page.</p>
System Location	<p>Specifies the physical location of the device or related information. Only printable ASCII characters are allowed, up to 64 characters.</p> <p>When configured, this parameter will be displayed on the HP Jetdirect home page.</p>
Banner Page	<p>Specifies whether to enable or disable printing of an LPD banner page for print jobs. For currently supported print servers, only a single port is available (Port 1).</p>
Default IP	<p>Specifies the IP address to use when the print server is unable to obtain an IP address from the network during a forced TCP/IP reconfiguration (for example, when manually configured to use BOOTP/DHCP).</p> <p>LEGACY_DEFAULT_IP: sets the legacy default IP address 192.0.0.192.</p> <p>AUTO_IP: sets a link-local IP address 169.254.x.x.</p> <p>The initial setting is determined by the IP address obtained when first powered on.</p>
Send DHCP requests	<p>A checkbox is used to specify whether DHCP requests will be periodically transmitted when a legacy default IP address 192.0.0.192 or link-local IP address 169.254.x.x has been automatically assigned.</p> <p>Clear the checkbox to disable DHCP requests.</p> <p>Check the checkbox (default) to enable DHCP requests.</p>

IPX/SPX

The **IPX/SPX** tab allows you to configure IPX/SPX (Internet Packet Exchange/Sequenced Packet Exchange) parameters on the HP Jetdirect print server for operation on a Novell NetWare or IPX/SPX-compatible network (such as a Microsoft network). See [Table 4.5](#) for a description of items on this page.

CAUTION If you are using direct-mode printing over IPX/SPX on a Microsoft network, **do not** disable IPX/SPX.

For a Novell NetWare network:

- The embedded Web server may be used to select Queue Server Mode parameters in a Novell Directory Services (NDS) environment.
- You cannot create the NDS print server, printer, and queue objects using the embedded Web server. To create these objects, use other available tools or utilities.

Table 4.5 IPX/SPX Settings (1 of 2)

Item	Description
IPX/SPX Enable	Enables or disables the IPX/SPX protocols on the HP Jetdirect print server. If the checkbox is empty, IPX/SPX is disabled.
IPX/SPX Frame Type	<p>Specify the IPX/SPX frame type to be used by the HP Jetdirect print server on your network. After a frame type has been configured, all others will be counted and discarded.</p> <ul style="list-style-type: none">● AUTO (default) senses all frame types and configures the first one detected.● EN_8023 limits the frame type to IPX over IEEE 802.3 frames.● EN_II limits the frame type to IPX over Ethernet frames.● EN_8022 limits the frame type to IPX over IEEE 802.2 with IEEE 802.3 frames.● EN_SNAP limits the frame type to IPX over SNAP with IEEE 802.3 frames.

Table 4.5 IPX/SPX Settings (2 of 2)

Item	Description
SAP Interval	Specifies the time interval (in seconds) that the HP Jetdirect print server waits to send Service Advertising Protocol (SAP) messages, which are broadcast to advertise its service capabilities on a Novell NetWare network. To disable SAP messages, use the value "0".
Print Server Name	Specify a NetWare printer name for the HP Jetdirect print server (alphanumeric characters only). The default name is NPIxxxxxx, where xxxxxx are the last six digits of the HP Jetdirect print server's LAN hardware (MAC) address.
NDS Tree Name	Specify the name of the NDS tree for this device. The NDS (Novell Directory Services) tree name refers to the name of the organizational tree used by your network. To disable NDS support, leave this field blank.
NDS Context	<p>The print server's NDS context refers to the NDS container or organizational unit that contains the print server object. Print queue and device objects can be located anywhere within the NDS tree, but the HP Jetdirect print server must be configured with the fully-qualified print server object name.</p> <p>For example, if the print server object is found in the container "marketing.mytown.lj", the fully qualified print server context name (CN) is: "OU=marketing.OU=mytown.O=lj"</p> <p>(where OU is an Organization Unit container and O is an Organization container within the NDS tree). The print server will also accept "marketing.mytown.lj".</p> <p>To disable NDS support, leave this field blank.</p> <p>Note: NDS objects cannot be created by the embedded Web server.</p>
Job Poll Interval	Specifies the time interval (seconds) that the HP Jetdirect print server will wait to check for print jobs in a print queue.
PJL Configuration	<p>For Printer Job Language (PJM) parameters, enable (check) or disable (clear) the parameters provided:</p> <ul style="list-style-type: none">● Banner Page (for printing separator pages between print jobs)● End-Of-Job Notification (if received from the printer, an end-of-job message will be forwarded to a client application)● Toner Low Notification (if received from the printer, the HP Jetdirect print server will forward a "toner low" message to a client application)

AppleTalk

The **AppleTalk** tab allows you to configure selected AppleTalk settings on the HP Jetdirect print server. See [Table 4.6](#) for a description of items on this page.

Note

The AppleTalk parameters displayed include the AppleTalk printer types that are advertised on the network.

The HP Jetdirect print server supports AppleTalk Phase 2 only.

Table 4.6 AppleTalk Settings

Item	Description
AppleTalk Enable checkbox	Enable (check) or disable (clear) the AppleTalk protocol on the print server. If AppleTalk is enabled, AppleTalk parameters stored on the print server are displayed.
Device (AppleTalk) Name	Specify the name of the printer on the AppleTalk network. If you enter a name that is already assigned on your network, the AppleTalk name specified on the Jetdirect configuration page will be followed by a number to indicate that it is a duplicate.
Print Type	Identify the type of printer being advertised on the network. Up to two types can be displayed (for example, HP LaserJet and LaserWriter).
Zone	Select an available AppleTalk network zone for the printer. By default, the zone currently selected will be displayed. Click the Refresh selected zone Info button to refresh the list of available zones.

DLC/LLC

Using the checkbox provided, you can enable (check) or disable (clear) the DLC/LLC (Data Link Control/Logical Link Control) protocols on the HP Jetdirect print server. If the checkbox is clear, DLC/LLC protocols are disabled.

SNMP

You can specify or change the SNMP (Simple Network Management Protocol) parameters provided. See [Table 4.7](#).

CAUTION If you use HP Web Jetadmin to manage your devices, you should use HP Web Jetadmin to seamlessly configure SNMP v3 and other security settings on the print server.

Using the embedded Web server to create the SNMP v3 account will erase any existing SNMP v3 accounts. In addition, the SNMP v3 account information will need to be implemented on the SNMP management application. For more information, see [SNMP v3](#).

Table 4.7 SNMP Settings (1 of 2)

Item	Description
Enable SNMPv1/v2 read-write access	<p>This option enables the SNMP v1/v2c agents on the print server. Custom community names can be configured to control management access to the print server.</p> <p>An SNMP Set Community Name is a password to be able to configure (or “write”) SNMP information on the HP Jetdirect print server.</p> <p>An SNMP Get Community Name is a password to retrieve (or “read”) SNMP information on the HP Jetdirect print server.</p> <p>An incoming SNMP SetRequest or GetRequest command must contain the appropriate Set or Get community name before the print server will respond.</p> <p>A community name must be ASCII characters and can be up to 255 characters long.</p> <p>The default Get community name is “public”, which can be disabled to restrict access by checking the checkbox provided.</p> <p>Note: If “public” is disabled, some port monitors or discovery utilities may not operate properly.</p>
Enable SNMPv1/v2 read-only access	<p>This option enables the SNMP v1/v2c agents on the print server, but limits access to read-only. Write-access is disabled. The default Get community name “public” is automatically enabled.</p>

Table 4.7 SNMP Settings (2 of 2)

Item	Description
Disable SNMPv1/v2	This option disables the SNMP v1/v2c agents on the print server, which is recommended for secure environments. If SNMP v1/v2c is disabled, some port monitors or discovery utilities may not operate properly.
Enable SNMPv3	<p>(Full-featured HP Jetdirect print servers only) This option enables (check) or disables (clear) the SNMP v3 agent on the print server.</p> <p>When enabled, an SNMP v3 account must be created on the print server, and the account information must be implemented on the SNMP v3 management application. You may create an account by providing the following information:</p> <p>User Name: the SNMP v3 account user name.</p> <p>Authentication Key: a 16-byte hexadecimal value for authenticating the SNMP packet contents using the Message Digest Algorithm 5 (MD5, RFC 1321).</p> <p>Privacy Key: a 16-byte hexadecimal value for encrypting the data portion of the SNMP packet using the Data Encryption Standard (DES) algorithm.</p> <p>Context Name: the view context in which this user can access SNMP objects. It is always "Jetdirect".</p>

Other Settings

This item provides access to a variety of management and printing configuration options. The following tabs are provided:

- [Misc. Settings](#): for enabling miscellaneous advanced protocols and functions
- [Firmware Upgrade](#): to update your HP Jetdirect print server with new features and enhancements (model ew2400 upgrade features are limited and require a wired network connection)
- [LPD Queues](#): for setting up print queues used in printing under LPD (line printer daemon) printing services
- [USB Settings](#): (external print servers only) to configure Universal Serial Bus connection parameters
- [Support Info](#): to set up the **Support** link located under **Other Links** in the left margin
- [Refresh Rate](#): to set the time interval (in seconds) for embedded Web diagnostic page updates

Misc. Settings

The Miscellaneous Settings parameters allow you to set a variety of advanced protocols and features, as described below.

See [Table 4.8](#).

Table 4.8 Miscellaneous Settings (1 of 5)

Item	Description
SLP Config	Enable or disable SLP (Service Location Protocol), used by selected client application software to automatically discover and identify the HP Jetdirect print server.
Telnet Config	Enable or disable access to HP Jetdirect configuration parameters using Telnet. For more information, see Chapter 3 .
mDNS	Enable or disable Multicast Domain Name System (mDNS) services. mDNS is typically used on small networks for IP address and name resolution (through UDP port 5353) where a conventional DNS server is not used.
Multicast IPv4	Enable or disable the receipt and transmission of IP version 4 multicast packets by the print server.
9100 Config	Enable or disable port 9100 services. Port 9100 is an HP-proprietary raw TCP/IP port on the HP Jetdirect print server and is the default port for printing. It is accessed by HP software (for example, the HP Standard Port).
FTP Printing	Enable or disable File Transfer Protocol services available on the HP Jetdirect print server for printing. For more information, see Chapter 6 .
LPD Printing	Enable or disable the Line Printer Daemon services on the HP Jetdirect print server. LPD on the HP Jetdirect print server provides line printer spooling services for TCP/IP systems. For more information, see Chapter 5 .
IPP Printing	Enable or disable the Internet Printing Protocol on the HP Jetdirect print server. If the printer is properly connected and accessible, IPP allows printing to this device over the Internet (or intranet). A properly configured IPP client system is also required. For information on IPP client software, see Chapter 2 .

Table 4.8 Miscellaneous Settings (2 of 5)

Item	Description
Link settings	<p>(For wired 10/100TX networks only) Set the network link speed(10 or 100 Mbps) and communication mode (full- or half-duplex) for HP Jetdirect 10/100TX print servers. The available settings are listed below.</p> <p>CAUTION: If you change the link setting, network communications with the print server and network device may be lost.</p> <ul style="list-style-type: none">● AUTO: (Default) The print server uses autonegotiation to match the network's link speed and communication mode. If autonegotiation fails, 100TXHALF is set.● 10TXFULL: 10 Mbps, full-duplex operation● 10TXHALF: 10 Mbps, half-duplex operation● 100TXFULL: 100 Mbps, full-duplex operation● 100TXHALF: 100 Mbps, half-duplex operation
Network Connection	<p>HP Jetdirect ew2400 wired/wireless print servers support a network connection using either a wired 802.3 port using a network cable, or a wireless 802.11 port. However, only one port can be active at a time. For these print servers, you should specify the active port behavior.</p> <ul style="list-style-type: none">● AUTO (Cable Detect): Automatically detects whether an 802.3 network cable is attached. If a network cable is not attached, only the 802.11 wireless port will be active. However, if a network cable is attached, then only the 802.3 wired port will be active.● Disable Wire: Disables the 802.3 wired port, whether or not a network cable is attached. Only the 802.11 wireless port will be active.● Disable Radio: Disables the 802.11 wireless port. Only the 802.3 wired port will be active.
Primary DNS Server	Specify the IP address of the primary DNS (Domain Name System) server.
Secondary DNS Server	Specify the IP address of a secondary DNS server to use if the primary DNS server is unavailable.
Email (SMTP) Server	Specify the IP address of the preferred outgoing e-mail Simple Mail Transport Protocol (SMTP) server, for use with supported Scan devices.

Table 4.8 Miscellaneous Settings (3 of 5)

Item	Description
Scan Idle Timeout	Specifies the number of seconds that an idle connection for scanning is allowed to remain open. The maximum is 3600, and the default is 300. If set to 0, the timeout is disabled and the connection will remain open until closed by the network system that is accessing the device.
Locally Administered Address	<p>Specifies a locally administered address (LAA) that replaces the factory-assigned LAN Hardware (MAC) address. If LAA is used, a user-specified string of exactly 12 hexadecimal digits must be entered.</p> <p>For Ethernet print servers, the LAA address must start with hexadecimal X2, X6, XA, or XE, where X is any hexadecimal digit 0 through F.</p> <p>The default address is the factory assigned address.</p>
Syslog Facility	Specify the encoded source facility of a message (for example, to identify the source of selected messages during troubleshooting). By default, the HP Jetdirect print server uses LPR as the source facility code, but local user values of local0 through local7 can be used to isolate individual or groups of print servers.
On fatal error	<p>(Supported external print servers only) Specify the print server's action when it detects a fatal error during operation with the attached device:</p> <ul style="list-style-type: none">● Halt (default): The print server's networking operation is suspended. User intervention will be required.● Reboot: The print server will restart, similar to when the printer is powered off/on.
Error page type	<p>(Supported external print servers only) Specify the type of diagnostic page that will automatically print on a fatal error.</p> <ul style="list-style-type: none">● Basic (default): A Default Diagnostic Page will print. It is a single page containing an error summary in user-readable form.● Full: Up to five pages of full diagnostic information will be printed.; These pages will contain detailed status of the print server at the time the error was detected. HP support personnel may be required to interpret the pages.● None: A diagnostic page will not be printed.
Dynamic Raw Port Setting	Allows additional ports to be specified for printing to TCP port 9100. Valid ports are 3000 to 9000, which are application-dependent.

Table 4.8 Miscellaneous Settings (4 of 5)

Item	Description
Disable listening on these ports	<p>For security purposes, two fields allow you to disable services on the printer that use the network. In each field, you must specify the port numbers that are used for network communications with those services. Up to five ports may be specified in each field (for example, [5, 10, 40, 20, 50]). The valid range for port numbers is 1 through 65535.</p> <p>Streams: In this field, enter port numbers of services that pass data streams. Data streams use Transport Control Protocol (TCP) to guarantee data delivery.</p> <p>Datagrams: In this field, enter port numbers of services that pass datagrams. Datagrams, typically used for broadcast messages, use the User Datagram Protocol (UDP), a connectionless protocol where delivery and error recovery are not guaranteed.</p>
Enable MFP and AIO software support	<p>Enable or disable the print server's support of the full-function scanning facility installed on client computers through software supplied with the HP multifunction device (MFP or All-in-One). If disabled, the print server will not allow client software device functions other than network printing.</p> <p>Support for the print server's Web Scan function is controlled separately.</p>
Enable Web Scan	<p>Enable or disable use of basic scanning through the print server's embedded Web Scan feature. The use of Web Scan is independent of the setting for enabling MFP and AIO device software support, described above.</p>
Enable Scan-to-email	<p>Enable or disable scan-to-email support. When this parameter is enabled, you can scan-to-email as well as download or display scanned files.</p> <p>The scan-to-email feature is available only when a mail server is specified. Specify the email server using the Email (SMTP) Server parameter described above.</p>
mDNS Service Name	<p>Specifies an alphanumeric string of up to 64 ASCII characters assigned to this device or service. This name is persistent and is used to resolve a particular device or service if socket information (such as the IP address) changes from session to session. Apple Rendezvous will display this service. The default service name is the printer model and the LAN Hardware (MAC) address.</p>

Table 4.8 Miscellaneous Settings (5 of 5)

Item	Description
mDNS Domain Name	(Read-only parameter) Specifies the mDNS domain name assigned to the device, in the form <host name>.local. If a user-specified host name has not been assigned, the default host name NPIxxxxxx is used, where xxxxxx are the last 6 digits of the LAN hardware (MAC) address.
mDNS Highest Priority Service	<p>Specifies the mDNS highest priority service to use for printing. To set this parameter, choose one of the following printing options:</p> <p>9100 Printing: Raw IP printing through HP-proprietary port 9100.</p> <p>IPP Printing: Internet Printing Protocol printing.</p> <p>LPD Printing (RAW): Default LPD raw queue printing.</p> <p>LPD Printing (TEXT): Default LPD text queue printing.</p> <p>LPD Printing (AUTO): Default LPD auto queue printing.</p> <p>LPD Printing (BINPS): Default LPD binary postscript queue printing.</p> <p>LPD Printing (<user-defined>): Up to 5 user-specified LPD queues will be listed if they have been configured, where <user-defined> is the name of the user-specified LPD print queue.</p> <p>The default selection will depend on the printer, typically 9100 Printing or LPD Printing (BINPS).</p>
Proxy Server	<p>Specifies the proxy server to be used by embedded applications in your printer/MFP. A proxy server is typically used by network clients for Internet access. It caches Web pages, and provides a degree of Internet security, for those clients.</p> <p>To specify a proxy server, enter its IP address or fully-qualified domain name. The name can be up to 64 characters.</p> <p>For some networks, you may need to contact your Independent Service Provider (ISP) for the proxy server address.</p>
Proxy Server Port	Enter the port number used by the proxy server for client support. The port number identifies the port reserved for proxy activity on your network, and can be a value from 0 to 65535.
Proxy Server User Name	If a user account on the proxy server has been set up, enter the name of the user account.
Proxy Server Password	If a user account on the proxy server has been set up, enter the password of the user account.
Proxy Server Exception List	Enter Web addresses, host names, or domain names that do not need to be accessed through the proxy server. Use semicolons (;) to separate entries.

Firmware Upgrade

For print servers that support firmware upgrades, this page allows you to upgrade the print server with new features.

Note HP Jetdirect ew2400 print servers will have limited upgrade capabilities. A network cable must be used. A firmware upgrade through a wireless connection is not supported.

The firmware upgrade file for the print server must be available on your system. To identify and retrieve the appropriate upgrade file, visit HP online support at:

http://www.hp.com/go/webjetadmin_firmware

On that page, do the following:

1. Locate the print server model and the upgrade file.
2. Check the upgrade file version and verify that it is more recent than the print server's installed version. If it is, then download the file. If not, then you do not need to upgrade.

To upgrade the print server using the embedded Web server:

1. Enter the path to the upgrade file or click **Browse** to locate it.
2. Then click **Upgrade Firmware**.

LPD Queues

The **LPD Queues** page allows you to specify LPD (line printer daemon) print queues on the Jetdirect print server. For more information on LPD printing and print queues, see [Chapter 5, "Configuring for LPD Printing"](#).

LPD printing must be enabled on the print server before you can set LPD queues. If LPD is disabled, go to the [Misc. Settings](#) tab to enable it.

If LPD printing is enabled, ten different named print queues are available. Four of these queues are configured automatically and their parameters cannot be changed. The remaining six queues can be defined by the user.

The six user-defined queues can be set up with character strings -- such as job control commands -- that are automatically added before

or after the print job. You can define up to eight named strings, and you can set up each queue so that any of these named strings precedes the print data (“prepend string name”) or follows the print data (“append string name”).

LPD Queue Parameters for setting up LPD queues are described below. See [Table 4.9](#).

Table 4.9 LPD Queue Parameters (1 of 3)

Item	Description
Queue Name	Name of the user-defined queue. This name can be up to 32 characters long, and can consist of any displayable ASCII characters. You can define up to six user-defined queues.
Prepend String Name	<p>Enter the name of one or more strings to be added before (or prepended to) the print data. You specify string names and values in the table at the bottom of the page.</p> <p>To prepend a long string, multiple string names may be concatenated, that is, entered and separated by a “+” character. For example, to prepend a long string that has been divided into two separate strings, enter:</p> <p style="text-align: center;"><stringname1>+<stringname2></p> <p>where stringname1 and stringname2 are specified as two separate string names with different values.</p>
Append String Name	<p>Enter the name of one or more strings to be added after (or appended to) the print data. You specify string names and values in the table at the bottom of the page.</p> <p>To append a long string, multiple string names may be concatenated, that is, entered and separated by a “+” character. For example, to append a long string that has been divided into two separate strings, enter:</p> <p style="text-align: center;"><stringname1>+<stringname2></p> <p>where stringname1 and stringname2 are specified as two separate string names with different values.</p>

Table 4.9 LPD Queue Parameters (2 of 3)

Item	Description
Queue Type	<p>Processing instruction for the queue. Choose from these four queue types:</p> <ul style="list-style-type: none">● RAW -- No processing. The line printer daemon treats the data in a <i>raw</i> queue as a print job that has already been formatted in PCL, PostScript, or HP-GL/2, and sends it to the printer without modification. (Note that any user-defined prepend or append string will be added to the job in the appropriate position.)● TEXT -- Carriage return added. The line printer daemon treats data in <i>text</i> queues as unformatted or ASCII text, and adds a carriage return to each line before sending it to the printer.● AUTO -- Automatic. The line printer daemon uses autosensing to determine whether the print data should be sent as <i>raw</i> or <i>text</i>.● BINPS -- Binary PostScript. This instructs the PostScript interpreter that the printjob is to be interpreted as Binary PostScript data.
Default Queue Name	<p>Name of the queue to be used if the queue specified for a print job is unknown. By default, the Default Queue Name is AUTO.</p>
String Name	<p>Name of a character string. You may define up to eight character strings for use in LPD queues; this parameter names the string, and the <i>Value</i> parameter defines the content of the string. <i>Prepend</i> and <i>Append</i> string names (specified in the table at the top of the browser window) must be chosen from the names specified here. The string name can be up to 32 characters long, and can consist of any displayable ASCII characters.</p>

Table 4.9 LPD Queue Parameters (3 of 3)

Item	Description
Value	<p>The content of the string. The <i>String Name</i> parameter names the string; the <i>Value</i> parameter defines its content. When a string name is specified for a prepend or append string (in the table at the top of the browser window), the line printer daemon sends the value of that string to the printer before or after the print data (as appropriate).</p> <p>Character values can be anywhere in the extended ASCII range of 0 to 255 (hex 00 to FF). You can specify a non-printing character using its hexadecimal value, by entering a backslash followed by two hexadecimal characters. For example, to enter the escape character (hex 1B), type in \1B. If your string includes the backslash character itself, specify it as \5C. The maximum number of characters you can type into this field is 240. The characters in the field are checked for hexadecimal values, converted if necessary, and stored internally. The maximum number of characters stored internally in the string is 80; any characters that exceed this are discarded.</p>

To set up a user-defined print queue, you first define the strings, assign them as prepend or append strings, and define the queue type. Once you have defined an LPD queue, you specify its use by setting up an LPD printer that uses that queue. For instance, if you set up string “a” with a value of “abc” and string “z” with a value of “xyz”, you can define print queue “az_queue” with a prepend string of “a”, an append string of “z”, and a queue type of “raw”. Then, when you send a print job consisting of <formatted_text> through queue az_queue, the job sent to the printer is “abc<formatted_text>xyz”.

Instructions for setting up an LPD printer are different for different operating systems; refer to [Chapter 5, “Configuring for LPD Printing”](#) for details.

Example. If you had an LPD printer and wanted to reset it at the start of each print job, you could set up a user-defined print queue named “clear_printer” that issues a PCL reset command (Escape-E) at the beginning of each job. You could set this up as follows:

First, set up the print queue:

- a. Name a string: Type “reset_string” into the **String Name** field in row 1.
- b. Define the string's value: Type “\1BE” (Escape-E) into the **Value** field in row 1. (Alternatively, you could type “\1B\45”.)
- c. Name the queue: Type “clear_printer” into the **Queue Name** field in row 5.
- d. Set up the prepend string: Type “reset_string” into the **Prepend String** field in row 5.
- e. Leave the **Append String** field in row 5 blank.
- f. Set the queue type: Using the pull-down menu, set the **Queue Type** field in row 5 to “RAW”.

Then, set up the printer to use the queue, making sure to specify “clear_printer” when asked for a queue name. (For details of setting up the printer, refer to [Chapter 5, “Configuring for LPD Printing”](#).) After that, any print jobs sent to the printer -- either from the server or from a client computer that has set up that printer -- will include a reset command at the beginning of the job.

USB Settings

If the HP Jetdirect print server provides a USB connection to the network device (such as a USB printer), a link to USB configuration parameters will be displayed. See [Table 4.10](#).

Table 4.10 USB Settings

USB Item	Description
USB Speed	<p>(Read-only parameter, for USB 2.0 print servers only). Specifies the autonegotiated communication speed over the USB connection between the print server and the device.</p> <ul style="list-style-type: none">● Full Speed: 12 Mb/s/sec as specified in the USB v2.0 specifications, compatible with USB v1.1 specifications.● Hi-Speed: 480 Mb/s/sec for USB v2.0 devices only.● Disconnected: The USB port is not connected.
Desired Communication Mode	<p>Select the highest level of USB communication capabilities when the print server tries to establish a communication level with the printer. If you change the current setting, unplug and then reconnect the USB cable, or power the print server off/on, to activate it.</p> <ul style="list-style-type: none">● Automatic (default): The print server will attempt to set the highest level available, starting with IEEE 1284.4. If not successful, subsequent levels are attempted.● IEEE 1284.4: This level is the highest communication level, and allows multiple channels of simultaneous print, scan, and status communication.● MLC: (Multiple Logical Channels) The next level is MLC, an HP-proprietary protocol that allows multiple channels of simultaneous print, scan, and status communication.● Bidirectional: This level provides basic two-way printer communications. Print data is sent to the printing device, and status information is returned from the printing device.● Unidirectional: This is the lowest communication level and provides one-way printer communication from the print server to the printing device. <p>The communication level set by the print server is reported on the Jetdirect configuration page.</p>
Status Page Language	<p>Select the Page Description Language (PDL) for the Jetdirect configuration page data sent to the printer. Available options include PCL, ASCII, PostScript and HPGL2.</p>

Support Info

Use this page to configure links for Support assistance. You can designate a Support person and phone number of an administrator for this device, as well as URL addresses for Web-based product and technical support.

Refresh Rate

The refresh rate is the time period (in seconds) that the diagnostic pages will be automatically updated. The value '0' disables the refresh rate.

Privacy Settings

On the **Privacy Settings** page, you can allow the embedded Web server to collect product identification and use information and then send the information to HP (Internet access is required). Product use information assists HP in improving product features and services. The default setting for this page will depend on the user's selection on initial access to the Networking tab.

To enable this feature, check the checkbox and click **Apply**.

To disable this feature, clear the checkbox and click **Apply**.

Select Language

This link appears if the HP Jetdirect Web pages support multiple languages. Supported languages may also be selected through language preference settings in your browser (see your browser's Help).

To display supported non-English languages, the use of cookies must be enabled in your browser settings.

Settings

In the **SECURITY** section, the **Settings** menu provides access to the following tabs: **Status** (default), **Wizard**, **Restore Defaults**. The available settings depend on your particular print server model.

Status

The **Status** page displays the current security configuration settings of the print server. The settings that will be displayed depend on the features supported by the print server.

Wizard

Note

If you use HP Web Jetadmin to manage your devices, you should not use this wizard. Instead, use HP Web Jetadmin to configure your network security settings to ensure they are properly set for your network.

The **Wizard** page allows you to run the *HP Jetdirect Security Configuration Wizard*. This wizard will guide you through the print server's security configuration needed for your network. Click **Start Wizard** to run the wizard. This opens the **Security Level** page.

The optional configuration parameters presented by the wizard will depend on your choice of security level. For an overview, see [Table 4.11](#).

Note

If you improperly exit the wizard (for example, by failing to use the Cancel button), an *Operation Failed* screen may appear. If so, wait approximately two minutes before entering the wizard again.

Restore Defaults

This page is used to restore security configuration settings to factory defaults. The default settings displayed depend on the features supported by the print server.

Only the security settings listed are restored to factory defaults, other configuration settings are not affected.

Table 4.11 Wizard Security Levels (1 of 2)

Security Level	Description
Basic Security	<p>This option requires that you configure an administrator password for configuration management. The administrator password is shared with other management tools, such as Telnet and SNMP applications. However, some management tools, such as Telnet, use plain-text communications and are not secure.</p> <p>The Administrator Account page is used to enter the administrator password. The Administrator Password will also be used as the SNMP v1/v2 Set Community Name for SNMP management applications.</p> <p>The Configuration Review page displays all the current settings that may affect security. Click Finish to set your basic security selections.</p>
Enhanced Security (Recommended)	<p>(Full-featured print servers only) This option adds to Basic Security by automatically disabling management protocols that do not use secure, encrypted communications (such as Telnet and FTP firmware updates, RCFG, SNMP v1/v2c). To change individual protocol settings, see Mgmt. Protocols.</p> <p>The Administrator Account page is used to enter the administrator password.</p> <p>SNMP Configuration pages are used to configure specific SNMP settings:</p> <ul style="list-style-type: none"> ● Enable SNMPv3: (Full-featured print servers only) Enable SNMP v3 and create an SNMP v3 account. Creating an SNMP v3 account is not recommended if you manage devices using HP Web Jetadmin. See SNMP. ● Enable SNMPv1/v2 read-only access: Enable this option to allow support of current tools that rely on SNMP v1/v2 for device discovery and status. <p>The Configuration Review page displays all the current settings that may affect security. Click Finish to set your basic security selections.</p>

Table 4.11 Wizard Security Levels (2 of 2)

Security Level	Description
Custom Security	<p>This option proceeds through all available security settings supported by your print server. For more information on specific parameters and selections, see the tabs on the Mgmt. Protocols and Authorization menu pages under SECURITY.</p> <p>The Administrator Account page is used to enter the administrator password.</p> <p>The Web Mgmt. page (for full-featured print servers only) is used for HTTPS (secure HTTP) configuration, including certificates and encryption levels.</p> <p>The Management Tools page allows configuration of management protocols that are not secure (such as RCFG, Telnet and FTP firmware updates).</p> <p>SNMP Configuration pages are used to configure specific SNMP settings:</p> <ul style="list-style-type: none">● Enable SNMPv1/v2: Enable this option to allow management software that use SNMP v1/v2. If selected the SNMPv1/v2 Configuration page is displayed to configure SNMP community names.● Enable SNMPv3: (Full-featured print servers only) Enable this option to create an SNMP v3 account. Creating an SNMP v3 account is not recommended if you manage devices using HP Web Jetadmin. See SNMP. <p>The Access Control page is used to set up an Access Control List, if desired to control host access to the device.</p> <p>The Print Protocols and Services page is used to enable or disable network printing, print services, and device discovery protocols that may affect security.</p> <p>The Configuration Review page displays all the current settings that may affect security. Click Finish to set your basic security selections.</p>

Authorization

The **Authorization** page provides tabs that allow you to control access to the device, as well as to device configuration and management features. In addition, you may configure certificates for client and server authentication.

Admin. Account

Use this page to set an administrator password for controlled access to Jetdirect configuration and status information. The administrator password is shared by Jetdirect configuration tools, such as the embedded Web server, Telnet, and HP Web Jetadmin. In addition, for selected EIO printers, the password is shared with the printer (see [Printer Password Synchronization](#) below).

If a password is set and you attempt to access Jetdirect print server settings, you will be prompted for a user name and *this password* before you are allowed access.

Note	The administrator password may be cleared by a cold reset of the print server, which resets the print server to factory default settings.
-------------	---

A checkbox allows you to synchronize HP Web Jetadmin and the SNMP v1/v2c Set Community Name. If you enable this feature (the checkbox is checked), the administrator password will also be used as the SNMP Set Community Name for SNMP v1/v2c management applications.

Note	If you subsequently change the SNMP Set Community Name (for example, using the SNMP tab on the Network Settings page or from Web Jetadmin), the two settings will no longer be synchronized.
-------------	---

Printer Password Synchronization. Many EIO printers provide password-protected access to printer configuration and status settings. The password is set through security Web pages provided by the printer. For these printers, the administrator password for the printer and the Jetdirect EIO print server are synchronized so that the same password is used to access both printer and networking configuration pages. For printers that support password synchronization, the same password is used regardless of the embedded Web server page (printer **Security** page or networking **Admin. Account** page) in which the password was set.

If password synchronization is lost on these printers, recovery may require one of the following procedures:

- Restore both the printer and the Jetdirect print server to factory-default states (for example, through a cold-reset), and then reconfigure your settings.
- Manually set the same administrator password using both the printer **Security** page and the networking **Admin. Account** page.

Certificates

(Certificate support depends on the print server model) This tab provides access to installation, configuration and management services for X.509 digital certificates. A digital certificate is an electronic message typically containing, among other things, a key (a short string used for encryption and decryption) and a digital signature. Certificates may be issued and signed by a trusted third party (commonly called a Certificate Authority, or CA), which may exist internal or external to the organization. Or certificates may be “self-signed”, which is similar to validating your own identity.

Note

While self-signed certificates are permitted and allow data encryption, they do not ensure valid authentication.

The **Certificates** page provides the status of the certificates installed on the HP Jetdirect print server:

- **Jetdirect certificate.** The Jetdirect certificate is used to validate the identity of the Jetdirect device to clients and to network authentication servers.

By factory default, a self-signed Jetdirect certificate is preinstalled. This allows the embedded Web server to use HTTPS and appear as a secure site when accessed by a Web browser.

Click **View** to view the contents of an installed Jetdirect certificate, or click **Configure** to update or install a new one. See [Configuring Certificates](#).

When installed, a Jetdirect certificate will be saved across a cold-reset, which is used to restore the print server to factory-default values.

- **CA Certificate.** (Full-featured print servers only) A certificate from a trusted third party, or Certificate Authority (CA), is used to validate the identity of a network authentication server during 802.1X authentication methods that use EAP (Extensible Authentication Protocol). The authentication server's identity is validated when information on the CA certificate matches the information on a certificate received from the authentication server.

A CA certificate for the print server is a certificate that was used to sign the authentication server's certificate. Therefore, the Certificate Authority for the authentication server's certificate must also be used for the CA certificate.

Click **View** to view the contents of an installed Jetdirect certificate, or click **Configure** to update or install a new one. See [Configuring Certificates](#).

A CA certificate is not saved when the print server is reset to factory-default values.

The maximum certificate size that can be installed on the HP Jetdirect print server is 3072 bytes.

Configuring Certificates

When you click **Configure**, a certificate management wizard will help you update or install a certificate. The screens displayed will depend on the type of certificate (Jetdirect or CA) and your selections. [Table 4.12](#) provides a description of the screens and configuration parameters that may appear.

Note If you improperly exit Certificates configuration (for example, by failing to use the **Cancel** button), an *Operation Failed* screen may appear. If so, wait approximately two minutes before entering the wizard again.

Table 4.12 Certificate Configuration Screens (1 of 4)

Certificate Options Choose from the options listed.
<p>Update Pre-Installed Certificate. Use this option to update the preinstalled, self-signed certificate. When updated, the preinstalled certificate is overwritten. You may update the following item:</p> <ul style="list-style-type: none">● Certificate Validity Period <p>With self-signed certificates, the browser will identify the certificate as self-signed for each new Web session and may cause a security alert message. This message can be bypassed if the user adds it to their browser's certificate store or disables browser alerts (not recommended).</p> <p>Self-signed certificates are not necessarily secure because the certificate owner is merely confirming his own identity instead of verification by a trusted third party. Certificates from a trusted third party are considered more secure.</p>
<p>Create Certificate Request. Using this option, you are prompted for specific device and organizational information in the following screen:</p> <ul style="list-style-type: none">● Certificate Information <p>This option may be used, for example, when an authentication protocol requires that a Jetdirect certificate issued by a trusted third party or Certificate Authority be installed.</p>
<p>Install Certificate. This option is displayed only if there is a Jetdirect certificate request (to a trusted third party) pending. When received, the certificate is installed using this option. Once installed, this certificate overwrites the preinstalled certificate.</p> <p>Using this option, you are prompted for information in the following screen:</p> <ul style="list-style-type: none">● Install Certificate <p>The certificate to be installed must be associated with a previous certificate request generated by the embedded Web server.</p>

Table 4.12 Certificate Configuration Screens (2 of 4)

<p>Install CA Certificate. (Full-featured print servers only) This option is provided when you click Configure for a CA certificate, which must be installed for selected authentication protocols. Using this option, you are prompted for information in the following screen:</p> <ul style="list-style-type: none">● Install Certificate
<p>Import Certificate and Private Key. This option allows you to import a previously acquired and known certificate as the Jetdirect certificate. If you import a certificate, the currently installed certificate will be overwritten. Using this option, you are prompted by the following screen:</p> <ul style="list-style-type: none">● Import Certificate and Private Key
<p>Export Certificate and Private Key. This option allows you to export the Jetdirect certificate currently installed on the print server for use on other print servers. Using this option, you are prompted by the following screen:</p> <ul style="list-style-type: none">● Export the Jetdirect certificate and private key
<p>Delete CA Certificate. (Full-featured print servers only) This option is used to remove the CA certificate installed on the Jetdirect print server. This option appears when a CA certificate for EAP authentication has been installed.</p> <p>CAUTION: If the CA Certificate is deleted, EAP authentication will be disabled and network access will be denied.</p> <p>The CA Certificate will also be removed on a cold-reset of the print server, where factory-default settings are restored.</p>
<p>Certificate Validity</p> <p>Use this screen to specify how long the Jetdirect self-signed certificate will be valid.</p>
<p>This screen appears only when a self-signed certificate is preinstalled and you click Edit Settings to update the validity period. It specifies the current Coordinated Universal Time (UTC). UTC is a time scale maintained by the International Bureau of Weights and Measures. It adjusts for differences between Greenwich Mean Time and atomic time. It is set at 0 degrees longitude on the prime meridian.</p> <p>The Validity Start Date is calculated from the PC's clock settings.</p> <p>The Validity Period specifies the number of days (1 to 3650) that the certificate is valid, starting from the Validity Start Date. A valid entry (1 to 3650) is required. The default is 5 years.</p>

Table 4.12 Certificate Configuration Screens (3 of 4)

Certificate Information Use this page to enter information for requesting a certificate from a Certificate Authority.
<p>Common Name. (Required)</p> <p>For HP Jetdirect print servers, specify the fully qualified domain name or a valid IP address for the device.</p> <p>Examples:</p> <ul style="list-style-type: none">● Domain Name: <i>myprinter.mydepartment.mycompany.com</i>● IP address: <i>192.168.2.116</i> <p>The Common Name will be used to uniquely identify the device. For HP Jetdirect print servers using EAP authentication, some authentication servers may need to be configured with the Common Name as specified on the certificate.</p> <p>If the default IP address 192.0.0.192 is configured on the Jetdirect print server, it will not likely be valid for your network. You should not use this default address to identify your device.</p>
<p>Organization. (Required) Specify the full legal name for your company.</p>
<p>Organizational Unit. (Optional) Specify your department, division, or other subgroup of your organization.</p>
<p>City/Locality. (Required) Enter the city or locality in which your organization is located.</p>
<p>State/Province. (Required for all countries/regions) Must contain at least three characters. (required)</p>
<p>Country/Region. Two-character ISO 3166 country/region code. For example, use "gb" Great Britain or "us" for USA (required).</p>
<p>Install Certificate, or Install CA Certificate</p> <p>Use the Install Certificate screen to install a Jetdirect certificate.</p> <p>Use the Install CA Certificate screen to install a trusted Certificate Authority (CA) certificate for use during EAP authentication. (Full-featured print servers only)</p>
<p>Install a PEM/Base64 (Privacy Enhanced Mail) encoded certificate.</p> <p>To install a certificate, specify the name and path of the file that contains the certificate. Or, click Browse to browse your system for the file.</p> <p>Click Finish to complete the installation.</p> <p>To install a certificate, it must be associated with a pending certificate request by the embedded Web server. The Install Certificate option will not be presented if there is no pending request.</p> <p>A Jetdirect or CA certificate size is limited to 3 KBytes.</p>

Table 4.12 Certificate Configuration Screens (4 of 4)

Import Certificate and Private Key Use this screen to import a Jetdirect certificate and private key.
<p>Import a Jetdirect certificate and private key. When imported, the existing certificate and private key will be overwritten.</p> <p>The file format must be PKCS#12 encoded (.pfx) and cannot exceed 4 KBytes.</p> <p>To import a certificate and private key, specify the name and path of the file that contains the certificate and private key. Or, click Browse to browse your system for the file. Then enter the password that was used to encrypt the private key.</p> <p>Click Finish to complete the installation.</p>
Export the Jetdirect certificate and private key Use this screen to export the installed Jetdirect certificate and private key to a file.
<p>To export a certificate and private key, enter a password that will be used to encrypt the private key. You must enter the password again to confirm it. Then click Save As to save the certificate and private key in a file on your system. The file format will be PKCS#12 encoded (.pfx).</p>

Access Control

Use this tab to display the Access Control List (ACL) on the HP Jetdirect print server. An access control list (or host access list) specifies individual host systems, or networks of host systems, that will be allowed to access the print server and the attached network device. Up to 10 entries can be included on the list. If the list is empty (no hosts are listed), any supported system can access the print server.

CAUTION

Use caution when using this feature. You may lose your ability to communicate with the HP Jetdirect print server if your system is not properly specified in the list, or access through HTTP is disabled.

For use of the host access list as a security feature, see [Chapter 7](#).

Note

By default, hosts with HTTP connections (for example, through the embedded Web server or IPP -- the Internet Printing Protocol) are allowed access to the print server regardless of access control list entries.

To disable access by HTTP hosts, clear the **Allow Web Server (HTTP) access** checkbox at the bottom of the list.

Host systems are specified by their IP addresses or network number. If the network contains subnets, an address mask may be used to identify whether the IP address designates an individual host system or a group of host systems.

Examples. See the table of sample entries below:

IP Address	Mask	Description
192.0.0.0	255.0.0.0	Allow all hosts with network number 192.
192.1.0.0	255.1.0.0	Allow all hosts on network 192, subnet 1.
192.168.1.2		Allow the host with IP address 192.168.1.2. The mask 255.255.255.255 is assumed and is not required.

To add an entry into the access control list, use the **IP Address** and **Mask** fields to specify a host, and click (check) the **Save** checkbox for that entry. Then click **Apply**.

To delete an entry from the list, clear the **Save** checkbox for that entry. Then click **Apply**.

To clear the entire access control list, clear all **Save** checkboxes, and click **Apply**.

Mgmt. Protocols

This link provides access to management communications and other protocols that affect security.

Web Mgmt.

Use this tab to manage communications with the embedded Web server from Web browsers. This tab appears only for full-featured print servers.

Secure, encrypted Web-based communication is provided through the Secure HTTP (HTTPS) protocol. If configured to require HTTPS, the embedded Web server routes HTTPS communications through port 443, the well-known port for HTTPS traffic. Although ports 80, 280, or 631 continue for Internet Printing Protocol (IPP) use, other non-secure communications (HTTP) are redirected to HTTPS. Redirection of your browser to use HTTPS may be transparent depending on your browser's capabilities.

By factory default, the print servers are configured to allow HTTPS or HTTP.

Although not recommended, you may choose to accept both HTTPS and HTTP communications that are not secure by disabling (clearing) the **Encrypt All Web Communication** checkbox.

To support the use of HTTPS communications, a Jetdirect certificate must be installed. A factory-default, self-signed certificate is preinstalled for initial use. Click the **Configure** button to update the preinstalled certificate, or to install a new one. For more information, see [Configuring Certificates](#).

The minimum encryption strength that will be allowed must be specified when using a Jetdirect certificate. You may select **Low** (default), **Medium**, or **High** encryption strength. For example, selecting **Low** will allow medium or high encryption levels to be used whereas selecting **High** will only allow high encryption levels.

For each encryption strength, ciphers are specified to identify the weakest cipher allowed. Early browsers may only support 40-bit (Low) encryption levels.

Note

Cipher suites support different levels of encryption strength. The cipher suites currently supported for encryption and decryption are DES (Data Encryption Standard, 56-bit), RC4 (40-bit or 128-bit), and 3DES (168-bit).

SNMP

Use this tab to enable or disable SNMP v1, v2c and v3 agents on the print server, depending on the print server model. Value-based print servers (such as ew2400) do not support an SNMP v3 agent. For a description of SNMP selections, see [Table 4.7](#).

SNMP v3. Full-featured HP Jetdirect print servers include an SNMP v3 (Simple Network Management Protocol, version 3) agent, for enhanced SNMP security. The SNMP v3 agent employs a User-based Security Model for SNMP v3 (RFC 2574), which features user-authentication and data privacy through encryption.

The SNMP v3 agent is enabled when an initial SNMP v3 account on the print server is created. Once the account is created, any SNMP management application, if properly configured, can access or disable the account.

CAUTION

If you use HP Web Jetadmin to manage your devices, you should use HP Web Jetadmin to seamlessly configure SNMP v3 and other security settings on the print server.

Using the embedded Web server to create the SNMP v3 account will erase any existing SNMP v3 accounts. In addition, the SNMP v3 account information will need to be implemented on the SNMP management application.

You may create the initial account by specifying the HMAC-MD5 authentication and CBC-DES data privacy encryption keys used by your SNMP v3 management application.

CAUTION

You should disable Telnet and ensure secure embedded Web communications through HTTPS is enabled before creating the initial SNMP v3 account. This will help to prevent access or interception of account information over a connection that is not secure.

SNMP v1 and v2c agents can coexist with the SNMP v3 agent. However, to fully secure SNMP access, you should disable SNMP v1 and v2c.

Other

Use this tab to enable or disable various protocols supported by the print server for printing, print services, and management. See [Table 4.13](#).

Table 4.13 Other Protocols (1 of 2)

Item	Description
Enable Print Protocols	<p>Enable or disable network protocols supported by the print server: IPX/SPX, AppleTalk, DLC/LLC. For example, you should disable unused protocols to prevent printer access using those protocols.</p> <p>For network environments that use these protocols, see Chapter 1.</p> <p>Because it uses TCP/IP, the embedded Web server does not allow disabling TCP/IP.</p>
Enable Print Services	<p>Enable or disable various print services supported by the print server: port 9100, LPD (Line Printer Daemon), IPP (Internet Printing Protocol), FTP (File Transfer Protocol). Disable unused print services to prevent access through those services.</p>
Enable Device Discovery	<p>Enable or disable device discovery protocols supported by the print server:</p> <p>SLP (Service Location Protocol).</p> <p>If enabled (checked), the HP Jetdirect print server sends SLP packets, which are used by system applications for automated discovery and installation.</p> <p>If disabled (cleared), SLP packets are not sent.</p> <p>mDNS (multicast Domain Name System).</p> <p>If enabled (checked), Multicast Domain Name System (mDNS) services are provided. mDNS is typically used on small networks for IP address and name resolution (through UDP port 5353) where a conventional DNS server is not used.</p> <p>Multicast IPv4.</p> <p>If enabled (checked), the print server will send and receive IP version 4 multicast packets.</p>

Table 4.13 Other Protocols (2 of 2)

Item	Description
Enable Management Protocols	<p>Enable or disable Telnet access and the use of FTP to upgrade firmware on the print server. Telnet and FTP are not secure protocols and device passwords may be intercepted.</p> <p>Enable or disable RCFG, a remote IPX configuration protocol used by older management tools to configure Novell NetWare parameters. Disabling RCFG does not affect direct mode printing using IPX/SPX.</p> <p>Disabling Telnet, FTP firmware upgrades, and RCFG is recommended.</p>

802.1x Authentication

(Full-featured print servers only) This page allows you to configure 802.1X authentication settings on the Jetdirect print server as required for client authentication on your network. In addition, you can reset the 802.1X authentication settings to factory-default values.

CAUTION **Use caution when changing the 802.1X authentication settings; you may lose your connection.** If communication with the printer/MFP device is lost, you may need to reset the print server to a factory-default state and then reinstall the device.

For most 802.1X networks, the infrastructure components (such as LAN switches) must use 802.1X protocols to control a port's access to the network. If these ports do not allow partial or guest access, the print server may need to be configured with your 802.1X parameters prior to connection.

To configure initial 802.1X settings before connecting to your network, you can use an isolated LAN, or a direct computer connection using a cross-over cable.

The supported 802.1X authentication protocols and associated configuration depend on the print server model and firmware version. Available configuration settings are listed in [Table 4.14](#).

Table 4.14 802.1X Configuration Settings (1 of 2)

Item	Description
Enable Protocols	<p>Enable (check) the supported protocols used for 802.1X authentication on your network.</p> <ul style="list-style-type: none">● PEAP: (Protected Extensible Authentication Protocol). PEAP uses digital certificates for network server authentication and passwords for client authentication. PEAP requires an EAP User Name, EAP Password, and CA Certificate. Dynamic encryption keys are also used.
User Name	<p>Specify an EAP/802.1X user name (up to 128 characters maximum) for this device. The default user name is the default host name of the print server, NPIxxxxxx, where xxxxxx are the last six digits of the LAN hardware (MAC) address.</p>
Password, Confirm Password	<p>Specify an EAP/802.1X password (up to 128 characters maximum) for this device. Enter the password again in the Confirm Password field to ensure it was properly entered.</p>
Server ID	<p>Specify the Server ID validation string that identifies and validates the authentication server. The Server ID string is specified on the digital certificate issued by a trusted Certificate Authority (CA) for the authentication server. The entry may be a partial string unless the Require Exact Match checkbox is enabled.</p>
Encryption Strength	<p>Specify the minimum encryption strength that can be used during communications with the authentication server. You may select Low, Medium, or High encryption strength. For each encryption strength, ciphers are specified to identify the weakest cipher allowed.</p> <p>Early browsers may only support 40-bit (Low) encryption levels.</p>
CA Certificate	<p>To validate the authentication server's identity, a CA (or "Root") certificate must be installed on the print server. This CA certificate must be issued by the Certificate Authority who signed the authentication server's certificate.</p> <p>To configure or install a CA certificate, click Configure.</p>

Table 4.14 802.1X Configuration Settings (2 of 2)

Item	Description
Authentication Behavior: Reauthenticate on Apply	<p>Enable (check) or disable (clear) this checkbox to control authentication when you click Apply on this page, assuming valid configuration entries have been made.</p> <p>Note: This parameter does not apply to security or other configuration wizards. Changes to parameters through a wizard will always cause the print server to reauthenticate.</p> <p>If disabled (default), the print server will not attempt reauthentication unless configuration changes cause the print server to disconnect and reconnect to the network.</p> <p>If enabled, the print server will always try to reauthenticate using the configuration values set.</p>

Wireless

Use this link to manage secure wireless configuration settings. For the features and parameter settings on this page, see [Table 4.3](#).

Network Statistics

This page is used to display counter values and other status information currently stored on the HP Jetdirect print server. This information is often useful to diagnose performance and operational problems associated with the network or network device.

Protocol Info

This page provides a list of various network configuration settings on the HP Jetdirect print server for each protocol. Use these lists to validate your desired settings.

Configuration Page

This page provides a view of the HP Jetdirect configuration page that contains a summary of HP Jetdirect status and configuration information. The contents of this page are described in [Chapter 9](#).

Other Links

Help

The **Help** page in the **Networking** tab provides a quick summary of the HP Jetdirect embedded Web server features. In the **Help** page, a link to an HP support document containing updated information is provided (Internet access is required).

Support

The information displayed on the **Support** page depends on the values configured in the [Support Info](#) tab in the [Other Settings](#) menu. Support information may include the name and telephone number of a Support person, or Web links to Product and Technical Support pages. The default Web links include HP online support and HP product information Web pages (Internet access is required).

HP Home

HP Home provides a link to Hewlett-Packard's home page on the HP Web site (Internet access is required). This link may also be accessed by clicking on the HP logo.

HP Web Jetadmin

HP Web Jetadmin is HP's premier network peripheral management software tool.

A link to HP Web Jetadmin will be displayed only if HP Web Jetadmin has discovered this device through an "Integration URL". You can then use HP Web Jetadmin to provide enhanced management capabilities for this and other HP Jetdirect-connected devices on your network.

Configuring for LPD Printing

Introduction

The HP Jetdirect print server contains an LPD (Line Printer Daemon) Server module to support LPD printing. This chapter describes how to configure the HP Jetdirect print server for use with various systems that support LPD printing. These instructions include:

- [LPD on UNIX Systems](#)
 - Configuring BSD-based UNIX systems using LPD
 - Configuring print queues using the SAM utility (HP-UX systems)
- [LPD on Windows NT/2000/Server 2003 Systems](#)
- [LPD on Windows XP Systems](#)
- [LPD on Mac OS Systems](#)

Note

For other systems not listed, refer to your operating system documentation and online help.

Recent versions of Novell NetWare (NetWare 5.x with NDPS 2.1 or greater) support LPD printing. For setup instructions and support, refer to the documentation supplied with NetWare. Also, refer to the Technical Information Documentation (TID) on Novell's support Web site.

About LPD

Line Printer Daemon (LPD) refers to the protocol and programs associated with line-printer spooling services that may be installed on various TCP/IP systems.

Some of the widely used systems in which the HP Jetdirect print server functionality supports LPD include:

- Berkeley-based (BSD) UNIX systems
- HP-UX
- Solaris
- IBM AIX
- Linux
- Windows NT/2000
- Mac OS

The UNIX configuration examples in this section show the syntax for BSD-based UNIX systems. The syntax for your system may vary. See your system documentation for the correct syntax.

Note

The LPD functionality can be used with any host implementation of LPD that complies with the RFC 1179 document. The process for configuring printer spoolers, however, may differ. See your system documentation for information on configuring these systems.

The LPD programs and protocol include the following:

Table 5.1 LPD Programs and Protocols

Program Name	Purpose of Program
lpr	Queues jobs for printing
lpq	Displays print queues
lprm	Removes jobs from print queues
lpc	Controls print queues
lpd	Scans and prints the files if the specified printer is connected to the system. If the specified printer is connected to another system, this process forwards the files to an lpd process on the remote system where the files are to be printed.

Requirements for Configuring LPD

Before you can use LPD printing, your printer must be properly connected to the network through the HP Jetdirect print server, and you must have print server status information. This information is listed on the HP Jetdirect printer configuration page. If you have not printed a configuration page from your printer, see your printer documentation for instructions. You must also have the following:

- An operating system that supports LPD printing.
- Superuser (root) or Administrator access to your system.
- The LAN hardware address (or station address) of the print server. This address is printed with print server status information on the HP Jetdirect configuration page and is of the form:

HARDWARE ADDRESS: xxxxxxxxxxxx

where x is a hexadecimal digit (for example, 0001E6123ABC).

- An IP address configured on the HP Jetdirect print server.

LPD Setup Overview

The following steps are necessary to configure the HP Jetdirect print server for LPD printing:

1. Setting up IP parameters.
2. Setting up print queues.
3. Printing a test file.

The following sections provide detailed descriptions for each step.

Step 1. Setting Up IP Parameters

To set up IP parameters on the HP Jetdirect print server, refer to [Chapter 3](#). For more information on TCP/IP networks, refer to [Appendix A](#).

Step 2. Setting Up Print Queues

You must set up a print queue for each printer or printer personality (PCL or PostScript) you use on your system. Also, different queues are required for formatted and unformatted files. The queue names `text` and `raw` in the following examples (see `rp` tag) have special meanings.

Table 5.2 Supported Queue Names

<code>raw</code> , <code>raw1</code> , <code>raw2</code> , <code>raw3</code>	no processing
<code>text</code> , <code>text1</code> , <code>text2</code> , <code>text3</code>	carriage return added
<code>auto</code> , <code>auto1</code> , <code>auto2</code> , <code>auto3</code>	automatic
<code>binps</code> , <code>binps1</code> , <code>binps2</code> , <code>binps3</code>	binary PostScript
<code><user-defined></code>	defined by user; optionally including command strings before and after the print data

The line printer daemon on the HP Jetdirect print server treats data in the `text` queue as unformatted text or ASCII, and adds a carriage return to each line before sending it to the printer. (Note that the actual observed behavior is that a PCL line termination command (value of 2) is issued at the beginning of the job.)

The line printer daemon treats data in the `raw` queue as formatted files in PCL, PostScript, or HP-GL/2 languages and sends the data without change to the printer.

Data in the `auto` queue will be automatically processed as text or raw, as appropriate.

For the `binps` queue, the PostScript interpreter interprets the print job as binary PostScript data.

For user-defined queue names, the line printer daemon adds user-defined strings before or after the print data (user-defined print queues can be set up through Telnet, [Chapter 3](#), or the embedded Web server, [Chapter 4](#)).

If the queue name is not one of the above, the HP Jetdirect print server assumes it to be `raw1`.

Step 3. Printing a Test File

Print a test file using the LPD commands. For instructions, see the information provided for your system.

LPD on UNIX Systems

Configuring Print Queues for BSD-based Systems

Edit the `/etc/printcap` file to include the following entries:

```
printer_name|short_printer_name:\
:lp=:\
:rm=node_name:\
:rp=remote_printer_name_argument:\ (this should be
text, raw, binps, auto, or user-defined)
:lf=/usr/spool/lpd/error_log_filename:\
:sd=/usr/spool/lpd/printer_name:
```

where `printer_name` identifies the printer to the user, `node_name` identifies the printer on the network, and `remote_printer_name_argument` is the print queue designation.

For more information on `printcap`, see the `printcap` man page.

Example: Printcap Entries for ASCII or Text Printers

```
lj1_text|text1:\
:lp=:\
:rm=laserjet1:\
:rp=text:\
:lf=/usr/spool/lpd/lj1_text.log:\
:sd=/usr/spool/lpd/lj1_text:
```

Example: Printcap Entries for PostScript, PCL, or HP-GL/2 Printers

```
lj1_raw|raw1:\
:lp=:\
:rm=laserjet1:\
:rp=raw:\
:lf=/usr/spool/lpd/lj1_raw.log:\
:sd=/usr/spool/lpd/lj1_raw:
```

If your printer does not support automatic switching between PostScript, PCL, and HP-GL/2 languages, use the printer's control panel (if the printer has one) to select the printer language or rely on the application to select the printer language via commands embedded in the print data.

Make sure your users know the printer names for the printers, since they must type those names on the command line for printing.

Create the spooling directory by making the following entries. At the root directory, type:

```
mkdir /usr/spool/lpd
cd /usr/spool/lpd
mkdir printer_name_1 printer_name_2
chown daemon printer_name_1 printer_name_2
chgrp daemon printer_name_1 printer_name_2
chmod g+w printer_name_1 printer_name_2
```

where `printer_name_1` and `printer_name_2` refer to the printers to be spooled. You may spool several printers. The following example shows the command to create the spooling directories for printers used for text (or ASCII) printing and for PCL or PostScript printing.

Example: Creating Spooling Directory for Text and PCL/PostScript Printers

```
mkdir /usr/spool/lpd
cd /usr/spool/lpd
mkdir lj1_text lj1_raw
chown daemon lj1_text lj1_raw
chgrp daemon lj1_text lj1_raw
chmod g+w lj1_text lj1_raw
```

Configuring Print Queues Using SAM (HP-UX systems)

On HP-UX systems you can use the SAM utility to configure remote print queues for printing “text” (ASCII) files or “raw” (PCL, PostScript, or other printer language) files.

Before you execute the SAM program, select an IP address for the HP Jetdirect print server and set up an entry for it in the `/etc/hosts` file on your system running HP-UX.

1. Start the SAM utility as a superuser.
2. Select **Peripheral Devices** from the *Main* menu.
3. Select **Printers/Plotters** from the *Peripheral Devices* menu.
4. Select **Printers/Plotters** from the *Printers/Plotters* menu.
5. Select **Add a Remote Printer** from the *Actions* list, then select a printer name.

Examples: `my_printer` or `printer1`

6. Select a remote system name.

Example: `jetdirect1` (node name of the HP Jetdirect print server)

7. Select a remote printer name.

Type `text` for ASCII or `raw` for PostScript, PCL, or HP-GL/2.

Type `auto` to let the line printer daemon select automatically.

Type `binps` to instruct the PostScript interpreter to interpret the print job as binary PostScript data.

Type the name of a user-defined queue to include pre-defined strings before and/or after the print data (user-defined print queues can be set up through Telnet, [Chapter 2](#), and the embedded Web server, [Chapter 4](#)).

8. Check for a remote printer on a BSD system. You must type `Y`.
9. Click **OK** at the bottom of the menu. If the configuration is successful, the program prints the message:

The printer has been added and is ready to accept print requests.

10. Click **OK** and select **Exit** from the *List* menu.

11. Select **Exit Sam**.

Note

By default, the lpsched is not running. Make sure you turn the scheduler on when you set up your print queues.

Printing a Test File

To verify that the printer and print server connections are correct, print a test file.

1. At the UNIX system prompt type:

```
lpr -Pprinter_name file_name
```

where `printer_name` is the designated printer and `file_name` refers to the file to be printed.

Examples (for BSD-based systems):

Text File: `lpr -Ptext1 textfile`

PCL File: `lpr -Praw1 pclfile.pcl`

PostScript File: `lpr -Praw1 psfile.ps`

HP-GL/2 File: `lpr -Praw1 hpglfile.hpg`

For HP-UX systems, substitute `lp -d` for `lpr -P`.

2. To get print status, type the following at the UNIX prompt:

```
lpq -Pprinter_name
```

where `printer_name` is the designated printer.

Examples (for BSD-based systems):

```
lpq -Ptext1
```

```
lpq -Praw1
```

For HP-UX systems, substitute `lpstat` for `lpq -P` to get print status.

This completes the process for configuring the HP Jetdirect print server to use LPD.

LPD on Windows NT/2000/Server 2003 Systems

This section describes how to configure Windows NT/2000 networks to use the HP Jetdirect LPD (Line Printer Daemon) services.

The process consists of two parts:

- Installing TCP/IP software (if not already installed).
- Configuring a network LPD printer.

Installing TCP/IP Software

This procedure lets you check whether you have TCP/IP installed on your Windows NT system, and to install the software if necessary.

Note	You may need your Windows System distribution files or CD-ROMs to install TCP/IP components.
-------------	--

1. To check whether you have Microsoft TCP/IP Printing protocol and TCP/IP printing support:

- Windows 2000/Server 2003—

Windows 2000: Click **Start, Settings, Control Panel**. Then double-click the **Network and Dial-up Connections** folder. Double-click the **Local Area Connection** for your network and click **Properties**.

Server 2003: Click **Start, All Programs, Accessories, Communications**, and open the **Network Connections** folder. Double-click the **Local Area Connection** for your network and click **Properties**.

If Internet Protocol (TCP/IP) is listed and enabled in the list of components used by this connection, the necessary software is already installed. (Proceed to "[Configuring a Network Printer for Windows 2000/Server 2003 Systems](#)"). If not, go to step 2.

- NT 4.0—Click **Start, Settings, Control Panel**. Then double-click the **Network** option to display the *Network* dialog box.

If TCP/IP Protocol is listed in the **Protocols** tab, and Microsoft TCP/IP Printing is listed in the **Services** tab, you have already installed the necessary software. (Proceed to [“Configuring a Network Printer for Windows NT 4.0 Systems.”](#)) If not, go to step 2.

2. If you have not previously installed the software:

- Windows 2000/Server 2003—In the *Local Area Connection Properties* window, click **Install**. In the *Select Network Component Type* window, select **Protocol** and click **Add** to add the **Internet Protocol (TCP/IP)**.

Follow the instructions on the screen.

- NT 4.0—Click the **Add** button for each tab and install the **TCP/IP Protocol** and the **Microsoft TCP/IP Printing** service.

Follow the instructions on the screen.

When prompted, type the full path to the Windows NT distribution files (you may need your Windows NT workstation or server CD-ROM).

3. Enter TCP/IP configuration values for the computer:

- Windows 2000/Server 2003—On the **General** tab in the *Local Area Connection Properties* window, select **Internet Protocol (TCP/IP)** and click **Properties**.
- NT 4.0—You may be automatically prompted for TCP/IP configuration values. If not, select the **Protocols** tab in the *Networks* window and select **TCP/IP Protocol**. Then click **Properties**.

If you are configuring a Windows server, type the IP address, default gateway address, and subnet mask in the appropriate spaces.

If you are configuring a client, check with your Network Administrator to learn whether you should enable automatic TCP/IP configuration or whether you should type a static IP address, default gateway address, and subnet mask in the appropriate spaces.

4. Click **OK** to exit.

5. If prompted, exit Windows and restart your computer for the changes to take effect.

Configuring a Network Printer for Windows 2000/Server 2003 Systems

Set up the default printer by performing the following steps.

1. Verify that the Print Services for Unix is installed (required for LPR port availability):

- a. On Windows 2000, click **Start, Setup, and Control Panel**. Double-click the **Network and Dial-up Connections** folder.

On Server 2003: Click **Start, All Programs, Accessories, Communications**, and open the **Network Connections** folder.

- b. Click the **Advanced** menu and select **Optional Networking Components**.
 - c. Select and enable **Other Network File and Print Services**.
 - d. Click **Details**, and verify that **Print Services for Unix** is enabled. If not, enable it.
 - e. Click **OK**, and then **Next**.
2. On Windows 2000, open the **Printers** folder (from the Desktop, click **Start, Settings, and Printers**).
- On Server 2003, open the **Printers and Faxes** folder (from the Desktop, click **Start, Printers and Faxes**).
3. Double-click **Add Printer**. From the Add Printer Wizard welcome screen, click **Next**.
 4. Select **Local printer**, and disable automatic detection for Plug and Play printer installation. Click **Next**.
 5. Choose **Create a new port**, and select **LPR Port**. Click **Next**.
 6. In the *Add LPR compatible printer* window:
 - a. Enter the DNS name or IP address of the HP Jetdirect print server.
 - b. For the name of the printer or print queue on the HP Jetdirect print server, enter (in lowercase) **raw**, **text**, **auto**, **binps**, or the name of a user-defined print queue (user-defined print queues can be set up through the embedded Web server, see [Chapter 4](#)).

- c. Then click **OK**.

Note

The HP Jetdirect print server treats text files as unformatted text or ASCII files. Files that are raw are formatted files in PCL, PostScript, or HP-GL/2 printer languages.

If the queue type is *binps*, the PostScript interpreter is instructed to interpret the print job as binary PostScript data.

7. Select the Manufacturer and Printer model. (If necessary, click **Have Disk** and follow the instructions to install the printer driver.) Click **Next**.
8. Choose to keep the existing driver, if prompted. Click **Next**.
9. Enter a printer name, and choose whether this printer will be the default printer. Click **Next**.
10. Choose whether this printer will be available to other computers. If shared, enter a share name that identifies the printer to other users. Click **Next**.
11. If desired, enter a location and other information for this printer. Click **Next**.
12. Choose whether to print a test page, and click **Next**.
13. Click **Finish** to close the wizard.

Configuring a Network Printer for Windows NT 4.0 Systems

At the Windows NT 4.0 system, set up the default printer by performing the following steps.

1. Click **Start**, select **Settings**, and click **Printers**. The *Printers* window opens.
2. Double-click **Add Printer**.
3. Select **My Computer**, then click **Next**.
4. Click **Add Port**.
5. Select **LPR Port**, and click **New Port**.
6. In the *Name or address of server providing lpd* box, type the IP address or DNS name of the HP Jetdirect print server.

Note	NT clients can enter the IP address or name of the NT server that is configured for LPD printing.
-------------	---

7. In the *Name of printer or print queue on that server* box, type (in lowercase) *raw*, *text*, *binps*, *auto*, or the name of a user-defined print queue (user-defined print queues can be set up through the embedded Web server, see [Chapter 4](#)). Then click **OK**.

The HP Jetdirect print server treats *text* files as unformatted text or ASCII files. Files that are *raw* are formatted files in PCL, PostScript, or HP-GL/2 printer languages. If the queue type is *binps*, the PostScript interpreter is instructed to interpret the print job as binary PostScript data.

8. Ensure that the port is selected in the *Add Printer* list of the available ports, then click **Next**.
9. Follow the remaining instructions on the screen to complete the configuration.

Verifying the Configuration

From within Windows NT, print a file from any application. If the file prints correctly, the configuration was successful.

If the print job is not successful, try printing directly from DOS using the following syntax:

```
lpr -S<ipaddress> -P<queuenam> filename
```

where `ipaddress` is the IP address of the print server, `queuenam` is the name “raw” or “text” and `filename` is the file you wish to print. If the file prints correctly, the configuration was successful. If the file does not print, or prints incorrectly, see [Chapter 8](#).

Printing from Windows Clients

If the LPD printer on the Windows server is shared, Windows clients can connect to the printer on the Windows server using the Windows Add Printer utility in the Printers folder.

LPD on Windows XP Systems

This section describes how to configure Windows XP networks to use the HP Jetdirect LPD (Line Printer Daemon) services.

The process consists of two parts:

- Adding Windows Optional Networking Components
- Configuring a Network LPD Printer.

Adding Windows Optional Networking Components

1. Click **Start**.
2. Click **Control Panel**.
3. Click **Network and Internet Connections**.
4. Click the **Network Connections** icon.
5. Select **Advanced** in the top menu bar. In the drop-down list, select **Optional Networking Components**.

6. Select **Other Network File and Print Services** and click **Next**. (If you select **Details** before selecting **Next**, you will see “Print Services for UNIX (R)” as a component of Other Network File and Print Services.) The files being loaded will be shown.
7. Close the Network Connections window. LPR port is now an option in the **Properties** of a printer under **Ports, Add Port**.

Configuring a Network LPD Printer

Adding a New LPD Printer

1. Open the **Printers** folder (from the desktop, click **Start, Printers and Faxes**).
2. Click **Add Printer**. On the Add Printer Wizard welcome screen, click **Next**.
3. Select **Local printer**, then *uncheck* the automatic detection for Plug and Play printer installation. Click **Next**.
4. Select **Create a new port**, and select **LPR Port** from the pull-down menu. Click **Next**.
5. In the Add LPR Compatible Printer window, do the following:
 - a. Type the Domain Name System (DNS) name or Internet protocol (IP) address of the HP Jetdirect print server.
 - b. Type (in lowercase) the name of the print queue for the HP Jetdirect print server (for example: raw, text, auto, or binps.)
 - c. Click **OK**.
6. Select the manufacturer and printer model. (If necessary, click **Have Disk** and follow the instructions to install the printer driver.) Click **Next**.
7. Click **Yes** to keep the existing driver, if prompted. Click **Next**.
8. Type a printer name and (if desired) click this printer as default (if desired). Click **Next**.
9. Select whether to *share* this printer with other network computers (for example, if your system is a printer server). If shared, type a share name to identify the printer to other users. Click **Next**.

10. If desired, enter a location and other information for this printer. Click **Next**.
11. Click **Yes** to print a test page, then click **Next**.
12. Click **Finish** to close the wizard.

Creating an LPR Port for an Installed Printer

1. Click **Start, Printers and Faxes**.
2. Right-click the **Printer** icon, and select **Properties**.
3. Select the **Ports** tab and **Add Port**.
4. Select **LPR Port** from the Printer Ports dialog box, and select **New Port**.
5. In the field labeled *Name or address of server providing lpd*, enter the DNS name or IP address of the HP Jetdirect print server.
6. In the dialog box labeled *Name of printer or print queue on that server*, (in lowercase) type the name of the print queue for the HP Jetdirect print server (for example: raw, text, auto, binsps, or user-specified print queue).
7. Select **OK**.
8. Select **Close** and **OK** to close the **Properties** box.

LPD on Mac OS Systems

LaserWriter 8 version 8.5.1 or higher is required in order to support IP printing on computers running any of the following:

- Mac OS 8.1 or higher
- Mac OS 7.5 through Mac OS 7.6.1
- Desktop Printer Utility 1.0 or later

Note	IP printing in LaserWriter 8 is not available on Mac OS 8.0.
-------------	--

Assigning an IP Address

Before you can set up a printer for LPR printing, assign an IP address to the printer or print server. Use the HP LaserJet Utility to configure the printer IP address as follows:

1. Double-click **HP LaserJet Utility** in the HP LaserJet folder.
2. Click the **Settings** button.
3. Select **TCP/IP** from the scrolling list and then click **Edit**.
4. Select the desired option. You can automatically obtain the TCP/IP configuration from either the DHCP server or the BOOTP server, or you can manually specify the TCP/IP configuration.

Setting Up Mac OS

To configure a computer for LPR printing, do the following:

1. Launch the *Desktop Printer Utility*.
2. Select **Printer (LPR)** and click **OK**.
3. In the *PostScript Printer Description (PPD) File* section, click **Change...** and select the PPD for your printer.
4. In the *Internet Printer* or the *LPR Printer* section, depending on your version of the Desktop Printer Utility, click **Change...**
5. Enter the printer's IP address or domain name for *Printer Address*.
6. Enter the queue name, if used. Otherwise, leave it blank.

Note

The queue name is typically *raw*. Other valid queue names are *text*, *binps*, *auto*, or a user-defined queue name (user-defined print queues can be set up through Telnet or the embedded Web server, see [Chapter 4](#)).

-
7. Click **Verify** to verify that the printer was found.
 8. Click **OK** or **Create**, depending on your version of the Desktop Printer Utility.
 9. Go to the **File** menu and select **Save** or use the resulting save dialog, depending on your version of the Desktop Printer Utility.

10. Enter a name and location for the desktop printer icon and click **OK**. The default name is the printer's IP address, and the default location is on the desktop.
11. Exit the program.

For the latest information on using the HP Jetdirect LPD services from Mac OS systems, search for “LPR printing” at Apple Computer's Tech Info Library Web site at <http://til.info.apple.com>.

FTP Printing

Introduction

FTP (File Transfer Protocol) is a basic TCP/IP connectivity utility to transfer data between systems. FTP printing is a way to use FTP to send print files from a client system to an HP Jetdirect-connected printer. In an FTP printing session, the client connects and sends a print file to the HP Jetdirect FTP server which in turn passes the print file to the printer.

The HP Jetdirect FTP server can be enabled or disabled through a configuration tool, such as Telnet (see [Chapter 3](#)) or the embedded Web server (see [Chapter 4](#)).

Requirements

FTP printing described here requires the following:

- TCP/IP client systems with FTP that complies with RFC 959.

Note

For the most recent list of tested systems, visit HP online support at www.hp.com/support/net_printing.

Print Files

The HP Jetdirect FTP server transfers print files to the printer but does not interpret them. For proper printing, print files must be in a language recognized by the printer (such as PostScript, PCL, or unformatted text). For formatted print jobs, you must first print to a file from your application using the driver for the selected printer, then transfer the print file to the printer through an FTP session. For formatted print files, use binary (image) type transfers.

Using FTP Printing

FTP Connections

Similar to standard FTP file transfers, FTP printing uses two TCP connections: a control connection and a data connection.

Once an FTP session is opened, it remains active until either the client closes the connection or the data and control connections are idle for a time that exceeds the idle timeout period (default is 270 seconds). The idle timeout can be set through various TCP/IP configuration tools, such as BOOTP/TFTP, Telnet, printer's control panel (see [Chapter 3](#)), the embedded Web server (see [Chapter 4](#)), or management software.

Control Connection

Using standard FTP, a control connection is opened by the client to the FTP server on the HP Jetdirect print server. FTP control connections are used to exchange commands between the client and the FTP server. The HP Jetdirect print server supports up to four control connections (or FTP sessions) simultaneously. If the number of allowed connections is exceeded, a message indicating that service is not available will be displayed.

FTP control connections use TCP port 21.

Data Connection

A second connection, a data connection, is created each time a file is transferred between the client and the FTP server. The client controls the creation of a data connection by issuing the commands that require a data connection (such as FTP `ls`, `dir` or `put` commands).

Although the `ls` and `dir` commands are always accepted, the HP Jetdirect FTP server supports a single data connection for printing at a time.

The transmission mode for an FTP data connection with the HP Jetdirect print server is always in stream mode, which marks the end-of-file by closing the data connection.

Once a data connection is established, the file transfer type (ASCII or binary) can be specified. Clients may attempt to autonegotiate a transfer type, and the default transfer type depends on the client system (for example, Windows NT may default to ASCII, while UNIX may default to binary). To specify the transfer type, enter the `bin` or `ascii` command at the FTP prompt.


FTP Login

To start an FTP session, enter the following command from a MS-DOS or UNIX command prompt:

```
ftp <IP address>
```

where <IP address> is the valid IP address or node name configured for the HP Jetdirect print server. See [Figure 6.1](#)

Figure 6.1 FTP Login Example



```
Microsoft(R) Windows NT(TM)
(C) Copyright 1985-1996 Microsoft Corp.

C:\>ftp 192.168.45.39
Connected to 192.168.45.39
220 JD FTP Server Ready
User (192.168.45.39:(none)): susan_g
331 Username Ok, send identity (email address) as password.
Password:
230- Hewlett-Packard FTP Print Server Version 2.0
Directory:      Description:
-----
PORT1          Print to port 1 HP Color LaserJet 4500

To print a file, use the command: put <filename> [portx]
or 'cd' to a desired port and use: put <filename>.

Ready to print to PORT1
230 User logged in.
ftp>
```

If the connection is successful, a Ready message will be displayed.

After a successful connection, the user is prompted for a login name and password. The default is the client's login name. The Jetdirect FTP server will allow any user name. Passwords are ignored.

If login is successful, a message "230" will be displayed on the client system. In addition, the available HP Jetdirect ports for printing will be displayed. HP Jetdirect print servers supported in this guide provide a single port (Port 1). For a typical FTP printing session, see "[Example of an FTP Session.](#)"

Ending the FTP Session

To end an FTP session, type quit or bye.

Note

Prior to ending an FTP session, a **Ctrl C** command is recommended to ensure the data connection is closed.

Commands

[Table 6.1](#) summarizes commands available to the user during an FTP printing session.

Table 6.1 User Commands for HP Jetdirect FTP Server (1 of 2)

Command	Description
user <username>	<username> specifies a user. Any user will be accepted and can print to the selected port.
cd <port#>	<port#> selects a port number for printing. For supported HP Jetdirect print servers, only port1 is available.
cd /	/ specifies the root directory of the HP Jetdirect FTP server.
quit	quit or bye terminates the FTP session with the HP Jetdirect print server.
bye	
dir	dir or ls displays the contents of the current directory. If this command is typed in the root directory, a list of available ports for printing is displayed. For supported HP Jetdirect print servers, only port1 is available.
ls	
pwd	Displays the current directory or the current Jetdirect printing port.
put <filename>	<filename> specifies the file to send to the selected HP Jetdirect print server port (Port 1).
bin	Configures an FTP binary (image) file transfer.
ascii	Configures an FTP ASCII file transfer. HP Jetdirect print servers support only non-print format control for character transfers (standard values for spacing and margins are used).

Table 6.1 User Commands for HP Jetdirect FTP Server (2 of 2)

Command	Description
Ctrl C	Press the Ctrl and C keyboard keys simultaneously to abort the FTP service command and any transfer of data. The data connection is closed.
rhelphelp remotehelp	This command depends on your client system (use rhelphelp on UNIX, or remotehelp on Windows NT/2000/Server 2003) and displays a list of FTP system commands supported by the print server. (Note: The commands displayed are <i>not</i> user commands. User-accessible commands depend on the client's FTP system.)

Example of an FTP Session

This is an example of a typical FTP printing session:

```
C:\> ftp 192.168.45.39
Connected to 192.168.45.39.
220 JD FTP Server Ready
User <192.168.45.39:<none>>: susan_g
001 Username Ok, send identity <email address> as password
Password:
230- Hewlett-Packard FTP Print Server Version 2.0
Directory:      Description:
-----
PORT1          Print to port 1 HP color LaserJet 4500
```

To print a file, use the command: put <filename> [portx]
or cd to a desired port and use: put <filename>.

Ready to print to PORT1

```
230 User logged in.
ftp> pwd
257 "/" is current directory. <"default port is : /PORT1">
HP Color LaserJet 4500"
ftp> cd port1
250 Changed directory to "/PORT1"
ftp> pwd
257 "/PORT1" is current directory. "HP Color LaserJet 4500"
ftp> bin
200 Type set to I. Using binary mode to transfer files.
ftp> put d:\atlas\temp\ftp_test.ps
200 PORT command successful.
150 Opening BINARY mode data connection
226- Ready
226- Processing job
226 Transfer complete
31534 bytes sent in 0.04 seconds <788.35 Kbytes/sec>
ftp> quit
221 Goodbye

C:\>
```

Security Features

Introduction

Security features are provided that can help to minimize unauthorized access to network configuration parameters and other data stored on HP Jetdirect print servers. The features may differ depending on the version of firmware resident on the print server.

CAUTION

Although these features can help to minimize unauthorized access to stored data and configuration parameters on HP Jetdirect print servers, the prevention of unauthorized access cannot be guaranteed.

For advanced security needs, contact HP Consulting services.

[Table 7.1](#) summarizes the basic security features provided with HP Jetdirect print servers.

Table 7.1 Summary of HP Jetdirect Security Features (1 of 3)

Secure Embedded Web Server Management
<ul style="list-style-type: none">● A preinstalled, self-signed digital certificate provides HTTPS (secure HTTP) access to the embedded Web server from your Web browser. HTTPS (secure HTTP) provides secure, encrypted communications with your browser.● Digital certificates issued by a trusted third party can be installed on the print server, allowing it to be configured as a trusted site.● Using HTTPS, the embedded Web server provides configuration and management of network parameters and protocols through a secure channel.● An HP Jetdirect Security Configuration Wizard provides an easy-to-use interface to configure security settings.● A wireless configuration wizard provides an easy-to-use interface to configure wireless encryption and authentication settings.● Full-featured print servers can be configured with EAP/802.1X server-based authentication.
Network Protocol Control
<ul style="list-style-type: none">● Network printing, printing services, device discovery, and management protocols on the HP Jetdirect print server can be enabled or disabled. By disabling unused or unnecessary protocols, unauthorized access through applications that use these protocols can be prevented.● Protocols may be enabled or disabled through Telnet, embedded Web server, and HP Web Jetadmin.
IP Administrator Password
<ul style="list-style-type: none">● Used by Telnet, HP Web Jetadmin, and the embedded Web server to control access to HP Jetdirect configuration parameters.● Up to 16 alphanumeric characters may be used.● Configured on the HP Jetdirect print server using TFTP (Chapter 3), Telnet (Chapter 3), embedded Web server (Chapter 4) services, or HP Web Jetadmin. Up to 16 alphanumeric characters are allowed.● If configured through the embedded Web server, may be synchronized as the SNMP Set Community Name used in HP Web Jetadmin SNMP v1/v2c Set commands.● Cleared by cold reset of the print server to factory default settings.

Table 7.1 Summary of HP Jetdirect Security Features (2 of 3)

IP Access Control List
<ul style="list-style-type: none">● Specifies up to 10 host systems, or networks of host systems, that are allowed access to the HP Jetdirect print server and the attached network device.● Access is generally limited to host systems specified in the list.● By factory default, host systems that use HTTP (for example, using the embedded Web server or IPP) are not checked against entries in the Access List and are allowed access. However, HTTP host access can be disabled through the embedded Web server.● If the list is empty, then all hosts are allowed access.● Configured on the HP Jetdirect print server using TFTP (Chapter 3), Telnet (Chapter 3), embedded Web server (Chapter 4), or management software.
Telnet Control
<ul style="list-style-type: none">● Telnet may be disabled through the embedded Web server (see Chapter 4). Telnet access is not secure.
Authentication and Encryption
<ul style="list-style-type: none">● (Full-featured print servers) Certificate management for X.509 digital certificates is provided through the embedded Web server, for both client-based and server-based authentication. (Installed certificates are limited to 3KB. A single Certificate Authority (CA) certificate may be installed.)● (Value-based wired/wireless print servers) In wireless mode, enhanced wireless authentication and encryption methods are supported, including WPA-PSK.
SNMP v1/v2c Set Community Name (IP/IPX)
<p>(SNMP v1/v2c only)</p> <ul style="list-style-type: none">● A password on the HP Jetdirect print server that allows incoming SNMP Set commands (for example, from management software) to write (or <i>set</i>) HP Jetdirect configuration parameters.● For a user-assigned Set Community Name, SNMP Set commands must contain the user-assigned name, which is authenticated by the print server before the command is performed.● On IP networks, authentication of SNMP Set commands may be further restricted to systems identified on the access control list.● Configured on the HP Jetdirect print server using TFTP (Chapter 3), Telnet (Chapter 3), embedded Web server (Chapter 4), or Management application services.● SNMP v1/v2c uses plain text and can be disabled.

Table 7.1 Summary of HP Jetdirect Security Features (3 of 3)

SNMP v3
<p>(For full-featured print servers only)</p> <ul style="list-style-type: none">● An SNMP v3 agent on the HP Jetdirect print server provides secure, encrypted communications with an SNMP v3 management application, such as HP Web Jetadmin.● The print server supports creation of an SNMP v3 account when it is enabled through the embedded Web server. The account information can be integrated on SNMP v3 management applications.● The print server supports seamless SNMP v3 account creation and management from HP Web Jetadmin.
HP Web Jetadmin Password and Profiles
<ul style="list-style-type: none">● Access control to Jetdirect configuration parameters through the Jetdirect IP Administrator password, which may be configured from HP Web Jetadmin, Telnet, or embedded Web server. For instructions, refer to the HP Web Jetadmin online help.● HP Web Jetadmin provides access control through User Profiles. User Profiles allow password protection for individual profiles and controlled access to HP Jetdirect and printer features. For more information, refer to the HP Web Jetadmin online help.● (For full-featured print servers only) HP Web Jetadmin can seamlessly enable the SNMP v3 agent on the print server, and create an SNMP v3 account for secure, encrypted management.
Printer Control Panel Lock
<ul style="list-style-type: none">● Selected HP printers provide a control panel lock that prevents access to HP Jetdirect internal print server configuration parameters. In many cases, this lock may be set remotely by management applications (such as HP Web Jetadmin). To determine whether your printer supports a control panel lock, refer to your printer documentation.

Using Security Features

Access to HP Jetdirect configuration parameters can be controlled through combined use of the available security features. [Table 7.2](#) provides examples of various settings and the associated level of access control.

Table 7.2 Settings for Access Control (1 of 2)

Settings	Level of Access Control
<ul style="list-style-type: none">● Accessible through HTTP (embedded Web server), SNMP v1/v2c applications, or Telnet● Administrator password not set● Default SNMP v1/v2c community names used● No authentication or encryption● Access control list empty	Low Best suited for trusted environments. Any system can access the HP Jetdirect configuration parameters through the embedded Web server, Telnet, or SNMP management software. Passwords are not required.
<ul style="list-style-type: none">● Administrator password set● User-specified SNMP v1/v2 Set Community Name set● The Access Control List contains host entries and checks HTTP connections● Telnet and other non-secure protocols disabled.	Medium Limited security for non-trusted environment. If the Administrator password and SNMP v1/v2c Set Community Name are known, access is limited to: <ul style="list-style-type: none">● systems listed in the Access Control List, and● SNMP v1/v2c management applications

Table 7.2 Settings for Access Control (2 of 2)

Settings	Level of Access Control
<ul style="list-style-type: none"> ● Unused protocols disabled ● HTTPS access enabled using certificates issued by trusted sources ● Full-featured Jetdirect print servers configured for EAP/802.1x server-based authentication and encryption ● Full-featured Jetdirect print servers with SNMP v3 enabled, SNMP v1/v2c disabled ● Telnet disabled ● Passwords set ● The Access Control List contains specified entries and HTTP connections are checked ● Printer control panel locked 	<p>High</p> <p>High security for non-trusted, professionally managed environments.</p> <p>Access is limited to authenticated hosts that are specified in the Access Control List. Encryption provides data privacy; network communication in plain-text is not used.</p> <p>CAUTION: Power-on settings (for example, configurations from a BootP/TFTP or DHCP/TFTP server) may change the print server's settings when it is power-cycled. Be sure to confirm your intended power-on settings.</p>

Troubleshooting the HP Jetdirect Print Server

Introduction

This chapter describes how to diagnose and correct problems associated with the HP Jetdirect print server.

A flowchart guides you to the correct procedures for troubleshooting the following:

- Printer problems
- HP Jetdirect hardware installation and connection problems
- Network-related problems

To troubleshoot your HP Jetdirect print server, you may need the following items:

- A Jetdirect configuration page (see [Chapter 9](#))
- A Printer Configuration or Diagnostic Page
- Documentation that came with your printer
- Documentation that came with your HP Jetdirect print server
- The diagnostics tools and utilities provided with your network software (for example, Novell NetWare utilities, TCP/IP utilities, or network printer management applications such as HP Web Jetadmin)

Note

Frequently asked questions about installing and configuring HP Jetdirect print servers can be found by searching for your HP Jetdirect product at http://www.hp.com/support/net_printing.

Resetting to Factory Defaults

Parameters on the HP Jetdirect print server (for example, the IP address) can be reset to factory default values using the following procedures:

CAUTION

For HP Jetdirect wireless print servers, resetting to factory default settings may cause the print server to lose its wireless connection to your network.

Reconfiguration of wireless network settings and reinstallation of the print server may be required.

A Jetdirect X.509 certificate will be saved over a cold reset to factory default values. However, a Certificate Authority (CA) certificate installed to validate a network authentication server will not be saved.

● HP LaserJet Printer with Internal EIO Print Server

In most cases, the HP Jetdirect internal print server can be reset to factory defaults when a cold-reset is performed on the printer.

CAUTION

Resetting the printer will reset **all** printer settings to their factory defaults. After resetting the printer, you may need to use the printer's control panel to reconfigure printer settings that are required by users.

-
- For older HP LaserJet printers, a cold-reset is performed by power cycling the printer while pressing the **Go, Start, or Pause/Resume** button.
 - For recent LaserJet printers and MFPs, use the **Menu, Configure Device, Resets** menu at the control panel.
 - For other printers, refer to your printer manuals. Or, visit <http://www.hp.com/go/support> and search for document file bpj02300.html.

Note

When you attempt to reset to factory default values, print a Jetdirect configuration page to confirm that factory-reset values have been assigned.

● HP Jetdirect External Print Servers

Reset the HP Jetdirect external print server by holding down the **Test** button on the print server while connecting the power cord.

After a cold reset, your network systems may lose their connection to the printer.

General Troubleshooting

Troubleshooting Chart - Assessing the Problem




Figure 8.1 Assessing the Problem

Procedure 1: Verifying that the Printer is On and Online

Check the following items to make sure the printer is ready to print.

1. Is the printer plugged in and turned on?

Make sure the printer is plugged in and turned on. If the problem persists, you may have a defective power cable, power source, or printer.

2. Is the printer online?

The online **Ready** light should be lit. If it is not, press the appropriate buttons (for example, **Start**, **Pause/Resume**, or press ✓ to access the menus) to place the printer online.

3. Is the printer's control panel display blank (on printers with displays)?

- Make sure the printer is turned on.
- Make sure the HP Jetdirect print server is installed correctly.
- Make sure the printer is not in Power Save mode.

4. Does a message other than `READY` appear on the printer control panel display?

- See Procedure 3 in this section for a list of network-related error messages and corrective actions.
- See your printer documentation for a complete list of control panel messages and corrective actions.

Procedure 2: Printing an HP Jetdirect Configuration Page

The HP Jetdirect configuration page is an important troubleshooting tool. The information on this page reveals the status of your network and the HP Jetdirect print server. The ability to print a configuration page provides an indication that the printer is operating correctly. See [Chapter 9](#) for information on the HP Jetdirect configuration page.

Note For a TCP/IP network, the Jetdirect configuration page can also be viewed from a browser by accessing the Jetdirect embedded Web server. See [Chapter 4](#) for more information.

Check the following items if the configuration page does not print.

1. Did you perform the correct steps on the printer to print the configuration page?

The steps required to print a configuration page vary between different printers and print servers. See the documentation supplied with your print server.

For EIO print servers, a Jetdirect page typically prints along with the printer configuration page. Use the printer control panel menus.

For external print servers, press the Test button on the print server.

2. Is there a print job in process?

You cannot print an HP Jetdirect configuration page to the printer while a print job is in process. Wait until the print job is complete, then print the configuration page.

3. Does an error message appear on the printer control panel display?

- See Procedure 3 in this section for a list of network-related error messages and corrective actions.
- See your printer documentation for a complete list of control panel messages and corrective actions.

Procedure 3: Resolving Printer Display Error Messages

Check the following information to resolve network-related error messages that appear on the printer control panel display. *This information assumes you have already printed a configuration page.*

1. For LaserJet printers or MFPs, does the control panel display a Service Error message, such as 49.XXXX, 79.XXXX or 8X.XXXX error?
 - Refer to your printer manuals to interpret the error message.
 - If you upgraded the Jetdirect firmware recently, power the print server off/on. For internal Jetdirect cards, turn the printer off and back on again.
 - Reinstall the HP Jetdirect print server to ensure it is installed correctly, and verify all connectors are fully mated.
 - If possible, print an HP Jetdirect configuration page and verify all configuration parameters. To interpret HP Jetdirect configuration page messages, see [Chapter 9](#).
 - If your printer contains multiple EIO slots, try using a different slot.
 - Turn off the printer, remove the HP Jetdirect print server, and turn the printer back on. If the error message disappears when the print server is removed, it is likely that the print server was causing the error. Replace the print server.
 - Record all error codes and contact your service provider. If you need to replace the HP Jetdirect print server under warranty service, include all diagnostic and configuration pages with the faulty print server.
2. Does EIOX INITIALIZING/DO NOT POWER OFF appear on the display?

Wait for ten minutes to see if it clears. If it does not, you may need to replace the HP Jetdirect print server.

3. Does a 40 ERROR appear on the printer's control panel display?

The HP Jetdirect print server detected a break in the data communications. When this error occurs, the printer goes offline.

A break in communications may result from the physical network connection being disrupted or the server going down. If your printer has an Auto Continue feature that is disabled or off, you must press the appropriate key (**Start** or **Pause/Resume**, for example) on the printer after the communications problem is solved to put the printer back online. Turning the Auto Continue feature on forces the printer to reconnect without user intervention. However, this does not solve the disconnect problem.

4. Does an initializing (INIT) message appear on the display?

This is a normal message. Wait about 3 minutes for the message to clear, or another message to appear. If another message appears, see the printer's documentation and configuration pages for additional information.

5. Does a message other than READY or the messages listed in this section appear on the display?

See your printer documentation for a complete list of control panel messages and corrective actions.

Procedure 4: Resolving Printer Communication Problems with the Network

Check the following items to verify that the printer is communicating with the network. *This information assumes you have already printed a Jetdirect configuration page.*

1. Are there any physical connection problems between the workstation or file server and the HP Jetdirect print server?

Verify network cabling, connections, and router configurations. Verify that network cable lengths meet network specifications. Verify that wireless network settings have been properly configured.


2. Are your network cables connected properly?

Make sure that the printer is attached to the network using the appropriate HP Jetdirect print server port and cable. Check each cable connection to make sure it is secure and in the right place. If the problem continues, try a different cable or network port on the hub or switch.

3. For 10/100Base-TX print servers, is autonegotiation properly configured?

The speed and communication mode on the print server must match the network for proper operation. For EIO print servers, autonegotiation is configured through the EIO Jetdirect menu from the printer's control panel.

The print server's RJ-45 network connector has indicator lights to identify the connection speed. Verify that either the 10 Mbps or 100 Mbps light is on.



4. Is the print server connected to an 802.1X network and properly configured for EAP/802.1X operation?

The network must support the Extensible Authentication Protocol (EAP) method configured for use on the print server.

Verify the configuration of the network's 802.1X port. If it does not allow guest or temporary access, you may need to preconfigure the Jetdirect print server for 802.1X operation before connection to your network. This is done using an isolated LAN, or through a direct computer-to-printer connection using a cross-over cable.

5. Have any software applications been added to the network?
Make sure they are compatible and that they are installed correctly with the correct printer drivers.
6. Are other users able to print?
The problem may be workstation-specific. Check the workstation network drivers, printer drivers, and redirection (capture in Novell NetWare).
7. If other users are able to print, are they using the same network operating system?
Check your system for proper network operating system setup.
8. Is your protocol enabled on the HP Jetdirect print server?
Check the status of the network protocols on the Jetdirect configuration page. See [Chapter 9](#) for information on the configuration page. (On TCP/IP networks, you can also use the embedded Web server to check status of other protocols. See [Chapter 4](#).)
9. Is there an error message in the protocol's section on the Jetdirect configuration page?
See [Chapter 9 "HP Jetdirect Configuration Page"](#) for a list of error messages.
10. If you are using Apple EtherTalk, does the printer appear in the Chooser?
 - Verify network and HP Jetdirect settings on the Jetdirect configuration page. See [Chapter 9](#) for information on the configuration page.
 - Confirm the network settings for the printer using the printer control panel (for printers with control panels).
 - See the troubleshooting section in the online help for the HP LaserJet Utility.
 - Verify the printer has the PostScript option installed.

11. If you are on a TCP/IP network, can you use Telnet to print directly to the printer?

Use the following Telnet command:

```
telnet <IP address> <port>
```

where <IP address> is the IP address assigned to the HP Jetdirect print server and <port> is 9100, the default printing port of the print server.

In the Telnet session, type in data and press **Enter**. The data should print to the printer (a manual form feed may be required).

12. Does the printer appear in HP Web Jetadmin or other management application?

- Verify network and HP Jetdirect settings on the Jetdirect configuration page. See [Chapter 9](#) for information on the configuration page.
- Confirm the network settings for the printer using the printer control panel (for printers with control panels).
- See the troubleshooting section in the online help included with the HP Web Jetadmin software.

13. If you are using Microsoft Windows NT 4.0 (DLC/LLC), does the printer appear in the *Add a Hewlett-Packard Network Peripheral Port* dialog box?

- Verify network and HP Jetdirect settings on the Jetdirect configuration page. See [Chapter 9](#) for information on the configuration page.
- Confirm the network settings for the printer using the printer control panel (for printers with control panels).
- Ensure that the printer is on the same physical subnet and that it is not connected over a router.

14. On supported systems, does the printer respond to HP Web Jetadmin?

- Verify network and HP Jetdirect settings on the Jetdirect configuration page. See [Chapter 9](#) for information on the configuration page.
- Confirm the network settings for the printer using the printer control panel (for printers with control panels).
- See the troubleshooting section in the online help included with the HP Web Jetadmin software.

Troubleshooting Wireless Print Servers

Unable to Communicate During Initial Setup

If you are using wireless communications to set up the print server, verify the following:

- Your wireless computer is configured to match the default wireless network settings on the HP Jetdirect print server:
 - Communication Mode: Ad Hoc
 - Network Name (SSID): hpsetup
 - Encryption (WEP): <Disabled>

Note	The Network Name (SSID) is case-sensitive. Be sure to specify “hpsetup” using lowercase characters.
-------------	---

- The HP Jetdirect print server is turned on and operating properly (print a Jetdirect configuration page).
- You are within range of the HP Jetdirect print server.
- There are fewer than six devices total on the Ad Hoc network (with SSID “hpsetup”).
- There is no Access Point in the vicinity that is configured with an SSID of “hpsetup”.
- Multiple print servers are not being configured at the same time. If there are multiple print servers, turn all off except the one you want to configure.

Unable to Communicate After Initial Setup

If you have successfully configured the HP Jetdirect wireless print server with a network connection to your network, but your network computers are unable to communicate with the printer (including a “ping” command), try the following:

- Print a Jetdirect configuration page and verify all configuration settings for your network. Common errors include incorrect entries for the following items:
 - Communication Mode (Ad Hoc or Infrastructure)
 - Network Name (SSID), which is case-sensitive
 - Authentication method
 - Encryption level, encryption key entries, or the specified transmit key
 - IP address
 - BSSID (Basic Service Set Identifier), which distinguishes one wireless LAN from another even though they have the same SSID
- Verify that the printer is within range of the network. See [“Improving Reception and Performance”](#) in this chapter.
- Use a wireless PC and its utilities to confirm the signal strength at the printer’s location. The detected signal strength should be similar for the print server, as indicated on the HP Jetdirect configuration page.

My Configured Channel Does Not Match the Configuration Page

(Ad Hoc mode only) The HP configuration tools allow you to select channel 10 or 11 (default) on the HP Jetdirect wireless print server. This channel is only used by the print server to broadcast its Network Name (SSID) if it fails to detect and join an existing wireless network. If it is able to join a network, it will reconfigure its channel to the one used by the network.

The Jetdirect configuration page will identify the network channel actually being used on a network. It does not show the broadcast channel used when a network is not detected.

Unable to Use the HP Jetdirect Install Network Printer Wizard

The wizard (Windows) is used to configure the HP Jetdirect wireless print server with wireless network connection settings to access your network.

If you are unable to use this wizard, try other configuration tools. Other tools available include:

- the embedded Web server (see [Chapter 4](#))
- Telnet (see [Chapter 3](#))

Note	The configurable parameters available through these optional tools may be limited.
-------------	--

Improving Reception and Performance

Wireless LAN radio signals can penetrate many indoor structures and can reflect around obstacles. However, wireless communication range and performance depends on a variety of factors, including the number of users, the quality and physical placement of the wireless hardware, and the sources of radio signal interference (for example, microwave ovens and cordless telephones use similar frequencies that may interfere with wireless LAN signals). In general, the HP Jetdirect wireless print server's data transfer rates will decrease with increasing distance, obstructions and interference.

Symptoms

- The signal strength (see the HP Jetdirect configuration page or embedded Web server) is poor or marginal.
- Print jobs are excessively slow.

Corrective Actions

- Re-orient the printer or HP Jetdirect wireless print server. In general, having the print server pointed toward the Access Point or wireless PC will improve reception and performance.

- Reduce or remove sources of interference. Metallic objects can absorb or attenuate radio signals, and devices such as microwave ovens and cordless phones operate using similar radio frequencies.
- Reduce the distance between the printer and the Access Point or wireless PC. This can be accomplished by:
 - moving the printer
 - moving the Access Point or wireless PC
 - adding an additional Access Point (Infrastructure mode only)
- Elevate the Access Point's antenna. In most office environments, elevating the Access Point's antenna will improve the range and performance of all wireless devices.

Firmware Download Failure

HP ew2400 firmware upgrades must be performed through a wired/cable connection. As with other HP Jetdirect print servers, firmware upgrades may be downloaded using tools such as HP Download Manager (Windows), HP Web Jetadmin, or FTP (File Transfer Protocol).

If a firmware download failure occurs on an HP Jetdirect wireless print server, simply restart the download process and try again. If it is powered off/on, the print server will regain its previous configuration prior to the download failure.

Troubleshooting an LPD UNIX Configuration

Note For HP Jetdirect wireless print servers, this section assumes that a wireless connection to your network has been established.

The troubleshooting steps below describe how to troubleshoot printing problems you may have with the HP Jetdirect print server.

1. Print a Jetdirect configuration page.
2. Verify that the IP configuration values are correct. If they are not, reconfigure the HP Jetdirect print server.
3. Log onto the host system and type:

```
ping <IP address>
```

where <IP address> is the IP Address assigned to the printer.

4. If ping fails, make sure the IP Address on the configuration page is correct. If it is correct, the problem is in the network.
5. If the ping test passes, print a test file. At the UNIX prompt, type:

```
lpr -Pprinter_name test_file (BSD-based and Linux systems)
```

where `printer_name` is the name of your printer and `test_file` is an appropriate file (ASCII, PCL, PostScript, HP-GL/2, or text) for the printer defined in the `:rp` tag in the `printcap` file.

6. If the test file does not print, do the following:
 - Check `printcap` entries.
 - Check printer status (using LPC or a similar process).
 - Examine the contents of the logfile for this printer, such as `/usr/spool/lpd/error_log_filename`
 - Check other log files, such as
HP-UX: `/usr/adm/syslog`

7. If the test file prints but is formatted incorrectly, do the following:
 - Check :rp tag in printcap file.

Example 1 (suggested name for an ASCII or text printer):

```
text | ljl_text:\
:lp=:\
:rm=laserjet1:\
:rp=text:\
:lf=/usr/spool/lpd/ERRORLOG:\
:sd=/usr/spool/lpd/ljl_text:
```

Example 2 (suggested name for PostScript, PCL, or HP-GL/2 printers):

```
raw | ljl_raw:\
:lp=:\
:rm=laserjet:\
:rp=raw:\
:lf=/usr/spool/lpd/ERRORLOG:\
:sd=/usr/spool/lpd/ljl_raw:
```

8. Check that the printer is set up to print the type of test file you specified: PCL, PostScript, HP-GL/2, or ASCII.
9. Check whether the printer was turned off or lost its LAN connection in the middle of a print job. LPD queues may become disabled or stop sending data if the printer is powered off or if the LAN connection is broken when the printer is in the middle of printing a job. (Example: power is turned off to fix a paper jam.)

Use the HP-UX command `lpstat -Pqname` to find out if the queue has been disabled after the printer has powered up again or the connection is reestablished.

The disabled queue can be restarted using the following command:

HP-UX: `enable qname`

HP Jetdirect Configuration Page

Introduction

The HP Jetdirect configuration page is an important tool for managing or troubleshooting HP Jetdirect print servers. This page provides identification information (such as the HP Jetdirect model, firmware version, and LAN hardware address), as well as status and configuration parameters of supported network protocols. Network statistics gathered by the print server are also provided.

The HP Jetdirect configuration page may be printed directly on the attached printer. The format of the Jetdirect configuration page depends on:

- the printer model
- the HP Jetdirect model and firmware version

For HP Enhanced I/O (EIO) printers with an HP Jetdirect EIO print server installed, a Jetdirect configuration page will automatically print after a printer configuration page is printed. For instructions, see your printer manuals.

An HP Jetdirect configuration page can also be viewed over the network from a management utility (such as HP Web Jetadmin), or by accessing the embedded Web server on the HP Jetdirect print server (see [Chapter 4](#)).


Status Field Error Messages

The HP Jetdirect configuration page contains several status fields for the print server and the supported protocols. One or more error codes and related error messages may be displayed in a Status field. For information on each error message, see [Table 9.11](#).

Configuration Page Format

A typical Jetdirect configuration page is illustrated in [Figure 9.1](#). The configuration page information provided will vary depending on the print server.

Figure 9.1 Typical Jetdirect Configuration Page



The Jetdirect configuration page is divided into sections, as identified in the following table. For each section, the detailed parameter descriptions and settings, including error messages, are provided in the remainder of this chapter.

Section Name	Description
HP Jetdirect Configuration or General Information	Identifies the HP Jetdirect print server and provides general status. For information on items in this section, see Table 9.1 . (For error messages, see Table 9.11 .)
USB Printer Information	(HP Jetdirect external print servers only) Provides current status of the USB connection to the printer. See Table 9.2 . (For error messages, see Table 9.11 .)
802.11 Wireless	Provides current status of the wireless connection, and identifies the current wireless network parameters configured. See Table 9.3 . Error messages are also included in the table.)
Security Settings	Provides the current status of configuration and access security parameters. See Table 9.4 .
Network Statistics	(HP Jetdirect wired print servers only) Provides the current values for various network parameters monitored by the HP Jetdirect print server. See Table 9.5 .
TCP/IP	Provides the current status and parameter values for the TCP/IP network protocols. See Table 9.6 . (For error messages, see Table 9.11 .)
IPX/SPX	Provides the current status and parameter values for the IPX/SPX network protocols. See Table 9.7 . (For error messages, see Table 9.11 .)
Novell/NetWare	Provides the current status and parameter values for a Novell NetWare network. See Table 9.8 . (For error messages, see Table 9.11 .)
AppleTalk	(Ethernet Only) Provides the current status and parameter values for the AppleTalk network protocols. See Table 9.9 . (For error messages, see Table 9.11 .)
DLC/LLC	Provides the current status and parameter values for the DLC/LLC network protocols. See Table 9.10 . (For error messages, see Table 9.11 .)

Configuration Page Messages

HP Jetdirect Configuration/General Information

Information in this section provides general HP Jetdirect print server configuration as described in [Table 9.1](#). For error messages, see [Table 9.11](#).

Table 9.1 HP Jetdirect Configuration (1 of 2)

Message	Description
STATUS:	<p>Current state of the HP Jetdirect print server.</p> <p>I/O CARD READY, or READY: The HP Jetdirect print server has successfully connected to the network and is awaiting data.</p> <p>I/O CARD INITIALIZING, or INITIALIZING: The HP Jetdirect print server is initializing the network protocols. For more information, see the status line for each protocol on the configuration page.</p> <p>I/O CARD NOT READY, or ERROR: There is a problem with the print server or its configuration.</p> <p>An error code and message is displayed if the print server is not ready. For more information, see Table 9.11.</p>
MODEL NUMBER:	The model number of the HP Jetdirect print server (for example, J7951A)
HARDWARE ADDRESS:	The 12-digit hexadecimal network hardware (MAC) address of the HP Jetdirect print server installed in the printer or device. This address is assigned by the manufacturer.
FIRMWAREVERSION:	The firmware revision number of the HP Jetdirect print server currently installed in the printer.
NETWORK CONNECTION TYPE	(ew2400) Specifies the type of network connection: Wireless or Wired.
DATA RATE DETECTED	(ew2400) Specifies the network data rate depending on the type of network connection: 1 - 54 Mbps (Wireless 802.11g) 10 Mbs, 100 Mbps (Wired 10/100Base-TX)
LINK CONFIG	(ew2400) Specifies the active link communication mode: 802.11: Wireless 802.11g 10T HALF: 10 Mbps, half-duplex (wired port) 10T FULL: 10 Mbps, full-duplex (wired port) 100TX HALF: 100Mbps, half-duplex (wired port) 100TX FULL: 100Mbps, full-duplex (wired port)

Table 9.1 HP Jetdirect Configuration (2 of 2)

Message	Description
PORT SELECT:	(Ethernet only) Specifies the port on the HP Jetdirect print server that has been detected for use: NONE: The print server is not connected to the network. RJ-45: The RJ-45 network port is connected.
LAA	The Locally Administered Address (LAA) identifies the user-specified LAN hardware address of a print server, which may be required by some network administrators. The default address is the print server's factory-default LAN hardware address.
PORT CONFIG:	Identifies the link configuration of the RJ-45 port on the HP Jetdirect 10/100Base-TX print server: 10BASE-T HALF: 10 Mbps, half-duplex 10BASE-T FULL: 10 Mbps, full-duplex 100TX HALF: 100Mbps, half-duplex 100TX-FULL: 100Mbps, full-duplex UNKNOWN: The print server is in an initialization state. DISCONNECTED: A network connection has not been detected. Check network cables.
AUTONEGOTIATION	Identifies whether IEEE 802.3u Autonegotiation on the HP Jetdirect 10/100TX port is enabled (ON) or disabled (OFF). ON (default): The HP Jetdirect print server will attempt to automatically configure itself onto the network at the proper speed (10 or 100 Mbps) and mode (half or full duplex). Autonegotiation is enabled after a cold reset. OFF: You must manually configure the speed and mode using the EIO menu from the printer's control panel. If Autonegotiation is off, the settings must match those of the network for proper operation.
MANUFACTURING ID:	The manufacturing identification code for use by HP online support personnel.
DATE MANUFACTURED:	Identifies the date of manufacture of the HP Jetdirect print server.

USB Printer Settings

This section applies to HP Jetdirect external print servers with USB printer connections only. USB information on the HP Jetdirect configuration page is described in [Table 9.2](#). For non-HP devices, some information may not be available.

Table 9.2 USB Settings

Message	Description
Device Name	Name of the attached USB printing device, supplied by the manufacturer.
Manufacturer	Manufacturer of the attached printing device.
Serial Number	The Manufacturer's serial number for the attached printing device.
Communication Mode	<p>Current USB communication mode:</p> <ul style="list-style-type: none">● 1284.4: IEEE standard protocol, a mode for printers and multi-function (All-in-One) devices that allows multiple channels of simultaneous print, scan, and status communication.● MLC: HP-proprietary protocol for Multiple Logical Channels, a mode for printers and multi-function (All-in-One) devices that allows multiple channels of simultaneous print, scan, and status communication.● Bidirectional: Two-way printer communication, sending print data to the printing device and returning status information from the printing device.● Unidirectional: One-way communication to the printing device.● Device not found: The connection of a printing device has not been detected. Check device and cable.● Device not supported: The device connected is not a printer (for example, a camera).
USB SPEED	<p>(USB 2.0 print servers only) Specifies the autonegotiated communication speed over the USB connection between the print server and the device.</p> <p>Full Speed: 12 Mbits/sec as specified in the USB v2.0 specifications, compatible with USB v1.1 specifications.</p> <p>Hi-Speed: 480 Mbits/sec for USB v2.0 devices only.</p> <p>Disconnected: The USB port is not connected.</p>

802.11 Wireless Settings

Wireless status, configuration parameters and error messages are listed in [Table 9.3](#).

Table 9.3 802.11 Wireless Settings (1 of 3)

Message	Description
Status	<p>Current 802.11 wireless configuration status.</p> <p>Ready: A wireless connection to the network has been established.</p> <ul style="list-style-type: none">● Infrastructure Mode: Associated with an Access Point and authenticated on the network.● Ad Hoc Mode: Wireless communications established directly with other network devices (Access Points are not used in Ad Hoc Mode). <p>Initializing: The print server is booting up, performing self-tests, and verifying internal communications.</p> <p>Scanning: The print server is scanning for the specified network. Status or error messages that may also be displayed are listed below.</p> <ul style="list-style-type: none">● Infrastructure Mode: The print server is scanning on all channels for a network (Access Point) with the specified SSID.● Ad Hoc Mode: The print server is scanning on all channels for a network with the specified SSID, or has created a workgroup to which no one has joined. <p>Error: A wireless connection error has occurred that prevents association or authentication with an Access Point (Infrastructure Mode), or prevents a connection to an Ad Hoc network. Status or error messages that may also be displayed are listed below.</p> <p>Status/Error Messages</p> <ul style="list-style-type: none">● NO SIGNAL DETECTED: (Infrastructure Mode only) The print server did not find an Access Point and did not detect a radio signal.● SCANNING FOR SSID: The print server is scanning on all channels for devices on the specified SSID. Check your specified SSID, or check status of the Access Point (Infrastructure mode) or other wireless devices. The print server will continue to scan for the specified SSID.

Table 9.3 802.11 Wireless Settings (2 of 3)

Message	Description
	<ul style="list-style-type: none"> ● AUTHENTICATION IN PROGRESS: Link-level authentication is in progress. In Infrastructure mode, server-based authentication may also be in progress. ● AUTHENTICATION FAILED: The Jetdirect print server could not access the network because of an authentication error. The error depends on the authentication method used. Verify the authentication method using the “Authentication Type” field. ● ENCRYPTION REQUIRED: Encryption is required on this network, but encryption has not been enabled on the Jetdirect print server. Verify encryption configuration.
Communication Mode	<p>Specifies the wireless network topology configured on the Jetdirect print server:</p> <p>Infrastructure: Wireless connection to an Access Point (gateway, bridge, Base Station) that receives and forwards network traffic between all network nodes.</p> <p>Ad Hoc: A direct wireless peer-to-peer connection to all network nodes, without routing through an Access Point.</p>
Network Name (SSID)	Identifies the name of the network (Service Set Identifier) to which the print server has connected.
Signal Strength (1-5)	<p>The strength of the radio signal received by the print server. The following items may be displayed:</p> <p>Level 1(Poor), Levels 2 and 3 (Marginal), Level 4 (Good), Level 5 (Excellent)</p> <p>No Signal: Level 0, No radio signal detected on any channel.</p> <p><blank>: No radio signal detected while the print server is scanning.</p> <p>Not Applicable: Signal strength is not applicable when the print server is in Ad Hoc mode.</p>
Access Point / BSSID	<p>Basic Service Set Identifier (BSSID) is a 6-byte number that distinguishes one wireless LAN (WLAN) from another, even if they have the same Network Name (SSID).</p> <p>Infrastructure Mode: The MAC address or name of the Access Point to which the Jetdirect wireless print server is connected.</p> <p>Ad Hoc Mode: A random number or name generated by the initiator of the Ad Hoc network.</p>

Table 9.3 802.11 Wireless Settings (3 of 3)

Message	Description
Channel	<p>Specifies the radio frequency channel that the print server sensed and configured for communication on the network. Because it was automatically sensed from the network, this channel may differ from the user-configured channel (which is only used for broadcasts if the specified network/SSID is not found).</p> <p>Channel number values 1 through 14 may be displayed. The allowed channels are country/region-dependent.</p>
Authentication Type	<p>Identifies the authentication method configured on the Jetdirect print server. It must match the method used on the network to which the print server will connect.</p> <p>Open System: Positive validation of a device's identification is not required for network access unless the network requires EAP authentication. An authentication failure may indicate that an EAP authentication server has rejected network access.</p> <p>Shared Key: Each device on the network must be configured with a shared secret WEP key to gain access to the network. Authentication failures for the Jetdirect print server may arise if the installed key is faulty, or the wrong key is active (when multiple keys are configured and stored on the print server).</p> <p>WPA-PSK: For enhanced security, Wi-Fi Protected Access using a Pre-shared key is configured, typically when the use of an authentication server is not supported. The Pre-shared key is generated by the print server through a user-specified network pass-phrase configured on the print server.</p>
Encryption Type	<p>Specifies the level of encryption configured on the Jetdirect print server.</p> <p>64-bit WEP: A user-specified static 40/64-bit WEP encryption key has been configured using 5 alphanumeric ASCII characters or 10 hexadecimal digits.</p> <p>128-bit WEP: A user-specified static 104/128-bit WEP encryption key has been configured using 13 alphanumeric ASCII characters or 26 hexadecimal digits.</p> <p>Dynamic: WPA dynamic encryption protocols are being used.</p> <p>None: Encryption keys have not been configured.</p>

Security Settings

Information in this section of the Jetdirect configuration page is described in [Table 9.4](#).

Table 9.4 Security Settings (1 of 3)

Message	Description
802.1X	Identifies whether the print server has been configured with EAP/802.1X client authentication settings. Specified: 802.1X authentication has been configured. Not Specified: 802.1X authentication has not been configured.
Admin Password:	Specifies whether an IP Administrator password has been configured on the print server. This password is shared by Telnet, the embedded Web server, and HP Web Jetadmin to control access to print server configuration parameters. Up to 16 case-sensitive, alphanumeric characters can be used. Not Set: An Administrator password has not been set. Set: An Administrator password has been set. (The password may be cleared from the print server through a cold reset.)
SSL/TLS	Status of Secure Sockets Layer/Transport Layer Security (SSL/TLS) protocols. Disabled: SSL/TLS is disabled. <certificate string>: A character string that identifies the certificate common name.
Cert Expires:	Specifies the expiration date of the digital certificate for SSL/TLS encrypted security. The date is in UTC format (for example, "2002-10-02 12:45 UTC"). Not Applicable: Displayed if a digital certificate has not been installed.

Table 9.4 Security Settings (2 of 3)

Message	Description
SNMP Versions:	<p>Specifies the SNMP versions enabled on the print server.</p> <p>Disabled: All SNMP versions are disabled on the print server. No SNMP access is allowed.</p> <p>1;2: SNMP v.1 and SNMP v.2c are supported, and SNMP v.3 is disabled, or not supported.</p> <p>1;2;3-na/np: SNMP v.1, v.2c, and v.3 are enabled. v.3 is enabled with the minimum security of no authentication ("na") and no privacy ("np").</p> <p>1;2;3-a/np: SNMP v.1, v.2c, and v.3 are enabled. v.3 is enabled with the minimum security of authentication enabled ("a") but no privacy ("np").</p> <p>1;2;3-a/p: SNMP v.1, v.2c, and v.3 are enabled. v.3 is enabled with the minimum security of authentication ("a") with privacy ("p") enabled.</p> <p>3-na/np: SNMP v.1 and v.2c are disabled. SNMP v.3 is enabled with the minimum security of no authentication ("na") and no privacy ("np").</p> <p>3-a/np: SNMP v.1 and v.2c are disabled. SNMP v.3 is enabled with the minimum security of authentication enabled ("a") but no privacy ("np").</p> <p>3-a/p: SNMP v.1 and v.2c are disabled. SNMP v.3 is enabled with the minimum security of authentication ("a") with privacy ("p") enabled.</p>
SNMP Set Cmty Name:	<p>Specifies whether an SNMP set community name has been configured on the HP Jetdirect print server. An SNMP set community name is a password for write access to SNMP control functions (SNMP SetRequests) on the HP Jetdirect print server.</p> <p>Not Specified: An SNMP set community name has not been set.</p> <p>Specified: A user-specified SNMP set community has been set.</p>

Table 9.4 Security Settings (3 of 3)

Message	Description
Access List:	<p>Identifies whether a host access control list is configured on the HP Jetdirect print server. A host access control list specifies the IP address of individual systems, or IP network of systems, that are allowed access to the print server and device.</p> <p>Specified: A host access list is configured on the HP Jetdirect print server.</p> <p>Not Specified: A host access list is not configured on the print server. All systems are allowed access.</p>
Secure Web:	<p>Specifies the use of encrypted communications between a browser and the HP Jetdirect embedded Web server.</p> <p>Optional (HTTPS/HTTP): Allows unencrypted communications using standard HTTP ports, as well as encrypted communications using HTTPS (secure HTTP).</p> <p>HTTPS Required: Only encrypted communications on HTTPS is allowed.</p>

Network Statistics

Information in this section of the Jetdirect configuration page is described in [Table 9.5](#).

Table 9.5 Network Statistics

Message	Description
TOTAL PACKETS RECEIVED:	Total number of frames (packets) received by the HP Jetdirect print server without error. This includes broadcast, multicast packets, and packets specifically addressed to the print server. This number does not include packets specifically addressed to other nodes.
UNICAST PACKETS RECEIVED:	Number of frames specifically addressed to this HP Jetdirect print server. This does not include broadcasts or multicasts.
BAD PACKETS RECEIVED:	Total number of frames (packets) received with errors by the HP Jetdirect print server.
FRAMING ERRORS RECEIVED:	Maximum of CRC (Cyclic Redundancy Check) errors and framing errors. CRC errors are frames received with CRC errors. Framing errors are frames received with alignment errors. A large number of framing errors could indicate a cabling problem with your network.
TOTAL PACKETS TRANSMITTED:	Total number of frames (packets) transmitted without error.
UNSENDABLE PACKETS:	Total number of frames (packets) not successfully transmitted because of errors.
TRANSMIT COLLISIONS:	Number of frames not transmitted because of repeated collisions.
TRANSMIT LATE COLLISIONS:	Total number of frames not transmitted because a late collision occurred. Late collisions often occur when cable lengths exceed network specifications. A large number may indicate a cabling problem on the network.

TCP/IP Protocol Information

Information in this section of the Jetdirect configuration page is described in [Table 9.6](#). For error messages, see [Table 9.11](#).

Table 9.6 TCP/IP Configuration Information (1 of 4)

Message	Description
STATUS:	<p>Current TCP status.</p> <p>READY: Indicates the HP Jetdirect print server is awaiting data over TCP/IP.</p> <p>DISABLED: Indicates that TCP/IP was manually disabled.</p> <p>INITIALIZING: Indicates that the print server is searching for the BOOTP server, or trying to get the configuration file through TFTP. An additional status message may also be displayed.</p> <p>An error code and message is displayed if the print server is not ready. For more information, see Table 9.11.</p>
HOST NAME:	<p>The host name configured on the print server. It may be truncated.</p> <p>NOT SPECIFIED: Indicates that no host name was specified in a BOOTP response or TFTP configuration file.</p> <p>NPIxxxxxx: The default name is NPIxxxxxx, where xxxxxx represents the last six digits of the LAN hardware (MAC) address.</p>
IP ADDRESS:	<p>The Internet Protocol (IP) address assigned to the HP Jetdirect print server. This is a required entry for operation of the print server on a TCP/IP network. During initialization, a temporary value 0.0.0.0 is displayed. After two minutes, a default IP address 169.254/16 or 192.0.0.192 is assigned.</p> <p>NOT SPECIFIED: Indicates that an IP address is not assigned or the value is zero.</p>
SUBNET MASK:	<p>The IP subnet mask configured on the HP Jetdirect print server. During initialization, a temporary value 0.0.0.0 is displayed. Depending on configuration parameters, the print server may automatically assign a usable default value.</p> <p>NOT SPECIFIED: Indicates that a subnet mask is not configured.</p>

Table 9.6 TCP/IP Configuration Information (2 of 4)

Message	Description
DEFAULT GATEWAY:	<p>The IP address of the gateway used when sending packets off the local network. Only one default gateway may be configured. During initialization, a temporary value 0.0.0.0 is displayed. If not provided, the IP address of the Jetdirect print server is used.</p> <p>NOT SPECIFIED: Indicates that a default gateway is not configured.</p>
CONFIG BY:	<p>Identifies how the HP Jetdirect print server obtained its IP configuration:</p> <p>BOOTP: Automatic configuration through a BOOTP server.</p> <p>BOOTP/TFTP: Automatic configuration through a BOOTP server and TFTP configuration file.</p> <p>DHCP: Automatic configuration through a DHCP server</p> <p>DHCP/TFTP: Automatic configuration through a DHCP server and TFTP configuration file.</p> <p>RARP: Automatic configuration through the Reverse Address Resolution Protocol.</p> <p>USER SPECIFIED: Manual configuration through Telnet, the printer's control panel, HP Web Jetadmin, embedded Web server, or other method.</p> <p>DEFAULT IP: The default IP address was assigned. This address may not be a valid address for your network.</p> <p>AUTO IP: A link-local IP address (169.254.x.x) was assigned. If the network is a link-local network, this address should be valid.</p> <p>NOT CONFIGURED: The print server was not configured with IP parameters. Verify that TCP/IP is enabled, or check for error status.</p>
BOOTP SERVER: or DHCP SERVER: or RARP SERVER:	<p>Displayed if BOOTP, DHCP, or RARP is used for TCP/IP configuration. It specifies the IP address of the system that responds to the HP Jetdirect print server's request for automatic TCP/IP configuration over the network.</p> <p>NOT SPECIFIED: Indicates that the configuration server's IP address could not be determined or was set to zero in the response packet.</p>
BOOTP/DHCP SERVER:	<p>Displayed during initialization while the HP Jetdirect print server attempts to obtain its TCP/IP configuration from a BOOTP or DHCP server. The temporary address displayed is 0.0.0.0.</p>

Table 9.6 TCP/IP Configuration Information (3 of 4)

Message	Description
TFTP SERVER:	The IP address of the system where the TFTP configuration file is located. During initialization, the temporary address 0.0.0.0 is displayed. NOT SPECIFIED: Indicates that a TFTP server has not been not been set.
CONFIG FILE:	The name of the HP Jetdirect configuration file. The file pathname may be truncated to fit on two lines. NOT SPECIFIED: Indicates that a file was not specified in the BOOTP reply from the host.
DOMAIN NAME:	The Domain Name System (DNS) name of the domain in which the HP Jetdirect print server resides (for example, support.company.com). It is not the fully qualified DNS name (for example, printer1.support.company.com) because the host printer name is not included. NOT SPECIFIED: Indicates that a domain name has not been configured on the print server.
DNS SERVER:	The IP address of the Domain Name System (DNS) server. NOT SPECIFIED: Indicates that a DNS server's IP address has not been configured on the print server.
WINS SERVER:	The IP address of the Windows Internet Naming Service (WINS) server. NOT SPECIFIED: Indicates that a WINS server's IP address has not been configured on the print server.
SYSLOG SERVER:	The IP address of the syslog server configured on the print server. NOT SPECIFIED: Indicates that a syslog server has not been configured.
IDLE TIMEOUT:	The timeout value expressed in seconds after which the print server closes an idle TCP print data connection. Acceptable values are integers between 0 and 3600. A value of zero turns off the timeout mechanism. The default value is 270 seconds.
SLP:	Specifies whether the HP Jetdirect print server sends Service Location Protocol (SLP) packets used by system applications for automated installation. ENABLED: The print server sends SLP packets. DISABLED: The print server does not send SLP packets.

Table 9.6 TCP/IP Configuration Information (4 of 4)

Message	Description
WEB JETADMIN URL:	<p>If the HP Jetdirect print server is found on the network by HP Web Jetadmin, the URL of the host system used for HP Web Jetadmin services is displayed. The URL is limited to two lines and may be truncated.</p> <p>NOT SPECIFIED: Indicates that the URL of the Web Jetadmin host system could not be identified or is not configured.</p>

IPX/SPX Protocol Information

Information in this section of the Jetdirect configuration page is described in [Table 9.7](#). For error messages, see [Table 9.11](#).

Table 9.7 IPX/SPX Configuration Information (1 of 2)

Message	Description
STATUS:	<p>Indicates the current IPX/SPX protocol status.</p> <p>READY: Indicates the HP Jetdirect print server is awaiting data over IPX/SPX.</p> <p>DISABLED: Indicates that IPX/SPX was manually disabled.</p> <p>INITIALIZING: Indicates that the print server is registering the node address or name. An additional status message may also be displayed.</p> <p>An error code and message is displayed if the print server is not ready. For more information, see Table 9.11.</p>
PRIMARY FRAME TYPE:	<p>Specifies the frame type selection on the Jetdirect print server.</p> <p>AUTO SELECT: The print server automatically senses and limits the frame type to the first one detected.</p> <p>EN_8023: Limits the frame type to IPX over IEEE 802.3 frames. All others will be counted and discarded.</p> <p>EN_II: Limits the frame type to IPX over Ethernet frames. All others will be counted and discarded.</p> <p>EN_8022: Limits the frame type to IPX over IEEE 802.2 with IEEE 802.3 frames. All others will be counted and discarded.</p> <p>EN_SNAP: Limits the frame type to IPX over SNAP with IEEE 802.3 frames. All others will be counted and discarded.</p>

Table 9.7 IPX/SPX Configuration Information (2 of 2)

Message	Description
<p>NETWORK</p> <p>XXXXXX</p> <p>XXXXXX</p> <p>XXXXXX</p> <p>XXXXXX</p>	<p>The first column (Network) indicates the network number associated with a protocol frame type used for communication between a server and the HP Jetdirect print server.</p> <p>UNKNOWN: Indicates that the HP Jetdirect print server is still trying to determine which network number to use.</p>
<p>FRAME TYPE</p> <p>XXXXX</p> <p>XXXXX</p> <p>XXXXX</p> <p>XXXXX</p>	<p>The second column (Frame Type) identifies the frame type used with the associated network number:</p> <p>EN_8023, EN_8022, EN_II, EN_SNAP. Unless a specific frame type has been manually configured, the print server automatically determines the protocol frame type by listening to the network data being transferred over the network.</p> <p>DISABLED: Indicates that a specific frame type for that network has been manually configured.</p>
<p>RCVD</p> <p>XXXX</p> <p>XXXX</p> <p>XXXX</p> <p>XXXX</p>	<p>The third column (RCVD) indicates how many packets have been received for each frame type.</p>

Novell NetWare Parameters

Information in this section of the Jetdirect configuration page is described in [Table 9.8](#). For error messages, see [Table 9.11](#).

Table 9.8 Novell NetWare Configuration Information (1 of 2)

Message	Description
STATUS:	<p>Indicates the current Novell NetWare configuration status.</p> <p>READY: Indicates the HP Jetdirect print server is awaiting data.</p> <p>DISABLED: Indicates that IPX/SPX was manually disabled.</p> <p>INITIALIZING: Indicates that the print server is registering the node address or name. An additional status message may also be displayed.</p> <p>An error code and message is displayed if the print server is not ready. For more information, see Table 9.11.</p>
NODE NAME:	<p>Queue Server Mode: The print server name. This name must match a valid print server on the appropriate NetWare file server. The default name is NPIXXXXXX, where XXXXXX is the last six digits of the LAN hardware (MAC) address.</p> <p>Remote Printer Mode: The name you gave the network printer when you configured the network printer. The default name is NPIXXXXXX.</p>
NETWARE MODE:	<p>The mode used by the HP Jetdirect print server.</p> <p>QUEUE SERVER: Indicates that the print server receives data directly from the queue.</p> <p>REMOTE PRINTER (followed by the printer number): Indicates that the print server emulates a Novell NetWare remote printer.</p> <p>If the printer is not configured, this field displays QUEUE SERVER.</p>
NDS TREE NAME:	<p>Displays the name of the Novell Directory Services (NDS) tree for this printer. NDS is a database of objects on a NetWare network organized in a hierarchical tree structure.</p> <p>NOT SPECIFIED or blank: NDS is disabled.</p>
NDS CONTEXT:	<p>Displays the fully qualified NDS name where the HP Jetdirect print server object resides in the NDS tree. For example:</p> <p>CN=lj_pserver.OU=support.OU=mycity.OU=mycompany</p> <p>NOT SPECIFIED or blank: NDS is disabled.</p>

Table 9.8 Novell NetWare Configuration Information (2 of 2)

Message	Description
ATTACHED SERVER:	The Attached Server field identifies the Jetdirect discovery method [NSQ] (Nearest Service Query) or [GSQ] (General Service Query) and the name of the proxy file server used to locate the configured bindery servers. NOT SPECIFIED or blank: A NetWare server has not been configured.
QUEUE POLL INTERVAL	(Job Poll Interval) Specifies the time interval (seconds) that the HP Jetdirect print server waits to check for print jobs in a print queue. The default is 2 seconds.
SAP INTERVAL:	Specifies the time interval (seconds) that the HP Jetdirect print server waits between Service Advertising Protocol (SAP) broadcasts on the network. The default is 60 seconds.
SERVER x:	Identifies a NetWare file server to which the HP Jetdirect print server is attached.

AppleTalk Protocol Information

Information in this section of the Jetdirect configuration page (Ethernet Only) is described in [Table 9.9](#). For error messages, see [Table 9.11](#).

Table 9.9 AppleTalk Configuration Information

Message	Description
STATUS:	Indicates the current AppleTalk configuration status. READY: Indicates the HP Jetdirect print server is awaiting data. DISABLED: Indicates that AppleTalk was manually disabled. INITIALIZING: Indicates that the print server is registering the node address or name. An additional status message may also be displayed. An error code and message is displayed if the print server is not ready. For more information, see Table 9.11 .
NAME:	The name of the printer on the AppleTalk network. A number after the name indicates that there are multiple devices with this name, and this is the Nth instance of the name.
ZONE:	The name of the AppleTalk network zone on which the printer is located.
TYPE:	The type of the printer being advertised on the network. Two types can be displayed.
NETWORK NUMBER: NODE NUMBER:	NETWORK NUMBER: Identifies the AppleTalk Network Number on which the HP Jetdirect print server is currently operating. NODE NUMBER: Identifies the AppleTalk Node Number that the print server chose for itself as part of its initialization sequence. Note: The AppleTalk phase 2 (P2) parameter is preconfigured on the HP Jetdirect print server.

DLC/LLC Protocol Information

Information in this section of the Jetdirect configuration page is described in [Table 9.10](#).

Table 9.10 DLC/LLC Configuration Information

Message	Description
STATUS:	<p>Indicates the current DLC/LLC protocol status.</p> <p>READY: Indicates the HP Jetdirect print server is awaiting data.</p> <p>DISABLED: Indicates that DLC/LLC was manually disabled.</p> <p>INITIALIZING: Indicates that the print server is registering the node address or name. An additional status message may also be displayed.</p> <p>An error code and message is displayed if the print server is not ready. For more information, see Table 9.11.</p>

Error Messages

Error codes and messages that may appear in the Status sections of the Jetdirect configuration page are described in [Table 9.11](#).

Table 9.11 Error Messages (1 of 11)

Error Code and Message	Description
02 LAN ERROR - INTERNAL LOOPBACK	During self-test, the HP Jetdirect print server detected an internal loopback test error. The print server may be faulty. If the error persists, replace the HP Jetdirect print server.
03 LAN ERROR - EXTERNAL LOOPBACK	The HP Jetdirect print server is incorrectly connected to your network or is defective. Make sure your HP Jetdirect print server is correctly attached to your network. In addition, check the cabling and connectors.
05 NO SIGNAL DETECTED	(802.11 Wireless, Infrastructure Mode only) The print server did not find an Access Point and did not detect a radio signal. Check for sources of radio signal interference. If possible, elevate the print server or the external antenna (if applicable). Verify other wireless devices are turned on and located in wireless signal range of the print server.
06 ENCRYPTION REQUIRED	Encryption is required on this network, but the print server cannot communicate on the network due to improper encryption settings. Check the encryption settings configured on the print server.
07 LAN ERROR - CONTROLLER CHIP	Check the network connections. If the connections are intact, run the power-on self-test: turn the printer off, then on again. If the error persists, replace the HP Jetdirect print server.
07 AUTHENTICATION FAILED	The Jetdirect print server could not access the network because of an authentication error. The error depends on the authentication method used. Verify the authentication method and settings on the print server.
08 LAN ERROR - INFINITE DEFERRAL	There is a network congestion problem. Note: If the print server is not connected to the network, this error cannot occur.
08 AUTHENTICATION IN PROGRESS	Link-level authentication is in progress.
09 LAN ERROR - BABBLE	Check the network connections. If the connections are intact, run the power-on self-test: turn the printer off, then on again. If the error persists, replace the HP Jetdirect print server. For replacement instructions, see the hardware installation guide for your print server.

Table 9.11 Error Messages (2 of 11)

Error Code and Message	Description
09 SCANNING FOR SSID	(802.11 Wireless) The print server is scanning on all channels for devices on the specified SSID (network name). Check your specified SSID, or check status of the Access Point (Infrastructure mode) or other wireless devices. The print server will continue to scan for the specified SSID.
0A LAN ERROR - NO SQE	(Wired Ethernet) Check the network connections. If the connections are intact, run the power-on self-test: turn the printer off, then on again. If the error persists, replace the HP Jetdirect print server.
0C LAN ERROR - RECEIVER OFF	There may be a problem with your network cabling or the HP Jetdirect print server. Check the cabling and connectors on your Ethernet network. If you cannot find a problem with your network cabling, run the power-on self-test: turn the printer off, then on again. If the error persists after the printer is turned on again, there is a problem with the HP Jetdirect print server.
0D LAN ERROR - TRANSMITTER OFF	There may be a problem with your network cabling or the HP Jetdirect print server. Check the cabling and connectors on your Ethernet network. If you cannot find a problem with your network cabling, run the power-on self-test: turn the printer off, then on again. If the error persists, there is a problem with the HP Jetdirect print server.
0E LAN ERROR - LOSS OF CARRIER	Check the network connections. If the connections are intact, run the power-on self-test: turn the printer off, then on again. If the error persists, replace the HP Jetdirect print server.
10 LAN ERROR - UNDERFLOW	(Wired Ethernet) There may be a problem with your network cabling or the HP Jetdirect print server. Check the cabling and connectors on your network. If you cannot find a problem with your network cabling, run the power-on self-test: turn the printer off, then on again. If the error persists, there is a problem with the HP Jetdirect print server.
11 LAN ERROR - RETRY FAULTS	(Wired Ethernet) There is a problem with your network cabling or external network configuration. Verify operation of the hub or switch port.
12 LAN ERROR - NO LINKBEAT	With a 10/100 Base-TX port connected, this message is displayed if Link Beat is not sensed. Check the network cable, and verify that the concentrator/hub is providing Link Beat.
13 NETWORK RECONFIG - MUST REBOOT	Reset or power off/on the HP Jetdirect print server to enable new configuration values.

Table 9.11 Error Messages (3 of 11)

Error Code and Message	Description
14 DISCONNECTED	The Novell NetWare protocol is disconnected. Check the server and the print server.
15 CONFIGURATION ERROR	(Ethernet) The configuration information for the NetWare functions is not stored correctly on the HP Jetdirect print server. Use the installation software, embedded Web server, or other tools to reconfigure the print server. If this error persists, there may be a problem with the HP Jetdirect print server.
16 NOT CONFIGURED	(Ethernet) The HP Jetdirect print server has not been configured for NetWare. Use the installation software, embedded Web server, or other tools to configure the print server for NetWare networks.
17 UNABLE TO FIND SERVER	<p>(Ethernet) The HP Jetdirect print server was unable to find the NetWare print server (Remote Printer mode) or file server (Queue Server mode). (There was no response to service queries for advertising print servers or file servers that matched the configured print server or file server name.)</p> <p>Make sure that the print server or file server is running and that the print server or file server name configured on the HP Jetdirect print server matches the actual name used by the print server or file server. Also make sure that all cables and routers are functioning correctly.</p>
18 PASSWORD ERROR	<p>The HP Jetdirect print server detected that the password for the NetWare print server object is wrong. Use a NetWare utility (such as PCONSOLE) to erase the password for the print server object. When the HP Jetdirect print server logs on again, it sets a new password.</p> <p>Note: When multiple file servers are configured, the error is only displayed on the configuration page if none of the file servers are connected.</p>
19 NO QUEUE ASSIGNED	<p>The HP Jetdirect print server detected that the print server object has not been assigned any queues to service. Assign queues to the print server object using printer installation or NetWare utilities.</p> <p>Note: When multiple file servers are configured, the error is only displayed on the configuration page if none of the file servers were successfully connected.</p>
1A PRINTER NUMBER NOT DEFINED	A NetWare printer number for this printer has not been configured. Assign a valid printer number to the HP Jetdirect print server. Use a NetWare utility (such as PCONSOLE), the Jetdirect embedded Web server, or other tool to assign a printer number.

Table 9.11 Error Messages (4 of 11)

Error Code and Message	Description
1B PRINTER NUMBER IN USE	The NetWare printer number assigned to the printer is already in use by another printer. Assign an unused printer number. This may also occur when a printer is powered off/on, in which case the error goes away after the print server times out and detects the lost connection.
1C PRINT SERVER NOT DEFINED	The file server does not have a print server object that corresponds to the specified NetWare node name. Use printer installation software, a NetWare utility (such as PCONSOLE), or other tool to create the print server object. When the HP Jetdirect print server is configured for multiple file servers, the error is only displayed on the configuration page if none of the file servers made the connection.
1D UNABLE TO CONNECT TO SERVER	Remote Printer mode error: The HP Jetdirect print server was unable to establish an SPX connection with the NetWare print server. Make sure that the NetWare print server is running and that all cables and routers are functioning correctly.
1E FAIL RESERVING PRINTER NUM	The SPX connection to the print server was lost when the HP Jetdirect print server attempted to reserve the printer number. This indicates a possible network problem, or a problem with the print server. Make sure all cables and routers are functioning correctly. Try restarting the print server.
1F ERR NEGOTIATING BUFFER SIZE	A failure was detected when selecting the buffer size to be used when reading print data from the file server. This may indicate a network problem. When the HP Jetdirect print server is configured for multiple file servers, the error is only displayed on the configuration page if none of the file servers was successfully connected.
20 UNABLE TO LOGIN	A failure was detected when the HP Jetdirect print server tried to log onto the file server. This could be caused by the print server object not existing on the file server, or by a security check that prevents the print server from logging in. Make sure the file server name and print server object name are correct. Use PCONSOLE to erase the password for the print server object. Create a new print server object. When the HP Jetdirect print server is configured for multiple file servers, the error is only displayed on the configuration page if none of the file servers made the connection.

Table 9.11 Error Messages (5 of 11)

Error Code and Message	Description
21 UNABLE TO SET PASSWORD	<p>A failure was detected when the HP Jetdirect print server tried to set the password for the print server object. (Whenever the HP Jetdirect print server is able to log in without a password, it sets the password automatically.) This indicates a networking or security problem. Create a new print server object.</p> <p>When multiple file servers are configured, the error is only displayed on the configuration page if none of the file servers were successfully connected.</p>
22 UNABLE TO CONNECT TO SERVER	<p>Queue Server mode error: The HP Jetdirect print server could not establish an NCP connection to the file server. Make sure that the correct file servers are connected.</p> <p>When multiple file servers are configured, the error is only displayed on the configuration page if none of the file servers were successfully connected.</p>
23 UNABLE TO ATTACH TO QUEUE	<p>A failure was detected when the HP Jetdirect print server tried to attach to one of the queues assigned to the print server object. This may be because no servers are allowed to attach to this queue. There may also be a networking or security problem. Use PCONSOLE to make sure that servers are allowed to attach to the queue, to delete the print server object from the list of queue servers if you want the HP Jetdirect print server to service other queues, or to delete the queue and create a new one (the print server object must be added to the list of queue servers).</p> <p>When the HP Jetdirect print server is configured for multiple file servers, the error is only displayed on the configuration page if none of the file servers made the connection.</p>
24 PSERVERCLOSED CONNECTION	<p>The NetWare print server requested a termination of the connection with the HP Jetdirect print server. No error exists or is indicated. Make sure the NetWare print server is running, and restart it if necessary.</p>
25 DISCONNECTING - SPX TIMEOUT	<p>The SPX connection to the print server was lost after the connection had been made. This indicates a possible network problem, or a problem with the print server. Make sure all cables and routers are functioning correctly. Try restarting the print server.</p>
26 UNKNOWN NCP RETURN CODE	<p>The HP Jetdirect print server encountered an unexpected fatal error after it had successfully connected to the file server. A wide variety of failures could produce this error message, including a downed file server or a network router failure.</p>

Table 9.11 Error Messages (6 of 11)

Error Code and Message	Description
27 UNEXPECTED PSERVER DATA RCVD	The print server sent some data when the HP Jetdirect print server had not given its permission to do so. This indicates a possible print server problem, possibly a software problem.
28 OUT OF BUFFERS	The HP Jetdirect print server was unable to allocate a buffer from its internal memory. This indicates all buffers are busy due possibly to heavy broadcast traffic or large amounts of network traffic directed to the print server.
29 UNABLE TO SENSE NET NUMBER	The HP Jetdirect print server has been trying for over 3 minutes to determine the NetWare protocol used on the network. Make sure that any file servers and routers are operating correctly. Make sure that the settings for NetWare frame type and source routing are correct.
2A NDS ERR: EXCEEDS MAX SERVERS	More queues were assigned than the HP Jetdirect print server can handle. Remove one or more print queues from the list to be serviced by Queue Server Mode.
2B NDS ERR: UNABLE TO LOGIN	Unable to log onto the NetWare directory tree. Make sure that the print server object is defined in the directory at the correct context. Clear the print server password using NWADMIN or similar NetWare tool.
2C NDS AUTHENTICATION ERROR	Unable to log onto the NetWare directory tree. Make sure that the print server object is defined in the directory at the correct context.
2D NDS ERR: CHANGE PSSWRD FAILED	Cannot modify the print server password to the value expected by the HP Jetdirect print server.
2E NDS SERVER PUBLIC KEY ERROR	Print Server Object Name mismatch. Unable to read the file server's public key. Verify object names, or contact the NDS administrator.
2F NDS ERR: SRVR NAME UNRESOLVD	The file server on the network cannot be located. The server may not be running at this time or a communications problem may exist.
30 NDS PRINT SERVER NAME ERROR	The HP Jetdirect print server object cannot be located in the specified NDS context.
31 NDS PS PRINTER LIST ERROR	Cannot locate a list of printers objects that should be assigned to the print server object.
32 NDS PRINTER OBJ NOTIFY ERR	The list of notification objects assigned to the printer object cannot be located.
33 NDS PRINT OBJ QUEUE LIST ERR	The list of print queues assigned to the printer objects cannot be located.

Table 9.11 Error Messages (7 of 11)

Error Code and Message	Description
34 NDS ERR: UNRESOLVD PRNTR OBJ	The printer object cannot be located in the NDS directory.
35 NDS ERR: INVALID SRVR VERS	The current version of the NetWare file server is not supported.
36 NDS ERR: NO PRINTER OBJECTS	No printer objects are assigned to the print server object configured to this HP Jetdirect print server.
37 NDS ERR: MAX PRINT OBJECTS	Too many printer objects are assigned to the print server object. Using NetWare utilities (such as NWADMIN), reduce the number of printer objects assigned to the print server.
38 NDS ERR: NO QUEUE OBJECTS	No print queue objects are assigned to the printer objects located in the NDS directory.
39 NDS ERR: MAX QUEUE OBJECTS	Too many print queue objects are assigned to the printer. Reduce the number of queues assigned.
3A NDS ERR: UNABLE TO FIND TREE	The NDS tree cannot be located. The message may occur when the file server is not running or when a network communications problem exists.
3B NDS CONNECTION STATE ERROR	The HP Jetdirect print server cannot change the NDS connection state. Check licenses on the spooling server.
3C NDS ERR: UNRESOLVED QUEUE	The print queue object cannot be located in the specified NDS context.
3D NDS ERR: CANNOT READ Q HOST	Cannot locate the file server on the network. The server may not be running at this time or a communications problem may exist.
3E NDS PRNT SRVR PUBLIC KEY ERR	Print Server Object Name mismatch. Unable to read the print server's public key. Verify object names. Verify that the object key assigned to the HP Jetdirect print server is a print server object and not a printer or other object.
3F UNABLE TO GET NDS SRVR ADDR	The NDS server address cannot be located or accessed.
40 ARP DUPLICATE IP ADDRESS	The ARP layer has detected another node on the network using the same IP address as the HP Jetdirect print server. Extended error information below this message shows the hardware address of the other node.
41 NOVDRAM ERROR	The HP Jetdirect print server cannot read the contents of its NOVDRAM.

Table 9.11 Error Messages (8 of 11)

Error Code and Message	Description
42 INVALID IP ADDRESS	The IP address specified for the HP Jetdirect print server (through BOOTP) is an invalid IP address for specifying a single node. Check your Bootptab file for proper entries.
43 INVALID SUBNET MASK	The IP subnet mask specified for the HP Jetdirect print server (through BOOTP) is an invalid subnet mask. Check your Bootptab file for proper entries.
44 INVALID GATEWAY ADDRESS	The default gateway IP address specified for the HP Jetdirect print server (through BOOTP) is an invalid IP address for specifying a single node. Check your Bootptab file for proper entries.
45 INVALID SYSLOG ADDRESS	The syslog server IP address specified for the HP Jetdirect print server (through BOOTP) is an invalid IP address for specifying a single node. Check your Bootptab file for proper entries.
46 INVALID SERVER ADDRESS	The TFTP server IP address specified for the HP Jetdirect print server (through BOOTP) is an invalid IP address for specifying a single node. Check your Bootptab file for proper entries.
47 INVALID TRAP DEST ADDRESS	One of the SNMP trap (Trap PDU) destination IP addresses specified for the HP Jetdirect print server (through TFTP) is an invalid IP address for specifying a single node. Check your TFTP configuration file.
48 CF ERR - FILE INCOMPLETE	The TFTP configuration file contained an incomplete last line that did not end in a newline character.
49 CF ERR - LINE TOO LONG	A line being processed in the TFTP configuration file was longer than the HP Jetdirect print server could accept.
4A CF ERR - UNKNOWN KEYWORD	A TFTP configuration file line contained an unknown keyword.
4B CF ERR - MISSING PARAMETER	A line in the TFTP configuration file was missing a required parameter.
4C CF ERR - INVALID PARAMETER	A line in the TFTP configuration file contained an invalid value for one of the parameters on that line.
4D CF ERR - ACCESS LIST EXCEEDED	The TFTP configuration file specified too many access list entries using the "allow:" keyword.
4E CF ERR - TRAP LIST EXCEEDED	The TFTP configuration file specified too many trap destination list entries using the "trap-destination:" keyword.
4F TFTP REMOTE ERROR	The TFTP transfer of the configuration file from the host to the HP Jetdirect print server failed with the remote host sending a TFTP ERROR packet to the print server.

Table 9.11 Error Messages (9 of 11)

Error Code and Message	Description
50 TFTP LOCAL ERROR	The TFTP transfer of the configuration file from the host to the HP Jetdirect print server failed with the local print server encountering some form of inactivity timeout, or excessive retransmissions situation.
51 TFTP RETRIES EXCEEDED	The overall retrying of the TFTP transfer of the configuration file from the host to the HP Jetdirect print server has exceeded a retry limit.
52 BAD BOOTP/DHCP REPLY	An error was detected in the BOOTP or DHCP reply that the HP Jetdirect print server received. The reply either had insufficient data in the UDP datagram to contain the minimum BOOTP/DHCP header of 236 bytes, had an operation field that was not BOOTPREPLY(0X02), had a header field that did not match the print servers hardware address, or had a UDP source port that was not the BOOTP/DHCP server port (67/udp).
53 BAD BOOTP TAG SIZE	The tag size in a vendor-specific field in the BOOTP reply is either 0, or greater than the remaining number of unprocessed bytes in the vendor-specified area.
54 BOOTP/RARP IN PROGRESS	The HP Jetdirect print server is currently in the process of obtaining its basic IP configuration information through BOOTP/RARP.
55 BOOTP/DHCP IN PROGRESS	The HP Jetdirect print server is currently in the process of obtaining its basic IP configuration information through BOOTP/DHCP, and has not detected any errors.
56 DHCP NAK	The HP Jetdirect print server received a negative acknowledgement message from the DHCP server in response to a configuration request.
57 UNABLE TO CONNECT DHCP SVR	The HP Jetdirect print server had received IP parameters from a DHCP server, but communication with the DHCP server has been lost. Check status of the DHCP server. If an infinite lease was assigned, the print server will use the IP address of the most recent DHCP server used, but operation may be degraded until a DHCP server responds.
58 POSTSCRIPT MODE NOT SELECTED	The printer does not support AppleTalk or AppleTalk extensions.
59 INCOMPLETE F/W - MUST DOWNLOAD	Firmware download message. Currently downloading firmware to the HP Jetdirect print server, or the download did not complete properly.
5A TURN PRINTER OFF / ON	Firmware download message. Download of firmware is complete. Power off/on the HP Jetdirect print server.

Table 9.11 Error Messages (10 of 11)

Error Code and Message	Description
5C DHCP BAD REPLY	A bad reply was received from the DHCP server. Check your DHCP server settings for this print server.
5D DHCP LEASE DURATION TOO SHORT	The DHCP lease times for this print server's TCP/IP configuration settings are too short. Reconfigure the DHCP lease times on the DHCP server.
5E DHCP LEASE RELEASED	The lease for DHCP-configured parameters, including the IP address, have been released through a manual configuration method, such as through the printer's control panel.
5F WINS REGISTRATION FAILED	Attempts to register the print server's name on the WINS server failed. Check for duplicate names, or verify the WINS server configuration.
61 AUTO IP CONFIGURED	An IP address could not be retrieved over the network. The print server will default to an IP address using link-local addressing in the form 169.254.x.x.
62 DEFAULT IP CONFIGURED	An IP address could not be retrieved over the network. The print server will default to a legacy default IP address 192.0.0.192.
63 AUTO IP IN PROGRESS	The print server is automatically assigning an IP address using link-local addressing in the form 169.254.x.x.
64 INVALID PASSWORD	An invalid password was specified through TFTP. Verify that the password consists of a maximum of 16 printable characters.
65 DOWNLOAD NOT ALLOWED ON WIRELESS	For this print server, attempting to upgrade the firmware over a wireless network connection is not allowed.
83 DISCONNECTING FROM SERVER	The server has been shut down because of a configuration change or reset request. This message automatically clears after a few seconds, unless the printer is offline, is in an error state, or is servicing another I/O port or another network protocol.
84 DHCP LEASE TIMERS ADJUSTED	<p>The print server detected a DHCP lease error due to one of the following conditions:</p> <ul style="list-style-type: none"> ● Renew time is less than 30 seconds. ● Rebind time is less than 52 seconds. ● Rebind time is less than, or equal to, the Renew time. ● The lease duration is less than, or equal to, the Rebind time.

Table 9.11 Error Messages (11 of 11)

Error Code and Message	Description
86 FOR MULTILANGUAGES UPGRADE AGAIN	When upgrading a supported print server that contains a firmware version prior to X.24.00, it will be necessary to perform the firmware upgrade again if you want the print server to support management tools (for example, the embedded Web server) using non-English languages.
F1 TRYING TO CONNECT TO SERVER	The HP Jetdirect print server is trying to connect to the NetWare server(s). This is a normal message. Wait until either the connection is established or another status message appears.
F2 TFTP IN PROGRESS	The print server is attempting to use TFTP to obtain TCP/IP configuration settings over the network.
F3 BOOTP/RARP IN PROGRESS	The print server is attempting to use BootP or RARP to obtain TCP/IP configuration settings over the network.
F4 BOOTP/DHCP IN PROGRESS	The print server is attempting to use BootP or DHCP to obtain TCP/IP configuration settings over the network.

TCP/IP Overview

Introduction

This appendix is intended to provide information to help you gain a basic understanding of TCP/IP.

Similar to a common language that people use to communicate with each other, TCP/IP (Transmission Control Protocol/Internet Protocol) is a suite of protocols designed to define the way computers and other devices communicate with each other over a network.

TCP/IP is rapidly becoming the most used set of protocols. The main reason this is happening is the fact that the Internet is based on TCP/IP. If you have a network that you wish to connect to the internet, you must be using TCP/IP to communicate.

Internet Protocol (IP)

When information is sent across the network, the data is broken down into small packets. Each packet is sent independently of one another. Each packet is encoded with IP information, such as the IP address of the sender and receiver. IP packets can be routed over routers and gateways, devices that connect a network with other networks.

IP communications is connectionless. When IP packets are sent, there is no guarantee that they arrive at their destination in the proper sequence. That task can be performed by higher level protocols and applications thereby allowing IP communications to be efficient.

Each node or device that will communicate directly onto the network requires an IP address, including HP Jetdirect-connected devices.

Transmission Control Protocol (TCP)

TCP handles breaking the data into packets and recombining the packets on the receiving end by providing a connection-oriented, reliable, and guaranteed delivery service to another node on the network. When data packets are received at their destination, TCP calculates a checksum for each packet to verify the data is not corrupt. If the data in the packet has been corrupted during transmission, TCP discards the packet and requests that the packet be resent.

User Datagram Protocol (UDP)

UDP provides similar services to TCP. However, UDP does not acknowledge data receipt and supports request/reply transactions with no added reliability or guarantee of delivery. UDP is used when acknowledgment and reliability are not required, such as during a “discovery broadcast.”

IP Address

Every host (workstation or node) on an IP network requires a unique IP address for each network interface. This address is a software address that is used to identify both the network and specific hosts located on that network. Each IP address can be divided into two separate parts: the network portion and the host portion. It is possible for a host to query a server for a dynamic IP address each time the device boots-up (for example, using DHCP and BootP).

Note

When assigning IP addresses, always consult the IP address administrator. Setting the wrong address can disable other equipment operating on the network or interfere with communications.

IP Address: (Network Portion)

Network addresses are managed by an organization in Norfolk, Virginia recognized as InterNIC. InterNIC has been contracted by the National Science Foundation to manage the Internet addresses and domains. Network addresses are distributed to organizations that are in turn responsible for making sure all attached devices or hosts on the network are properly numbered. For more information on the network portion of an IP address, see “[IP Address Structure and Class](#)” and “[Subnets](#)” later in this appendix.

IP Address: (Host Portion)

Host addresses numerically identify specific network interfaces on an IP network. Usually a host has only one network interface; thus, only one IP address. Because no two devices can share the same number at the same time, administrators typically maintain address tables to assure correct assignment of addresses in the host network.

IP Address Structure and Class

An IP address is comprised of 32 bits of information and divided into 4 sections containing 1 byte each section or 4 bytes total:

xxx . xxx . xxx . xxx

For efficiency in routing, networks were broken down into three classes, so routing can begin simply by identifying the leading byte of information in the IP address. The three IP addresses that InterNIC assigns are class A, B, and C. The network class determines what each of the four IP address sections identify as shown in [Table A.1](#):

Table A.1 IP Address Class Format

Class	First Address Byte xxx.	Second Address Byte xxx.	Third Address Byte xxx.	Fourth Address Byte xxx
A	Network.	Host.	Host.	Host
B	Network.	Network.	Host.	Host
C	Network.	Network.	Network.	Host

As illustrated in [Table A.2](#), each network class differs by the leading bit identifier, the address range, the number of each type available, and the maximum number of hosts each class allows.

Table A.2 Network Class Characteristics

Class	Leading Bit Identifier	Address Range	Maximum Number of Networks in the Class	Maximum Hosts in the Network
A	0	0.0.0.0 to 127.255.255.255	126	Over 16 Million
B	10	128.0.0.0 to 191.255.255.255	16,382	65,534
C	110	192.0.0.0 to 223.255.255.255	Over 2 Million	254

Configuring IP Parameters

TCP/IP configuration parameters (such as IP address, subnet mask, default gateway) can be configured on the HP Jetdirect print server in a variety of ways. These values can be configured manually (for example, through Telnet, the embedded Web server, the arp and ping commands, and HP management software), or they can be automatically downloaded using DHCP or BOOTP each time the print server is turned on. For configuration methods, see [Chapter 3](#).

When powered on, a new HP Jetdirect print server that is unable to retrieve a valid IP address from the network will automatically assign itself a default IP address. The default IP address will depend on the type of network to which the print server is connected. On a small private network, a technique called link-local addressing is used to assign a unique IP address in the range of 169.254.1.0 to 169.254.254.255, which should be valid. On a large or enterprise network, a temporary address of 192.0.0.192 will be assigned until it is properly configured for your network. The IP address configured on your print server may be determined by inspecting the Jetdirect configuration page for the print server.

Dynamic Host Configuration Protocol (DHCP)

DHCP allows a group of devices to use a set of IP addresses that are maintained by a DHCP server. The device or host sends a request to the server, and if an IP address is available, the server assigns it to that device.

BOOTP

BOOTP is a bootstrap protocol used to download configuration parameters and host information from a network server. BOOTP uses UDP for its transport. In order for devices to boot and load configuration information into RAM, they must communicate through the bootstrap protocol BOOTP as a client with their server.

To configure the device, the client broadcasts a boot request packet containing at least the hardware address of the device (HP Jetdirect print server hardware address). The server answers with a boot reply packet containing the information the device needs to configure.

Subnets

When an IP network address for a particular network class is assigned to an organization, no provision is made for more than one network being present at that location. Local network administrators use subnets to partition a network into several different subnetworks. Splitting a network into subnets can result in better performance and improved use of limited network address space.

Subnet Mask

The subnet mask is a mechanism used to divide a single IP network into several different subnetworks. For a given network class, a portion of an IP address that would normally be used to identify a node is used, instead, to identify a subnetwork. A subnet mask is applied to each IP address to specify the portion used for subnetworks, and the portion used to identify the node. For example, see [Table A.3](#).

Table A.3 Example: Subnet Mask 255.255.0.0 Applied to Class A Network

Class A Network Address	15	xxx	xxx	xxx
Subnet Mask	255	255	0	0
IP Address fields with Subnet Mask applied	Network	Subnet	Host	Host
Example of a node's IP Address on Subnet 1	15	1	25	7
Example of a node's IP Address on Subnet 254	15	254	64	2

As illustrated in [Table A.3](#), the Class A IP network address “15” has been assigned to company ABC. To allow additional networks at company ABC’s site, the subnet mask of 255.255.0.0 is used. This subnet mask specifies that the second byte of the IP address will be used to identify up to 254 subnets. Using this designation, each device is uniquely identified on its own subnet, but company ABC can incorporate up to 254 subnetworks without violating their assigned address space.

Gateways

Gateways (routers) are used to connect networks together. Gateways are devices that act as translators between systems that do not use the same communication protocols, data formatting, structures, languages, or architectures. Gateways repackage the data packets and change the syntax to match that of the destination system. When networks are divided into subnets, gateways are required to connect one subnet to another.

Default Gateway

The Default Gateway is the gateway or router that, if not specified, will be used to move packets between networks. It is specified by an IP address.

If multiple gateways or routers exist, then the default gateway is typically the address of the first, or nearest, gateway or router. If no gateways or routers exist, then the default gateway will typically assume the IP address of the network node (such as the workstation or HP Jetdirect print server).

Syslog Server

A syslog server is a system on the network (typically a UNIX system) that can receive and log syslog messages from other devices on the network. Syslog messages allow administrators to monitor status or troubleshoot network devices.

A syslog server requires software that provides syslog capabilities running on the server. UNIX systems provide a daemon, syslogd, that monitors User Datagram Protocol (UDP) port 514 for incoming messages. The messages are processed depending on their priority and on how syslogd is set up to operate.

You can configure the HP Jetdirect print server with the syslog server's IP address. When a syslog server is configured, both the HP Jetdirect print server and attached device can send syslog messages using UDP.

The syslog server may not receive all syslog events from the HP Jetdirect print server:

- UDP does not guarantee delivery of messages.
- The HP Jetdirect print server attempts to eliminate duplicate messages (to minimize unnecessary network traffic).
- The volume of messages sent by the HP Jetdirect print server is configurable.

Methods to configure HP Jetdirect syslog parameters include BOOTP, DHCP, Telnet, the embedded Web server, and management software. For selected printers, an EIO menu accessed through the printer control panel provides limited syslog configuration. The syslog configuration command or parameter entries may vary depending on the method used. For more information, see the applicable sections in this guide.

Selected syslog parameters on the HP Jetdirect print server are listed in [Table A.4](#).

Table A.4 HP Jetdirect Syslog Parameters

Item	Description
Syslog Server IP address	IP address of a syslog server for sending syslog messages. If zero (0.0.0.0) or not specified, syslog messages are disabled.
Syslog Maximum Messages	The number of syslog messages that can be sent by the HP Jetdirect print server on a per-minute basis, from 0 to 1000. This parameter helps to control the syslog file size. The default is 10 messages per minute. If 0, the number of syslog messages is not restricted.
Syslog Priority	A method for filtering syslog messages that are sent to the syslog server. The range is 0 through 8, with 0 the most specific and 8 the most general. Only messages that are lower than the specified filter level (or higher in priority) are reported. The default is 8, messages of all priorities are sent. If 0, all syslog messages are disabled.
Syslog Facility	A code used to identify the source facility of a message (for example, to identify the source of selected messages during troubleshooting). By default, the HP Jetdirect print server uses LPR as the source facility code, but local user values of local0 through local7 can be used to isolate individual or groups of print servers.

Typical logfile entries of syslog messages are illustrated below:

```
Oct 22 08:10:33 jd08 printer: error cleared
Oct 22 15:06:07 jd04 printer: powered up
Oct 22 15:07:56 jd04 printer: offline or intervention needed
Oct 22 15:08:58 jd04 printer: error cleared
Oct 24 17:52:27 jd37 printer: powered up
Oct 24 18:28:13 jd37 printer: printer is disconnected
Oct 24 18:37:46 jd07 printer: error cleared
Oct 24 18:38:42 jd37 printer: powered up
Oct 25 07:50:16 jd04 printer: toner/ink low
```

The HP Jetdirect EIO Control Panel Menu

Introduction

When supported by the printer, HP Jetdirect EIO internal print servers contain a configuration menu that can be accessed from the printer's control panel. The keystrokes to access this menu from the printer control panel depend on the printer. Refer to the printer manuals for more information.

The HP Jetdirect internal print servers support the following printer control panels:

- [Classic Control Panel](#) display with menu and parameter selection buttons
- [Graphical Control Panel](#) display with navigation and numeric keypads (available on newer HP LaserJet printer models)

Classic Control Panel

Classic control panels can typically display two lines of 16 characters each.

As described in [Table B.1](#), the HP Jetdirect control panel menu allows you to enable or disable network protocols, and configure selected network parameters. On the control panel display, an asterisk (*) is used to identify the selected value.



Table B.1 HP Jetdirect Classic Control Panel Menu (1 of 3)

Menu Item	Description
CFG NETWORK=	Selects whether or not you want to access the Jetdirect menu. NO (default): Bypass the HP Jetdirect menu. YES: Access the HP Jetdirect menu. You must change this to YES* each time you want to access the menu.
TCP/IP= IPX/SPX= DLC/LLC= ATALK=	Identifies whether the protocol stack is enabled or disabled. ON (default): The protocol is enabled. OFF: The protocol is disabled.

Table B.1 HP Jetdirect Classic Control Panel Menu (2 of 3)


Menu Item	Description
CFG TCP/IP=	<p>Selects whether you want to access the TCP/IP menu and set TCP/IP protocol parameters.</p> <p>NO (default): Bypass the TCP/IP menu items.</p> <p>YES: Access the TCP/IP menu items.</p> <ul style="list-style-type: none">● BOOTP=YES* enables configuration by a BootP Server.● DHCP=YES* enables configuration by a DHCP Server. <p>If DHCP=YES* and the print server has a DHCP lease, you can choose to configure the following DHCP settings:</p> <ul style="list-style-type: none">■ RELEASE: Choose YES to release, or NO to save, the current DHCP lease.■ RENEW: Choose YES to renew the current DHCP lease, or NO to not renew the DHCP lease. ● AUTO IP=YES* will automatically assign a link-local address in the form 169.254.x.x. <p>If you specify BOOTP=NO*, DHCP=NO* and AUTO IP=NO*, you can manually set the following TCP/IP parameters from the control panel:</p> <ul style="list-style-type: none">■ Each byte of the IP address (IP)■ Subnet Mask (SM)■ Syslog Server (LG)■ Default Gateway (GW)■ Idle Timeout period (default is 270 seconds, 0 disables the timeout) ● CFG DNS 1=YES* will allow you to specify the IP address of a primary DNS server, one byte at a time. ● CFG DNS 2=YES* will allow you to specify the IP address of a secondary DNS server, one byte at a time. <p>Print a Jetdirect configuration page to verify your settings. However, note that the print server may overwrite selected parameters with values that ensure proper operation.</p>
CFG IPX/SPX=	<p>Selects whether you want to access the IPX/SPX menu and set IPX/SPX protocol parameters.</p> <p>NO (default): Bypass the IPX/SPX menu items.</p> <p>YES: Access the IPX/SPX menu items.</p> <p>In the IPX/SPX menu, you can specify the <i>Frame Type</i> parameter used on your network.</p> <ul style="list-style-type: none">■ AUTO (default) will automatically set and limit the frame type to the first one detected.■ For Ethernet cards, frame type selections include EN_8023, EN_II, EN_8022, EN_SNAP.

Table B.1 HP Jetdirect Classic Control Panel Menu (3 of 3)

Menu Item	Description
CFG LINK=	Selects whether you want to manually configure the HP Jetdirect print server's network link. NO (default): Bypass the link configuration menu items. YES: Access the link configuration menu items.
	The link speed and communication mode must match the network. One of the following link configurations can be set: AUTO (default): The print server will automatically configure itself to match the network's link speed and communication mode. If it fails, 100TX Half will be set. 10T HALF: 10Mbps, half-duplex operation 10T FULL: 10 Mbps, full-duplex operation 100TX HALF: 100 Mbps, half-duplex operation 100TX FULL: 100 Mbps, full-duplex operation
WEB=	For configuration management, specify whether the embedded Web server will accept communications using HTTPS (Secure HTTP) only, or both HTTP and HTTPS. HTTPS: For secure, encrypted communications, only HTTPS access is accepted. The print server will appear as a secure site. HTTP/HTTPS: Access using either HTTP or HTTPS is permitted.
SECURITY=	Specify whether the current security settings on the print server will be saved or reset to factory defaults. KEEP (default): The current security settings are maintained. RESET: Security settings are reset to factory defaults.

Graphical Control Panel

Graphical control panels typically display 18 characters on a line, and as many as four lines at a time. In addition, scrolling may be supported to allow display of additional lines.



On graphical control panels, a numeric keypad and navigation buttons are used to access HP Jetdirect menu items. For a description of menu items and options, see [Table B.2](#).

Table B.2 HP Jetdirect Graphical Control Panel Menu (1 of 4)

Menu Item	Options	Description of settings
TCP/IP	ENABLE	ON: Enable the TCP/IP protocol OFF: Disable the TCP/IP protocol
	HOST NAME	An alphanumeric string, up to 32 characters, used to identify the device. This name is listed on the Jetdirect configuration page. The default host name is NPIxxxxxx, where xxxxxx is the last six digits of the LAN hardware (MAC) address.
	CONFIG METHOD	Specifies the method that TCP/IP parameters will be configured on the Jetdirect print server. <ul style="list-style-type: none">● BOOTP: Use BootP (Bootstrap Protocol) for automatic configuration from a BootP server.● DHCP: Use DHCP (Dynamic Host Configuration Protocol) for automatic configuration from a DHCP server. If selected and a DHCP lease exists, DHCP RELEASE and DHCP RENEW menus will be available to set DHCP lease options.● AUTO IP: Use automatic link-local IP addressing. An address in the form 169.254.x.x will be automatically assigned.● MANUAL: Use the MANUAL SETTINGS menu to configure TCP/IP parameters.

Table B.2 HP Jetdirect Graphical Control Panel Menu (2 of 4)

Menu Item	Options	Description of settings
	DHCP RELEASE	<p>This menu appears if CONFIG METHOD was set to DHCP and a DHCP lease for the print server exists.</p> <ul style="list-style-type: none"> ● NO (default): The current DHCP lease is saved. ● YES: The current DHCP lease along with the leased IP address are released.
	DHCP RENEW	<p>This menu appears if CONFIG METHOD was set to DHCP and a DHCP lease for the print server exists.</p> <ul style="list-style-type: none"> ● NO (default): The print server does not request to renew the DHCP lease. ● YES: The print server requests to renew the current DHCP lease.
	MANUAL SETTINGS	<p>(Available only if CONFIG METHOD is set to MANUAL) Configure parameters directly from the printer control panel:</p> <ul style="list-style-type: none"> ● IP ADDRESS n.n.n.n: The unique IP address of the printer, where n is a value from 0 to 255. ● SUBNET MASK m.m.m.m: The subnet mask for the printer, where m is a value from 0 to 255. ● SYSLOG SERVER n.n.n.n: The IP address of the syslog server used to receive and log syslog messages. ● DEFAULT GATEWAY n.n.n.n: The IP address of the gateway or router used for communications with other networks. ● IDLE TIMEOUT: The time period, in seconds, after which an idle TCP print data connection is closed (default is 270 seconds, 0 disables the timeout).
	DEFAULT IP	<p>Specify the IP address to default to when the print server is unable to obtain an IP address from the network during a forced TCP/IP reconfiguration (for example, when manually configured to use BootP or DHCP).</p> <ul style="list-style-type: none"> ● AUTO IP: A link-local IP address 169.254.x.x will be set. ● LEGACY: The address 192.0.0.192 will be set, consistent with older Jetdirect products.

Table B.2 HP Jetdirect Graphical Control Panel Menu (3 of 4)

Menu Item	Options	Description of settings
	PRIMARY DNS	Specify the IP address (n.n.n.n) of a Primary DNS Server.
	SECONDARY DNS	Specify the IP address (n.n.n.n) of a Secondary Domain Name System (DNS) Server.
	PROXY SERVER	<p>Specifies the proxy server to be used by embedded applications in your printer/MFP. A proxy server is typically used by network clients for Internet access. It caches Web pages, and provides a degree of Internet security, for those clients.</p> <p>To specify a proxy server, enter its IP address or fully-qualified domain name. The name can be up to 255 octets.</p> <p>For some networks, you may need to contact your Independent Service Provider (ISP) for the proxy server address.</p>
	PROXY PORT	Enter the port number used by the proxy server for client support. The port number identifies the port reserved for proxy activity on your network, and can be a value from 0 to 65535.
IPX/SPX	ENABLE	ON: Enable the IPX/SPX protocol OFF: Disable the IPX/SPX protocol
	FRAME TYPE	<p>Selects the frame type setting for your network.</p> <p>AUTO (default): Automatically sets and limits the frame type to the first one detected.</p> <p>EN_8023, EN_II, EN_8022, EN_SNAP: Frame type selections for Ethernet networks.</p>
APPLETALK	ENABLE	(Ethernet/Fast Ethernet only) ON: Enable the AppleTalk protocol OFF: Disable the AppleTalk protocol
DLC/LLC	ENABLE	ON: Enable the DLC/LLC protocol OFF: Disable the DLC/LLC protocol

Table B.2 HP Jetdirect Graphical Control Panel Menu (4 of 4)

Menu Item	Options	Description of settings
SECURE WEB		<p>For configuration management, specify whether the embedded Web server will accept communications using HTTPS (Secure HTTP) only, or both HTTP and HTTPS.</p> <p>HTTPS REQUIRED: For secure, encrypted communications, only HTTPS access is accepted. The print server will appear as a secure site.</p> <p>HTTPS OPTIONAL: Access using either HTTP or HTTPS is permitted.</p>
RESET SECURITY		<p>Specify whether the current security settings on the print server will be saved or reset to factory defaults.</p> <p>NO (default): The current security settings are maintained.</p> <p>YES: Security settings are reset to factory defaults.</p>
LINK SPEED		<p>Selects the network link speed and communication mode for the 10/100TX print server. For proper communications, the Jetdirect settings must match the network.</p> <p>AUTO: (Default) The print server will automatically configure itself to match the network's link speed and communication mode. If it fails, 100TX HALF is set.</p> <p>10T HALF: 10Mbps, half-duplex operation.</p> <p>10T FULL: 10 Mbps, full-duplex operation.</p> <p>100TX HALF: 100 Mbps, half-duplex operation</p> <p>100TX FULL: 100 Mbps, full-duplex operation</p>

OpenSSL Statements

OpenSSL License

Copyright © 1998-2004 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment:

"This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (<http://www.openssl.org/>)"

4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.

5. Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.

6. Redistributions of any form whatsoever must retain the following acknowledgment:

"This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>)"

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT ``AS IS'' AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (ey@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

Original SSLeay License

Copyright © 1995-1998 Eric Young (eay@cryptsoft.com). All rights reserved.

This package is an SSL implementation written by Eric Young (eay@cryptsoft.com). The implementation was written so as to conform with Netscape's SSL.

This library is free for commercial and non-commercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed.

If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used.

This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement:

"This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)"

The word 'cryptographic' can be left out if the routines from the library being used are not cryptographic related.

4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement:

"This product includes software written by Tim Hudson (tjh@cryptsoft.com)"

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The licence and distribution terms for any publically available version or derivative of this code cannot be changed, i.e., this code cannot simply be copied and put under another distribution license [including the GNU Public Licence.]

Index

A

Access List

- configuration page entry 213
- embedded Web server 145
- security features 181
- Telnet configuration 86
- TFTP configuration file 53

Ad Hoc Mode

- embedded Web server 112
- Telnet 80

Administrator Password 211

- embedded Web server 108, 138
- Security features 180
- Telnet configuration 79
- TFTP configuration file 50

Apple Chooser 32, 194

AppleTalk

- Control panel configuration 246, 251
- installing software 28
- Name 30, 223
- Network number 223
- Node number 223
- software configuration 29
- STATUS 223
- Telnet configuration 92
- TFTP configuration 58
- TYPE 120, 223
- verifying configuration 30
- Zone 120, 223

arp command 72

ARP DUPLICATE IP ADDRESS 231

ATTACHED SERVER 222

Authentication 150

- 802.1X 10, 150
- embedded Web server 113
- Telnet 81

AUTHENTICATION FAILED 225

Auto IP 35, 36

- See also, Default IP address
- configuration page 216
- embedded Web server 115

AUTONEGOTIATION 206

B

BAD BOOTP REPLY 233

BAD BOOTP TAG SIZE 233

BAD PACKETS RCVD 214

banner page

- embedded Web server 117
- Telnet configuration 84
- TFTP configuration 52

BOOTP

- embedded Web server 115
- overview 240
- Telnet configuration 83
- using 40

BOOTP Server 42

- configuration 42
- identifying 216

BOOTP/DHCP IN PROGRESS 233

BOOTP/RARP IN PROGRESS 233

browsers

- embedded web server 103
- HP Web Jetadmin 20

C

CA certificate 140

- embedded Web server 151

Cert Expires 211

Certificate Authority, See CA certificate

Certificates 139

- validity period 142

CF ERR

- ACCESS LIST EXCEEDED 232
- FILE INCOMPLETE 232
- INVALID PARAM 232
- LINE TOO LONG 232
- MISSING PARAM 232
- TRAP LIST EXCEEDED 232
- UNKNOWN KEYWORD 232

channel

- wireless communications 81, 112

Chooser, Apple 32, 194

cold-reset 186

- Communication Mode
 - embedded Web server 112
 - Telnet 80
- Community name
 - configuration page 212
 - embedded Web server 121
 - security features 181
 - Telnet 90
 - TFTP configuration 57
- CONFIG BY 216
- CONFIG FILE 217
- configuration
 - HP Web Jetadmin 22
 - LPD printing 154
 - software solutions 15
 - TCP/IP networks 35
 - Telnet commands 79
 - TFTP parameters 50
 - wireless 110
- CONFIGURATION ERROR 227
- configuration page
 - embedded web server 152
 - printing 190
- configuration page messages
 - 802.11 wireless 208
 - AppleTalk 223
 - DLC/LLC 224
 - Error Messages 225
 - General Messages 205
 - IPX/SPX 219
 - Novell NetWare 221
 - TCP/IP 215
 - USB 207
- control panel configuration 99, 245

D

- DATE MANUFACTURED 206
- Default gateway
 - See also, gateway
 - configuration page 216
- Default IP address 35
- defaults, See factory defaults

- DHCP
 - control panel 247, 249
 - enabling or disabling 68
 - IP addresses 240
 - Telnet configuration 83
 - UNIX systems 63
 - using 62
 - Windows servers 63
- DHCP NAK 233
- DHCP Server, identifying 216
- DISCONNECTED 227
- DISCONNECTING
 - FROM SERVER 234
 - SPX TIMEOUT 229
- DLC/LLC
 - configuration messages 224
 - Control panel configuration 246, 251
 - embedded Web server 120
 - Telnet configuration 93
 - TFTP configuration 59
- DNS server 63, 217
 - Boot file tag 44
 - embedded Web server 124
 - printer control panel 251
 - Telnet configuration 84
 - TFTP configuration 51
- Domain name 217
 - Boot file tag 44
 - embedded Web server 116
 - Telnet configuration 84
 - TFTP configuration 51
- dynamic encryption
 - embedded Web server 113
 - Telnet 82

E

- EAP
 - CA certificates 140
- EIO control panel menu 246

embedded Web server

- HP Web Jetadmin 103
- HTTPS security 146, 180
- LPD setup 128
- NetWare objects 106
- TFTP configuration file 55
- upgrading firmware 128
- using 101
- viewing 104
- web browsers 103

Encryption

- embedded Web server 114
- SNMP v3 147
- supported ciphers 147

ERR NEGOTIATING BUFFER SIZE 228

error messages 225

- 802.11 wireless 208
- HP Jetdirect configuration
page 202
- printer control panel 191

F

factory defaults, resetting 186

- cold-reset 186
- security parameters 50, 80,
135, 248, 252
- TCP/IP from Telnet 98
- wireless parameters 111

FAIL RESERVING PRINTER NUM 228

FIRMWARE REVISION 205

firmware upgrades 12

- embedded Web server 128
- obtaining 12
- TFTP configuration 59

FRAME TYPE 220

FRAMING ERRORS RCVD 214

FTP printing

- commands 176
- example 178
- exiting 176
- introduction 172
- TFTP configuration 51

G

gateway

- bootptab file 44
- description 242
- embedded Web server 116
- NDPS 26
- printer control panel 99

H

hardware address

- arp command 72
- Bootptab file 43
- default NetWare printer name
119
- embedded Web server 108
- identifying 205
- in default user name 151
- LPD printing 156
- RARP 71

Host Access List, See Access List

HOST NAME 215

- BOOTP tag 44
- embedded Web server 115
- Telnet 83
- TFTP file 51

HP IP/IPX printer gateway for NDPS 26

HP Jetdirect

- cold-reset 186
- configuration page messages
202
- configuration page, how to
print 190
- Error messages 225
- general configuration messages
205
- network statistics 211, 214
- supported print server 8
- using the printer control panel
99, 245
- wireless settings 208

HP LaserJet Utility

- renaming the printer 30
- running 29

HP Support, Online 12

HP Web Jetadmin 20
installing 21
removing 22
with embedded Web server 103

HTTPS
configuration page 213
embedded Web server 105, 146
redirection from control panel 248
redirection from Telnet 80
redirection from TFTP 50

I

I/O Card, STATUS message 205

idle timeout
current setting 217
embedded Web server 116
printer control panel 99
Telnet 88
TFTP configuration file 55

IEEE 802.1X 10
Configuration 150

Infrastructure Mode
embedded web server 112
Telnet 80

INIT message 192

INITIALIZING TRYING TO
CONNECT TO SERVER 235

installing
AppleTalk software 28
HP Web Jetadmin software 21

Internet Printer Connection
software

introduction 23
supported proxies 24
system requirements 24

Internet Printing Protocol, See IPP

INVALID
GATEWAY ADDRESS 232
IP ADDRESS 232
PASSWORD 234
SERVER ADDRESS 232
SUBNET MASK 232
SYSLOG ADDRESS 232
TRAP DEST ADDRESS 232

IP address 215
Bootptab file 43
configuring 240
default 35
embedded Web server 104, 115
erasing through Telnet 98
printer control panel 99
resetting 186
TCP/IP overview 237

IP, See TCP/IP

IP/IPX printer gateway 26
IPP

Internet Printer Connection
16, 23

TFTP configuration 52

ipv4-multicast
embedded Web server 123, 149
Telnet 88
TFTP configuration file 54

IPX/SPX
Control panel configuration 246, 251
STATUS message 219
Telnet configuration 91
TFTP configuration 57

J

Jetdirect certificate 139

L

LAN ERROR

BABBLE 225
CONTROLLER CHIP 225
EXTERNAL LOOPBACK 225
INFINITE DEFERRAL 225
INTERNAL LOOPBACK 225
LOSS OF CARRIER 226
NO LINKBEAT 226
NO SQE 226
RECEIVER OFF 226
RETRY FAULTS 226
TRANSMITTER OFF 226
UNDERFLOW 226

link configuration

- classic control panel 248
- embedded Web server 124
- graphical control panel 252
- Telnet 95
- TFTP 59

locally administered address (LAA) 93, 108, 125, 206

LPD (Line Printer Daemon), See

LPD printing

LPD printing

- Mac OS 169
- setup overview 156
- TFTP configuration 52
- UNIX 158
 - troubleshooting 200
- Windows NT/2000 162

LPD Queues

- embedded Web server 128
- Telnet 85
- user defined 128, 157

M

MAC address, See hardware address

Manufacturing ID 206

messages

- 802.11 wireless 208
- AppleTalk 223
- DLC/LLC 224
- Errors 225
- General 205
- HP Jetdirect configuration
 - page 202
- IPX/SPX 219
- TCP/IP 215

Model number

- configuration page 205
- product list 8

Multicast Domain Name System (mDNS)

- embedded Web server 123, 149
- Telnet 87
- TFTP 54

N

NDPS, See HP IP/IPX printer gateway for NDPS

NDS

AUTHENTICATION ERROR 230

CONNECTION STATE ERROR 231

Context 221

PRINT OBJ QUEUE LIST ERROR 230

PRINT SERVER NAME ERROR 230

PRINTER OBJ NOTIFY ERR 230

PRNT SRVR PUBLIC KEY ERR 231

PS PRINTER LIST ERROR 230

SERV PUBLIC KEY ERR 230 TREE NAME 221

NDS ERR

CANNOT READ Q HOST 231

CHANGE PSSWD FAILED 230

EXCEEDS MAX SERVERS 230

INVALID SRVR VERS 231

MAX PRINT OBJECTS 231

MAX QUEUE OBJECTS 231

NO PRINTER OBJECTS 231

NO QUEUE OBJECTS 231

SRVR NAME UNRESOLVD 230

UNABLE TO FIND TREE 231

UNABLE TO LOGIN 230

UNRESOLVD PRNTR OBJ 231

UNRESOLVED QUEUE 231

NETWARE MODE 221

network

- AppleTalk (Mac OS) 28
- configuration page 202
- Error messages 225
- HP software solutions 15
- security parameters 211
- statistical parameters 214
- supported protocols 9
- TCP/IP overview 236
- NETWORK FRAME TYPE RCVD 220
- Network Name (SSID)
 - embedded Web server 112
 - Telnet configuration 80
- NIS (Network Information Service) 41
- NO QUEUE ASSIGNED 227
- NODE NAME 221
- NOT CONFIGURED 227
- Novell NetWare
 - Configuration page 221
 - embedded web server 106
 - Error messages 225
 - STATUS 221
- NOVRAM ERROR 231

O

- Open System authentication
 - embedded Web server 113
 - Telnet 81
- OUT OF BUFFERS 230

P

- PACKETS TRANSMITTED 214
- pass-phrase 82, 113
- PASSWORD ERROR 227
- password, administrator
 - printer synchronization 139
 - Web Jetadmin synchronization 138
- PEAP 11
- PEM (Privacy Enhanced Mail) 143
- ping command 72
- PORT CONFIG 206
- PORT SELECT 206

POSTSCRIPT MODE NOT SELECTED 233

- Pre-Shared Key
 - embedded Web server 113
 - Telnet 82
- Primary Frame Type 219
- print queue
 - BSD systems 158
 - LPD 85, 157
 - SAM (HP-UX) systems 160
- print server
 - EIO control panel menu 246, 249
 - supported 8
- PRINT SERVER NOT DEFINED 228
- printcap file 158
- printer control panel 99, 245
- printer gateway, See HP IP/IPX
 - printer gateway for NDPS
- PRINTER NUMBER IN USE 228
- PRINTER NUMBER NOT
DEFINED 227
- printer, selecting with Apple
Chooser 32
- privacy settings
 - embedded Web server 110
 - Telnet configuration 90
- Protected Extensible
Authentication Protocol, See
PEAP
- protocols
 - control panel configuration 245
 - embedded Web server 122, 146
 - Telnet configuration 79
 - TFTP configuration 57
- proxies, Internet Printer
 - Connection software 24
- Proxy server
 - embedded Web server 127
 - printer control panel 251
- PSERVER CLOSED
CONNECTION 229

Q

- queue names
 - LPD printing 85, 129, 157
- Queue poll interval 222
 - Telnet 92
 - TFTP 58

R

- RARP Server, identifying 216
- RARP, using 70
- RCFG (NetWare) 137, 150
- refresh rate
 - embedded Web server 134
 - Telnet web-refresh 56, 88
- renaming the printer, AppleTalk networks 30, 120
- requirements
 - embedded web server 103
 - Internet Printer Connection software 24
 - LPD configuration 156
- reset security
 - classic control panel 248
 - embedded Web server 135
 - graphical control panel 252
 - Telnet 80
 - TFTP 50
- resetting to factory defaults 186

S

- SAM (HP-UX) print queues 160
- SAP Interval 222
- SCANNING FOR SSID 226
- Secure Web
 - configuration page entry 213
 - embedded Web server 146
 - Telnet configuration 80
 - TFTP configuration 50
- security features 179
- self-test page, See configuration page
- SERVER x 222

- Service Location Protocol (SLP)
 - configuration page entry 217
 - embedded Web server 149
 - Telnet 87
 - TFTP configuration 53
- Shared Key Authentication 113
- SMTP server
 - embedded Web server 124
 - Telnet 84
 - TFTP 51
- SNMP 10
 - configuration page entry 212
 - embedded Web server 147
 - Telnet configuration 90
 - TFTP configuration 49, 56
 - version 3 147
- SNMP get community name
 - See also, Community name
 - embedded Web server 121
 - TFTP configuration 57
- SNMP set community name
 - See also, Community name
 - configuration page 212
 - embedded Web server 121
 - security features 181
 - Telnet configuration 91
 - TFTP configuration 57
- SNMP v3 182
 - embedded Web server 122
- software installation
 - AppleTalk (Mac OS) 28
 - HP Web Jetadmin 21
- speed, USB 94, 133
- SSID (Service Set Identifier) 112
 - embedded Web server 112
 - Telnet configuration 80
- Status
 - 802.11 wireless 208
 - AppleTalk 223
 - General 205
 - IPX/SPX 219
 - TCP/IP 215

- subnet mask 215
 - bootptab file parameter 44
 - overview 241
 - printer control panel 99
 - TFTP host access list 53
 - Windows configuration 67
- subnets 241
- supported network protocols 8
- syslog parameters 243
 - embedded Web server 116
 - Telnet configuration 86
 - TFTP configuration 53
- syslog server
 - Bootptab file parameter 44
 - identifying 217
 - printer control panel 99
- T**
- TCP/IP 34
 - configuration methods 34
 - configuration page 215
 - Control panel configuration 246, 249
 - embedded Web server 115
 - LPD setup 156
 - overview 236
 - STATUS message 208, 215
 - Telnet configuration 83
 - TFTP configuration 51
- Telnet
 - command line configuration 79
 - erasing the IP address 98
 - security control 181
 - using 74
- test file, printing
 - UNIX LPD 161
- TFTP
 - BOOTP 40
 - configuration file 46
 - controlling configuration 50
 - DHCP 62
 - Error messages 233
 - Server 42, 217
- TFTP (Trivial File Transfer Protocol), See TFTP
- TOTAL PACKETS RCVD 214

- traps, TFTP configuration 57
- troubleshooting 185
 - configuration page error messages 225
 - flow chart 188
 - LPD UNIX 200
 - wireless print servers 196

U

- UDP, See User Datagram Protocol
- UNABLE TO
 - ATTACH TO QUEUE 229
 - CONNECT DHCP SERVER 233
 - CONNECT TO SERVER 228, 229
 - FIND SERVER 227
 - GET NDS SRVR ADDR 231
 - LOGIN 228
 - SENSE NET NUMBER 230
 - SET PASSWORD 229
- UNEXPECTED PSERVER DATA RCVD 230
- UNICAST PACKETS RCVD 214
- UNIX (HP-UX and Solaris)
 - networks, LPD printing 154
- UNKNOWN NCP RETURN CODE 229
- UNSENDABLE PACKETS 214
- upgrades (software, driver, and flash image) 12
- upgrades, firmware
 - TFTP parameter 59
- USB
 - configuration page 207
 - embedded Web server 133
 - Telnet configuration 94
 - TFTP configuration 60
- USB speed 94, 133
- User Datagram Protocol (UDP) 237
 - datagram port control 126
 - mDNS configuration 123, 149

V

Validity Period
certificates 142

W

Web Jetadmin URL
See also, HP Web Jetadmin
configuration page entry 218
embedded Web server link 153

WEP

embedded Web server 114
Telnet configuration 81

WINS server 217

DHCP and 62

Wired Equivalent Privacy, See
WEP

wireless connection setup
embedded Web server 110
Telnet 80

wireless print servers
configuration page messages
208
default IP configuration 37
Telnet 80
troubleshooting 196

X

XMIT COLLISIONS 214

XMIT LATE COLLISIONS 214

Z

zone, AppleTalk
embedded Web server 120
HP LaserJet Utility 31
Telnet 92



i n v e n t

© 2004

Hewlett-Packard Development Company, L.P.

English